

# SECTION EXL

## EXTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

### CONTENTS

<b>XENON TYPE</b>	
<b>BASIC INSPECTION .....</b>	<b>5</b>
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>5</b>
Work Flow .....	5
<b>INSPECTION AND ADJUSTMENT .....</b>	<b>7</b>
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>7</b>
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	7
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....	7
<b>LEVELIZER ADJUSTMENT .....</b>	<b>7</b>
LEVELIZER ADJUSTMENT : Description .....	7
LEVELIZER ADJUSTMENT : Special Repair Requirement .....	7
<b>SYSTEM DESCRIPTION .....</b>	<b>8</b>
<b>HEADLAMP SYSTEM .....</b>	<b>8</b>
System Diagram .....	8
System Description .....	8
Component Parts Location .....	10
Component Description .....	10
<b>AUTO LIGHT SYSTEM .....</b>	<b>12</b>
System Diagram .....	12
System Description .....	12
Component Parts Location .....	13
Component Description .....	14
<b>DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>15</b>
System Diagram .....	15
System Description .....	15
Component Parts Location .....	16
Component Description .....	16
<b>ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM .....</b>	<b>18</b>
<b>System Diagram .....</b>	<b>18</b>
<b>System Description .....</b>	<b>18</b>
<b>Component Parts Location .....</b>	<b>20</b>
<b>Component Description .....</b>	<b>20</b>
<b>FRONT FOG LAMP SYSTEM .....</b>	<b>22</b>
System Diagram .....	22
System Description .....	22
Component Parts Location .....	23
Component Description .....	23
<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM .....</b>	<b>25</b>
System Diagram .....	25
System Description .....	25
Component Parts Location .....	26
Component Description .....	26
<b>PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM .....</b>	<b>27</b>
System Diagram .....	27
System Description .....	27
Component Parts Location .....	28
Component Description .....	29
<b>EXTERIOR LAMP BATTERY SAVER SYSTEM .....</b>	<b>30</b>
System Diagram .....	30
System Description .....	30
Component Parts Location .....	31
Component Description .....	31
<b>DIAGNOSIS SYSTEM (BCM) .....</b>	<b>32</b>
<b>COMMON ITEM .....</b>	<b>32</b>
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	32
<b>HEADLAMP .....</b>	<b>33</b>
HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP) .....	33

EXL

<b>FLASHER .....</b>	<b>35</b>	DTC Logic .....	62
FLASHER : CONSULT-III Function (BCM -		Diagnosis Procedure .....	62
FLASHER) .....	35		
<b>DIAGNOSIS SYSTEM (IPDM E/R) .....</b>	<b>37</b>		
Diagnosis Description .....	37		
CONSULT-III Function (IPDM E/R) .....	39		
<b>DIAGNOSIS SYSTEM (AFS) .....</b>	<b>42</b>		
CONSULT-III Function (ADAPTIVE LIGHT) .....	42		
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>44</b>		
<b>B2503, B2504 SWIVEL ACTUATOR .....</b>	<b>44</b>		
Description .....	44		
DTC Logic .....	44		
Diagnosis Procedure .....	45		
Component Inspection .....	48		
<b>B2514 HEIGHT SENSOR UNUSUAL [RR] .....</b>	<b>50</b>		
Description .....	50		
DTC Logic .....	50		
Diagnosis Procedure .....	50		
Component Inspection .....	52		
<b>B2516 SHIFT SIGNAL [P, R] .....</b>	<b>53</b>		
Description .....	53		
DTC Logic .....	53		
Diagnosis Procedure .....	53		
<b>B2517 VEHICLE SPEED SIGNAL .....</b>	<b>54</b>		
Description .....	54		
DTC Logic .....	54		
Diagnosis Procedure .....	54		
<b>B2519 LEVELIZER CALIBRATION .....</b>	<b>55</b>		
Description .....	55		
DTC Logic .....	55		
Diagnosis Procedure .....	55		
<b>B2521 ECU CIRCUIT .....</b>	<b>56</b>		
Description .....	56		
DTC Logic .....	56		
Diagnosis Procedure .....	56		
<b>C0126 STEERING ANGLE SENSOR SIGNAL..</b>	<b>59</b>		
Description .....	59		
DTC Logic .....	59		
Diagnosis Procedure .....	59		
<b>C0428 STEERING ANGLE SENSOR CALI-</b>			
<b>BRATION .....</b>	<b>60</b>		
Description .....	60		
DTC Logic .....	60		
Diagnosis Procedure .....	60		
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>61</b>		
Description .....	61		
DTC Logic .....	61		
Diagnosis Procedure .....	61		
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>62</b>		
DTC Logic .....	62		
Diagnosis Procedure .....	62		
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>63</b>		
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>63</b>		
BCM (BODY CONTROL MODULE) : Diagnosis			
Procedure .....	63		
<b>IPDM E/R (INTELLIGENT POWER DISTRIBU-</b>			
<b>TION MODULE ENGINE ROOM) .....</b>	<b>63</b>		
IPDM E/R (INTELLIGENT POWER DISTRIBU-			
TION MODULE ENGINE ROOM) : Diagnosis Pro-			
cedure .....	63		
<b>AFS CONTROL UNIT .....</b>	<b>64</b>		
AFS CONTROL UNIT : Diagnosis Procedure .....	64		
<b>EXTERIOR LAMP FUSE .....</b>	<b>66</b>		
Description .....	66		
Diagnosis Procedure .....	66		
<b>HEADLAMP (HI) CIRCUIT .....</b>	<b>67</b>		
Description .....	67		
Component Function Check .....	67		
Diagnosis Procedure .....	67		
<b>HEADLAMP (LO) CIRCUIT .....</b>	<b>70</b>		
Description .....	70		
Component Function Check .....	70		
Diagnosis Procedure .....	70		
<b>XENON HEADLAMP .....</b>	<b>72</b>		
Description .....	72		
Diagnosis Procedure .....	72		
<b>HEADLAMP LEVELIZER CIRCUIT .....</b>	<b>74</b>		
Description .....	74		
Component Function Check .....	74		
Diagnosis Procedure .....	74		
<b>FRONT FOG LAMP CIRCUIT .....</b>	<b>76</b>		
Component Function Check .....	76		
Diagnosis Procedure .....	76		
<b>PARKING LAMP CIRCUIT .....</b>	<b>78</b>		
Component Function Check .....	78		
Diagnosis Procedure .....	78		
<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>80</b>		
Description .....	80		
Component Function Check .....	80		
Diagnosis Procedure .....	80		
<b>OPTICAL SENSOR .....</b>	<b>83</b>		
Description .....	83		
Component Function Check .....	83		
Diagnosis Procedure .....	83		
<b>HAZARD SWITCH .....</b>	<b>86</b>		
Description .....	86		
Component Function Check .....	86		

Diagnosis Procedure .....	86	Reference Value .....	176
<b>TAIL LAMP CIRCUIT .....</b>	<b>88</b>	Wiring Diagram - ACTIVE AFS - .....	179
Component Function Check .....	88	Fail-Safe .....	186
Diagnosis Procedure .....	88	DTC Inspection Priority Chart .....	186
DTC Index .....	187		
<b>LICENSE PLATE LAMP CIRCUIT .....</b>	<b>90</b>	<b>SYMPTOM DIAGNOSIS .....</b>	<b>188</b>
Component Function Check .....	90	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS.</b>	<b>188</b>
Diagnosis Procedure .....	90	Symptom Table .....	188
<b>HEADLAMP SYSTEM .....</b>	<b>91</b>	<b>NORMAL OPERATING CONDITION .....</b>	<b>191</b>
Wiring Diagram - HEADLAMP - .....	91	Description .....	191
<b>AUTO LIGHT SYSTEM .....</b>	<b>95</b>	<b>BOTH SIDE HEADLAMPS DO NOT SWITCH</b>	<b>192</b>
Wiring Diagram - AUTO LIGHT SYSTEM - .....	95	TO HIGH BEAM .....	192
<b>HEADLAMP AIMING CONTROL SYSTEM</b>		Description .....	192
<b>(MANUAL) .....</b>	<b>99</b>	Diagnosis Procedure .....	192
Description .....	99	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT</b>	<b>193</b>
Wiring Diagram - HEADLAMP AIMING CON-		TURNED ON .....	193
TROL SYSTEM (MANUAL) - .....	99	Description .....	193
Component Inspection .....	100	Diagnosis Procedure .....	193
<b>DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>102</b>	<b>PARKING, LICENSE PLATE AND TAIL</b>	
Wiring Diagram - DAYTIME LIGHT SYSTEM - ....	102	<b>LAMPS ARE NOT TURNED ON .....</b>	<b>194</b>
<b>FRONT FOG LAMP SYSTEM .....</b>	<b>107</b>	Description .....	194
Wiring Diagram - FRONT FOG LAMP - .....	107	Diagnosis Procedure .....	194
<b>TURN SIGNAL AND HAZARD WARNING</b>		<b>BOTH SIDE FRONT FOG LAMPS ARE NOT</b>	
<b>LAMP SYSTEM .....</b>	<b>111</b>	<b>TURNED ON .....</b>	<b>195</b>
Wiring Diagram - TURN AND HAZARD WARN-		Description .....	195
ING LAMPS - .....	111	Diagnosis Procedure .....	195
<b>PARKING, LICENSE PLATE AND TAIL</b>		<b>PRECAUTION .....</b>	<b>196</b>
<b>LAMPS SYSTEM .....</b>	<b>115</b>	<b>PRECAUTIONS .....</b>	<b>196</b>
Wiring Diagram - PARKING LICENSE PLATE		Precaution for Supplemental Restraint System	
AND TAIL LAMPS - .....	115	(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	
<b>STOP LAMP .....</b>	<b>120</b>	SIONER" .....	196
Wiring Diagram - STOP LAMP - .....	120	Precautions For Xenon Headlamp Service .....	196
<b>BACK-UP LAMP .....</b>	<b>124</b>	<b>PERIODIC MAINTENANCE .....</b>	<b>197</b>
Wiring Diagram - BACK-UP LAMP - .....	124	<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>197</b>
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>127</b>	Description .....	197
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>127</b>	Aiming Adjustment Procedure .....	198
Reference Value .....	127	<b>FRONT FOG LAMP AIMING ADJUSTMENT .</b>	<b>199</b>
Wiring Diagram - BCM - .....	151	Description .....	199
Fail-safe .....	157	Aiming Adjustment Procedure .....	199
DTC Inspection Priority Chart .....	160	<b>REMOVAL AND INSTALLATION .....</b>	<b>201</b>
DTC Index .....	160	<b>FRONT COMBINATION LAMP .....</b>	<b>201</b>
<b>IPDM E/R (INTELLIGENT POWER DISTRIBU-</b>		Exploded View .....	201
<b>TION MODULE ENGINE ROOM) .....</b>	<b>163</b>	Removal and Installation .....	202
Reference Value .....	163	Replacement .....	202
Wiring Diagram - IPDM E/R - .....	170	Disassembly and Assembly .....	203
Fail-safe .....	173	<b>FRONT FOG LAMP .....</b>	<b>205</b>
DTC Index .....	175	Exploded View .....	205
<b>AFS CONTROL UNIT .....</b>	<b>176</b>		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
EXL

Removal and Installation .....	205	Exploded View .....	214
Replacement .....	205	Removal and Installation .....	214
<b>OPTICAL SENSOR .....</b>	<b>207</b>	<b>REAR COMBINATION LAMP .....</b>	<b>215</b>
Exploded View .....	207	Exploded View .....	215
Removal and Installation .....	207	Removal and Installation .....	215
<b>LIGHTING &amp; TURN SIGNAL SWITCH .....</b>	<b>208</b>	Replacement .....	216
Exploded View .....	208	<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>217</b>
<b>HEADLAMP AIMING SWITCH .....</b>	<b>209</b>	Exploded View .....	217
Exploded View .....	209	Removal and Installation .....	217
Removal and Installation .....	209	<b>BACK-UP LAMP .....</b>	<b>218</b>
<b>HAZARD SWITCH .....</b>	<b>210</b>	Exploded View .....	218
Exploded View .....	210	Removal and Installation .....	218
<b>AFS CONTROL UNIT .....</b>	<b>211</b>	Replacement .....	218
Exploded View .....	211	<b>LICENSE PLATE LAMP .....</b>	<b>220</b>
Removal and Installation .....	211	Exploded View .....	220
<b>STEERING ANGLE SENSOR .....</b>	<b>212</b>	Removal and Installation .....	220
Removal and Installation .....	212	Replacement .....	220
<b>AFS OFF SWITCH .....</b>	<b>213</b>	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>221</b>
Exploded View .....	213	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>221</b>
Removal and Installation .....	213	Bulb Specifications .....	221
<b>HEIGHT SENSOR .....</b>	<b>214</b>		

&lt; BASIC INSPECTION &gt;


# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORKFLOW

### Work Flow

INFOID:000000003846116

### OVERALL SEQUENCE



### DETAILED FLOW

#### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
  
EXL  
  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

[XENON TYPE]

< BASIC INSPECTION >

>> GO TO 2.

## 2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# INSPECTION AND ADJUSTMENT

[XENON TYPE]

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000003846117

Perform "LEVELIZER ADJUSTMENT" with CONSULT-III when replacing the height sensor.

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000003846118

### 1. LEVELIZER ADJUSTMENT

Perform "LEVELIZER ADJUSTMENT".

>> Refer to [EXL-7, "LEVELIZER ADJUSTMENT : Special Repair Requirement".](#)

#### LEVELIZER ADJUSTMENT

##### LEVELIZER ADJUSTMENT : Description

INFOID:000000003846119

Perform "LEVELIZER ADJUSTMENT" when installing, removing, and replacing the height sensor and the suspension components.

##### LEVELIZER ADJUSTMENT : Special Repair Requirement

INFOID:000000003846120

### 1. CHECK VEHICLE CONDITION

1. Park the vehicle in the straight-forward position.
2. Unload the vehicle (no passenger aboard).

>> GO TO 2.

### 2. LEVELIZER ADJUSTMENT

#### CONSULT-III WORK SUPPORT

1. Select "LEVELIZER ADJUSTMENT" of ADAPTIVE LIGHT work support item.
2. Select "START".
3. When "ADJUSTMENT IS COMPLETED", select "END".

#### **CAUTION:**

If "CAN NOT BE TESTED" is indicated, AFS control unit detects that the height sensor signal changes. The levelizer adjustment is cancelled. In this case, turn the ignition switch OFF to prevent the vehicle from the height change. Perform the levelizer adjustment again.

EXL

Is the levelizer adjustment completed?

YES >> GO TO 3.

NO >> Perform the levelizer adjustment again.

### 3. SELF-DIAGNOSIS RESULT CHECK

Perform self-diagnosis with CONSULT-III. Check that any DTC is not detected.

Is any DTC detected?

YES >> GO TO 2.

NO >> Levelizer adjustment completed


&lt; SYSTEM DESCRIPTION &gt;

## SYSTEM DESCRIPTION

### HEADLAMP SYSTEM

#### System Diagram

INFOID:0000000003846121



#### System Description

INFOID:0000000003846122

##### OUTLINE

- Mobile valve shade type is adopted. Xenon headlamp switches the high beam and the low beam with one xenon bulb each on right and left.
- Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

##### HEADLAMP BASIC OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp ON condition.

##### Headlamp ON condition

- Lighting switch 2ND
- Lighting switch PASS
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

##### HEADLAMP HI/LO SWITCHING OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter (through the unified meter and A/C amp.) with CAN communication according to the high beam switching condition.

##### High beam switching condition


- Lighting switch HI with the headlamp ON
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.

# HEADLAMP SYSTEM

[XENON TYPE]

## < SYSTEM DESCRIPTION >

- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (2) is switched to the high beam position.
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.



A  
B  
C  
D  
E  
F  
G

H  
I  
J  
K

EXL

M  
N  
O  
P


# HEADLAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:000000003846123



JPMIA1091ZZ

- |                                     |                                |                             |
|-------------------------------------|--------------------------------|-----------------------------|
| 1. Headlamp                         | 2. Combination switch          | 3. BCM                      |
| 4. IPDM E/R                         | 5. Unified meter and A/C amp.  | 6. High beam indicator lamp |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind cluster lid C     |
| D. On the combination meter         |                                |                             |

## Component Description

INFOID:000000003846124

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges that the headlamp is turned ON according to the vehicle condition.</li> <li>- Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication).</li> <li>- Requests the high beam indicator lamp ON to the combination meter [with CAN communication (through the unified meter and A/C amp.)].</li> </ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).

# HEADLAMP SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

Part	Description	
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .	
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM [with CAN communication (through the unified meter and A/C amp.)].	
Headlamp assembly	• HID control unit • Xenon bulb	Refer to <a href="#">EXL-72, "Description"</a> .
	High beam solenoid	Refer to <a href="#">EXL-67, "Description"</a> .

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# AUTO LIGHT SYSTEM


[XENON TYPE]

< SYSTEM DESCRIPTION >

## AUTO LIGHT SYSTEM

### System Diagram

INFOID:0000000003846125



JPLIA0005GB

### System Description

INFOID:0000000003846126

#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function and the delay timer function.
- Auto light function turns the exterior lamps\* and each illumination ON/OFF automatically according to the outside brightness.
- When auto light system turns the exterior lamps ON with the ignition switch OFF, delay timer function turns the exterior lamps OFF depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), parking lamp, side marker lamp, tail lamp, license plate lamp and front fog lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

#### AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the ignition switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R with CAN communication according to ON/OFF condition by the auto light function.

#### NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT-III. Refer to [EXL-33, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#).

#### DELAY TIMER FUNCTION

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens (Door switch ON).
- Turns the exterior lamp OFF a certain period of time\* after closing all doors (Door switch ON→OFF).

# AUTO LIGHT SYSTEM

[XENON TYPE]

## < SYSTEM DESCRIPTION >

- Turns the exterior lamp OFF with the ignition switch ACC or the light switch OFF.


\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT-III. Refer to EXL-33, "HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)".

### NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

## Component Parts Location

INFOID:000000003846127



JPMIA1092ZZ

- |                                |                                     |                                |
|--------------------------------|-------------------------------------|--------------------------------|
| 1. Combination switch          | 2. Optical sensor                   | 3. BCM                         |
| 4. IPDM E/R                    | 5. Unified meter and A/C amp.       |                                |
| A. Instrument upper panel (RH) | B. Dash side lower (passenger side) | C. Engine room dash panel (RH) |
| D. Behind cluster lid C        |                                     |                                |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
**EXL**  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

## Component Description

INFOID:000000003846128

Part	Description
BCM	<ul style="list-style-type: none"><li>Detects each switch condition by the combination switch reading function.</li><li>Judges the outside brightness from the optical sensor signal.</li><li>Judges the OFF timing according to the vehicle condition.</li><li>Judges the ON/OFF status of the exterior lamp and each illumination according to the outside brightness and the vehicle condition.</li><li>Requests ON/OFF of each relay to IPDM E/R (with CAN communication).</li></ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .
Optical sensor	Refer to <a href="#">EXL-83, "Description"</a> .


# DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

### System Diagram



### System Description

INFOID:0000000003846490

#### OUTLINE

- Turns the front fog lamp ON as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

#### DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the vehicle condition depending on the following signals.
  - Engine condition signal (received from ECM with CAN communication)
  - Parking brake switch signal (received from unified meter and A/C amp. with CAN communication)
- BCM transmits the front fog light request signal to IPDM E/R with CAN communication according to the daytime running light ON condition.

#### Daytime running light ON condition

- While the engine running with the parking brake released

#### Daytime running light OFF condition

- Engine stopped
- Headlamp ON (passing included)
- IPDM E/R turns the integrated front fog lamp relay ON and turns the front fog lamp ON according to the front fog light request signal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


# DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:000000003846491



- |  |                                |                               |
|--|--------------------------------|-------------------------------|
| 1. Daytime running light<br>(Front fog lamp) | 2. Combination switch          | 3. BCM                        |
| 4. IPDM E/R                                  | 5. ECM                         | 6. Unified meter and A/C amp. |
| A. Dash side lower (passenger side)          | B. Engine room dash panel (RH) | C. Behind the glove box       |
| D. Behind the cluster lid C                  |                                |                               |

JPMIA1093ZZ

## Component Description

INFOID:000000003846492

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition with the combination switch reading function.</li> <li>Judges the headlamp ON/OFF status according to the vehicle condition. Requests the front fog lamp relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).

# DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

Part	Description
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .
ECM	Transmits the engine condition signal to BCM with CAN communication.
Unified meter and A/C amp.	Transmits the parking brake switch signal to BCM with CAN communication.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


# ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

### System Diagram



### System Description

INFOID:0000000003846682

#### OUTLINE

- AFS (ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM) is controlled by AFS control unit.
- AFS has AFS control (swivel control) and the headlamp auto aiming control.
- AFS control swivels the headlamp to the steering direction.
- Headlamp auto aiming control moves the headlamp light axis up/down according to the vehicle height.

#### AFS (ADAPTIVE FRONT-LIGHTING SYSTEM)

##### AFS Control Description

- AFS control controls the headlamp (right) only when the steering wheel is turned rightward, and the headlamp (left) only when the steering wheel is turned leftward.
- AFS control unit detects the vehicle condition necessary for AFS control with the following signals.
- AFS switch signal
- Steering angle sensor signal (received from steering angle sensor with CAN communication)
- Engine speed signal (received from ECM with CAN communication)
- Shift position signal (received from TCM with CAN communication)
- Low beam status and high beam status (received from IPDM E/R with CAN communication)
- Vehicle speed signal (received from unified meter and A/C amp. with CAN communication)
- When the operation conditions are satisfied, AFS control unit controls the swivel angle depending on the steering angle and the vehicle speed.

##### AFS operation condition

- Swivel actuator initialization completed
- AFS OFF switch OFF
- Headlamp ON
- While the engine running
- Selector lever position other than "P" or "R"
- Vehicle speed approximately 25 km/h (15.5 MPH) or more (left swivel only; Right swivel activates regardless of the vehicle speed.)

# ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

## < SYSTEM DESCRIPTION >

[XENON TYPE]

### Swivel Actuator Initialization

- AFS control unit performs the swivel actuator initialization when detecting that the engine starts.
- Swivels the headlamp to the vehicle-center side until it hits the stopper.
- Returns the swivel angle from the stopper. Completes the initialization with regarding the returned position as the swivel angle 0° (straight-forward position).

### Swivel Operation

- AFS control unit transmits the drive signal to the swivel actuator when activation conditions are satisfied. And swivels the headlamp.
- The swivel starts after steering approximately 20° or more from straight-forward position.

#### NOTE:

The steering angle differs between right turn and left turn.

- The swivel angle becomes the maximum angle toward the driving direction if the steering angle is approximately 90° or more depending on the vehicle speed. The swivel angle is maintained by shutting off the drive signal.
- The swivel starts, and returns to the swivel angle 0° (straight-forward position) when the steering is returned to the straight-forward position.
- AFS control unit returns the swivel angle to the straight-forward position, and stops the swivel regardless of the steering angle if the operation condition is not satisfied while the swivel angle is 0°.

### AFS OFF Indicator Lamp

- AFS control unit transmits AFS OFF indicator lamp signal to the combination meter (through the unified meter and A/C amp.) with CAN communication.
- Combination meter turns AFS OFF indicator lamp ON/OFF/blinking according to AFS OFF indicator lamp signal.
- AFS OFF indicator lamp is turned ON for 1 second for the AFS OFF indicator lamp bulb check when the ignition switch is turned ON. AFS OFF indicator lamp is turned OFF within 1 second when the engine starts.
- AFS OFF indicator lamp is turned OFF when AFS OFF switch is turned ON.
- AFS OFF indicator lamp blinks (1 second each) if AFS control unit detects a specific DTC.

#### NOTE:

Combination meter blinks AFS OFF indicator lamp (approximately 1 second each) if AFS OFF indicator lamp signal is not received from AFS control unit.

## HEADLAMP AUTO AIMING

### Headlamp Auto Aiming Control Description

- Headlamp auto aiming control controls the headlamp light axis height appropriately according to the vehicle height.
- AFS control unit detects the vehicle condition necessary for headlamp auto aiming control with the following signals.
  - Height sensor signal
  - Engine speed signal (received from ECM with CAN communication)
  - Low beam status signal and high beam status signal (received from IPDM E/R with CAN communication)
  - Vehicle speed signal (received from unified meter and A/C amp. with CAN communication)
- When the operation conditions are satisfied, AFS control unit transmits the aiming motor drive signal for adjusting the headlamp axis height.

EXL

### Headlamp auto aiming operation condition

- Headlamp ON
- While the engine running
- Vehicle speed (Control mode is switched according to the driving condition.)

N

### Headlamp Auto Aiming Operation

- AFS control unit calculates the vehicle pitch angle from the height sensor signal. AFS control unit judges the angle for adjusting the axis gap from the preset position.

P

#### CAUTION:

**Adjusted axis position may differ from the preset position although the headlamp auto aiming activates properly if the suspension is replaced or worn.**

- AFS control unit controls the headlamp axis by changing the aiming motor drive signal output according to the vehicle-rearward height when detecting the following vehicle condition. Output is maintained if other condition than following is detected.
  - Engine starts.
  - Headlamp is turned ON.

# ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM


## < SYSTEM DESCRIPTION >

[XENON TYPE]

- Vehicle posture becomes stable after changing the vehicle posture change is detected with the headlamp ON and the vehicle stopped.
- Vehicle speed is maintained with the headlamp ON and the vehicle driven.

## Component Parts Location

INFOID:000000003846683



- |                                   |                                  |   |
|-----------------------------------|----------------------------------|---|
| 1. IPDM E/R                       | 2. ECM                           | 3. Swivel actuator                          |
| 4. Aiming motor                   | 5. Steering angle sensor         | 6. AFS OFF switch                           |
| 7. AFS control unit               | 8. Height sensor                 | 9. AFS OFF indicator lamp                   |
| 10. Unified meter and A/C amp.    |                                  |   |
| A. Engine room dash panel (RH)    | B. Behind the glove box          | C. Front combination lamp (back)            |
| D. Steering column cover (inside) | E. Instrument driver lower panel | F. Behind the instrument driver lower panel |
| G. Rear suspension member (LH)    | H. On the combination meter      | I. Behind the cluster lid C                 |

## Component Description

INFOID:000000003846684

# ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

Part	Description
AFS control unit	Refer to <a href="#">EXL-56, "Description"</a> .
Swivel actuator	Refer to <a href="#">EXL-44, "Description"</a> .
Aiming motor	Refer to <a href="#">EXL-74, "Description"</a> .
AFS OFF switch	Inputs AFS OFF switch ON/OFF signal to AFS control unit.
Height sensor	Refer to <a href="#">EXL-50, "Description"</a> .
Steering angle sensor	Refer to <a href="#">EXL-59, "Description"</a> .
IPDM E/R	Transmits the headlamp (LO) ON signal and the headlamp (HI) ON signal to AFS control unit with CAN communication.
ECM	Transmits the engine speed signal to AFS control unit with CAN communication.
TCM	Refer to <a href="#">EXL-53, "Description"</a> .
Unified meter and A/C amp.	Refer to <a href="#">EXL-54, "Description"</a> .
Combination meter	Turns AFS OFF indicator lamp ON/OFF/blinking according to AFS control unit request [with CAN communication (through the unified meter and A/C amp.)].

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# FRONT FOG LAMP SYSTEM


[XENON TYPE]

< SYSTEM DESCRIPTION >

## FRONT FOG LAMP SYSTEM

### System Diagram

INFOID:0000000003846493



### System Description

INFOID:0000000003846494

#### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

#### NOTE:

For Canada models, the front fog lamp is turned ON as the daytime running light. Refer to [EXL-15. "System Diagram"](#) for the detail.

#### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R and the combination meter (through the unified meter and A/C amp.) with CAN communication according to the front fog lamp ON condition.

##### Front fog lamp ON condition

- Front fog lamp switch ON with the headlamp ON (except for the high beam ON)
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.
- Combination meter turns the front fog lamp indicator lamp ON according to the front fog light request signal.


# FRONT FOG LAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:000000003846495



JPMIA1095ZZ

- |                                     |                                |                                  |
|-------------------------------------|--------------------------------|----------------------------------|
| 1. Front fog lamp                   | 2. Combination switch          | 3. BCM                           |
| 4. IPDM E/R                         | 5. Unified meter and A/C amp.  | 6. Front fog lamp indicator lamp |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the cluster lid C      |
| D. On the combination meter         |                                |                                  |

## Component Description

INFOID:000000003846496

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges the front fog lamp ON/OFF status according to the vehicle condition. Requests the front fog lamp relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).

## FRONT FOG LAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

Part	Description
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .
Combination meter (Front fog lamp indicator lamp)	Turns the front fog lamp indicator lamp ON according to the request from BCM [with CAN communication (through the unified meter and A/C amp.)].

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< SYSTEM DESCRIPTION >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### System Diagram

INFOID:0000000003846141



### System Description

INFOID:0000000003846142

#### OUTLINE

Turn signal and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

#### TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

#### HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

#### TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter (through the unified meter and A/C amp.) with CAN communication while the turn signal lamp and the hazard warning lamp operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

#### HIGH FLASHER OPERATION (FAIL-SAFE)

- BCM detects the turn signal lamp circuit status by the terminal current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:000000003846143



JPMIA1096ZZ

- |                                     |                             |                               |
|-------------------------------------|-----------------------------|-------------------------------|
| 1. Hazard switch                    | 2. Front turn signal lamp   | 3. Combination switch         |
| 4. Rear turn signal lamp            | 5. BCM                      | 6. Unified meter and A/C amp. |
| 7. Turn signal indicator lamp       |                             |                               |
| A. Dash side lower (passenger side) | B. Behind the cluster lid C | C. On the combination meter   |

## Component Description

INFOID:000000003846144

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks.</li> <li>Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .
Hazard switch (Multifunction switch)	Refer to <a href="#">EXL-86, "Description"</a> .
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM [with CAN communication (through the unified meter and A/C amp.)].


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### System Diagram



INFOID:000000003846145

### System Description

INFOID:000000003846146

#### OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

#### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R with CAN communication according to the ON/OFF condition of the parking, license plate, side marker and tail lamps.

Parking, license plate, side marker and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking lamp, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:0000000003846147



- |                                     |                                |                               |
|-------------------------------------|--------------------------------|-------------------------------|
| 1. Parking lamp                     | 2. Front side marker lamp      | 3. Combination switch         |
| 4. Rear side marker lamp            | 5. Tail lamp                   | 6. License plate lamp         |
| 7. BCM                              | 8. IPDM E/R                    | 9. Unified meter and A/C amp. |
| 10. Tail lamp indicator lamp        |                                |                               |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the cluster lid C   |
| D. On the combination meter         |                                |                               |

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Description

INFOID:000000003846148

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM

### System Diagram



### System Description

INFOID:0000000003846150

#### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

#### Control by IPDM E/R

- Relay control function
- BCM turns the exterior lamp\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.

\*: Headlamp (LO/HI), parking lamp, tail lamp, side marker lamp, license plate lamp and front fog lamp

#### NOTE:

When the lighting switch is turned AUTO, the exterior lamp battery saver switches to the auto light system.  
Refer to [EXL-12. "System Diagram"](#).

#### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the ignition switch is turned from ON → OFF with the exterior lamps ON.

#### NOTE:

- Headlamp control function turns the exterior lamps ON normally when the ignition switch is turned ACC or the engine started (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamp OFF.


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Component Parts Location

INFOID:000000003846151



1. Combination switch

2. BCM

3. IPDM E/R

4. Unified meter and A/C amp.

A. Dash side lower (passenger side)

B. Engine room dash panel (RH)

C. Behind cluster lid C

## Component Description

INFOID:000000003846152

EXL

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"><li>Detects each switch condition by the combination switch reading function.</li><li>Judges the exterior lamp OFF according to the vehicle condition. Requests each relay OFF to IPDM E/R (with CAN communication).</li></ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "System Diagram"</a> .

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004068504

#### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>• Read and save the vehicle specification.</li> <li>• Write the vehicle specification when replacing BCM.</li> </ul>

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x

#### NOTE:

\*: This item is displayed, but is not used.

#### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	A
	SLEEP>OFF		B
	LOCK>ACC		C
	ACC>ON		D
	RUN>ACC		E
	CRANK>RUN		F
	RUN>URGENT		G
	ACC>OFF		H
	OFF>LOCK		I
	OFF>ACC		J
	ON>CRANK		K
	OFF>SLEEP		L
	LOCK>SLEEP		M
	LOCK		N
	OFF		O
	ACC		P
	ON		EXL
	ENGINE RUN		
	CRANKING		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## HEADLAMP

### HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000003846154

#### WORK SUPPORT

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING	MODE 1*	Normal
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation.)
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2.)
	MODE 4	Less sensitive setting than normal setting (Turns ON later than normal operation.)
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

**[XENON TYPE]**

Service item	Setting item	Setting
ILL DELAY SET	MODE 1*	45 sec.
	MODE 2	Without the function
	MODE 3	30 sec.
	MODE 4	60 sec.
	MODE 5	90 sec.
	MODE 6	120 sec.
	MODE 7	150 sec.
	MODE 8	180 sec.

\*: Factory setting

## DATA MONITOR

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ENGINE STATE [Stop/Stall/Crank/Run]	The engine status received from ECM with CAN communication
VEH SPEED 1 [km/h]	The value of the vehicle speed received from unified meter and A/C amp. with CAN communication
KEY SW-SLOT [On/Off]	Key switch status input from key slot
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	
DOOR SW-RR [On/Off]	
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor item [Unit]	Description
DOOR SW-BK [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
OPTICAL SENSOR [V]	The value of exterior brightness voltage input from the optical sensor

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the position light request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	Low	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	Transmits the front fog light request signal to IPDM E/R with CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog light request signal transmission.
RR FOG LAMP	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
	Off	
CORNERRING LAMP	RH	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	Off	
ILL DIM SIGNAL	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
	Off	

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000003846155

K

## WORK SUPPORT

EXL

Service item	Setting item	Setting
HAZARD ANSWER BACK	Lock/Unlk*	With locking/unlocking
	Unlk Only	With unlocking only
	Lock Only	With locking only
	Off	Without the function

\*: Factory setting

M

N

## DATA MONITOR

O

P

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from the request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from the request switch (passenger side)
PUSH SW [On/Off]	The switch status input from the push-button ignition switch

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Lock signal status received from the remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from the remote keyless entry receiver
RKE-PANIC [On/Off]	Panic alarm signal status received from the remote keyless entry receiver

## ACTIVE TEST

Test item	Operation	Description
FLASHER	Off	Stops the voltage to turn the turn signal lamps OFF.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	RH	Outputs the voltage to blink the right side turn signal lamps.

&lt; SYSTEM DESCRIPTION &gt;

**DIAGNOSIS SYSTEM (IPDM E/R)****Diagnosis Description**

INFOID:0000000004068505

**AUTO ACTIVE TEST****Description**

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side marker lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

**Operation Procedure**

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

**NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**

When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

**CAUTION:**

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-69, "Component Function Check".](#)
- Do not start the engine.

**Inspection in Auto Active Test Mode**

When auto active test mode is actuated, the following 5 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Side marker lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> </ul>	10 seconds
3	Headlamps	<ul style="list-style-type: none"> <li>• LO 10 seconds</li> <li>• HI ON ↔ OFF 5 times</li> </ul>
4	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
5*	Cooling fan	MID for 5 seconds → HI for 5 seconds


\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Parking lamps • License plate lamps • Side marker lamps • Tail lamps • Front fog lamps • Headlamp (HI, LO) • Front wiper	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES • Unified meter and A/C amp. signal input circuit • CAN communication signal between unified meter and A/C amp. and ECM • CAN communication signal between ECM and IPDM E/R
		NO • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES • Harness or connector between IPDM E/R and oil pressure switch • Oil pressure switch • IPDM E/R
		NO • CAN communication signal between IPDM E/R and BCM • CAN communication signal between BCM and unified meter and A/C amp. • Combination meter

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Symptom	Inspection contents	Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul> <ul style="list-style-type: none"> <li>• Cooling fan</li> <li>• Harness or connector between cooling fan and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connector between IPDM E/R and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000004068506

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [EXL-175, "DTC Index"](#).

### DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST /INHI/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the control device (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay request received from BCM via CAN communication.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R.
DTRL REQ [Off]		<b>NOTE:</b> The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

### Test item

Test item	Operation	Description
CORNERING LAMP	Off	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay 1 and horn relay 2 for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation	Description
HEAD LAMP WASHER	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# DIAGNOSIS SYSTEM (AFS)

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DIAGNOSIS SYSTEM (AFS)

### CONSULT-III Function (ADAPTIVE LIGHT)

INFOID:0000000003846446

#### APPLICATION ITEM

Diagnostic mode	Description
Ecu Identification	Allows confirmation of AFS control unit part number.
Self Diagnostic Result	Displays the diagnosis results judged by AFS control unit.
Work support	Sets each sensor.
Data monitor	Indicates AFS control unit input data in real time.
Active test	Provides the drive signal to the load. Checks operation.

#### WORK SUPPORT

Service item	Description
ST ANG SEN ADJUSTMENT*	—
LEVELIZER ADJUSTMENT	Adjusts the height sensor signal output value (AFS control unit recognized) in the un-loaded vehicle condition.

\*: Adjusts the steering angle sensor neutral position on ABS actuator and electrical unit (control unit) side. Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

#### DATA MONITOR

Monitor item [Unit]	Description
STR ANGLE SIG [°]	The steering angle value judged by the steering angle sensor signal received from the steering angle sensor with CAN communication
VHCL SPD [km/h]	The vehicle speed signal value from the unified meter and A/C amp. with CAN communication
SLCT LVR POSI [P - 1]	The selector lever status judged by the position indicator signal received from TCM with CAN communication
HEAD LAMP [On/Off]	The headlamp On/Off status judged by the low beam headlamp (ON) signal received from IPDM E/R with CAN communication
AFS SW [On/Off]	The switch status input from AFS OFF switch
HI SEN OTP RR [V]	The height sensor signal voltage value input from the height sensor
LEV ACTR VLTG [%]	The ratio value to the battery voltage generated by the levelizer activation signal control value judged by AFS control unit
SWVL SEN RH* [°]	The head lamp swivel angle value judged by AFS control unit received from the swivel position sensor signal input from the swivel actuator
SWVL SEN LH* [°]	The swivel angle command value to the swivel motor judged by AFS control unit
SWVL ANGLE RH* [°]	
SWVL ANGLE LH * [°]	

\*: The swivel angle "0°" (feedback value) of the swivel position sensor signal may differ from the swivel angle "0°" of the swivel motor (AFS control unit command value). This causes that the swivel motor initializes the value based on the step number from the stopper.

#### ACTIVE TEST

##### CAUTION:

Start the engine when using "ACTIVE TEST".

# DIAGNOSIS SYSTEM (AFS)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation Item	Description
LOW BEAM TEST RIGHT	Origin Fast	Swivels the right headlamp to the swivel angle 0° in the normal speed.
	Peak Fast	Swivels the right headlamp to the swivel angle approximately 15° in the normal speed.
	Origin Slow	Swivels the right headlamp to the swivel angle 0° in the speed at the initialization.
	Peak Slow	Swivels the right headlamp to the swivel angle approximately 15° in the speed at the initialization.
LOW BEAM TEST LEFT	Origin Fast	Swivels the left headlamp to the swivel angle 0° in the normal speed.
	Peak Fast	Swivels the left headlamp to the swivel angle approximately 17° in the normal speed.
	Origin Slow	Swivels the left headlamp to the swivel angle 0° in the speed at the initialization.
	Peak Slow	Swivels the left headlamp to the swivel angle approximately 17° in the speed at the initialization.
LEVELIZER TEST	Origin	Changes the aiming motor drive signal to approximately 70% of the battery voltage. Moves the headlamp upward and downward.
	Peak	Changes the aiming motor drive signal to approximately 15% of the battery voltage. Moves the headlamp upward and downward.

**NOTE:**

"Fast" operation speed is as three times fast as "Slow".

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

## DTC/CIRCUIT DIAGNOSIS

### B2503, B2504 SWIVEL ACTUATOR

#### Description

INFOID:000000003846453

#### SWIVEL ACTUATOR

The swivel actuator is installed in the headlamp unit. The swivel actuator consists of the swivel motor and the swivel position sensor.

#### SWIVEL MOTOR

- The swivel motor is the two-phase step motor.
- The swivel motor drives headlamp by exciting the two drive coils according to the drive signal from AFS control unit.
- The rotation direction of the swivel motor is changeable by changing the exciting pattern.

#### SWIVEL POSITION SENSOR

The swivel position sensor detects the headlamp swivel angle to transmit the swivel position sensor signal to AFS control unit.

#### DTC Logic

INFOID:000000003846454

#### DTC DETECTION LOGIC

- [B2503] Swivel actuator [RH]
- [B2504] Swivel actuator [LH]

DTC detection condition	DTC erase condition	Possible cause
AFS control unit indicates an applicable DTC when detecting any of the following conditions continuously for 2 seconds or more. <ul style="list-style-type: none"> <li>• AFS control unit-recognized swivel position differs extremely from the swivel position sensor-input value while the swivel operating.*</li> <li>• The swivel position sensor signal does not change even though AFS control unit transmits the swivel motor driving signal while the swivel operating.*</li> <li>• The swivel motor short and open is detected while the swivel operating.*</li> <li>• The swivel position sensor power supply is 6 V or more, or 4 V or less.</li> <li>• The swivel position sensor signal is 0.25 V or less, or 4.75 V or more.</li> </ul>	Ignition switch OFF	Swivel position sensor <ul style="list-style-type: none"> <li>• Swivel position sensor</li> <li>• Harness and connector</li> <li>• AFS control unit</li> </ul> Swivel motor <ul style="list-style-type: none"> <li>• Swivel motor</li> <li>• Harness and connector</li> <li>• AFS control unit</li> </ul>

\*: initialization is not included.

#### DTC CONFIRMATION PROCEDURE

##### 1.DTC ERASE

Erase the DTC memory of AFS with CONSULT-III.

>> GO TO 2.

##### 2.CONFIRMATION DTC SELECTION

Select "B2503" or "B2504" for confirmation.

##### Which DTC is confirmation?

B2503 >> GO TO 3.

B2504 >> GO TO 4.

##### 3.DTC CONFIRMATION (B2503)

1. Steer to the straight-forward position.
2. Start the engine.
3. Turn AFS OFF switch OFF.
4. Turn the headlamp ON.
5. Shift the selector lever to "N".
6. Steer to the right. (Rotate it once or more.)
7. Perform the self-diagnosis with CONSULT-III.

# B2503, B2504 SWIVEL ACTUATOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Is "B2503" detected?

- YES >> Refer to [EXL-45, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-35, "Intermittent Incident"](#).

A

## 4.DTC CONFIRMATION (B2504)

1. Steer to the straight-forward position.
2. Start the engine.
3. Turn AFS OFF switch OFF.
4. Turn the headlamp ON.
5. Drive at 25 km/h (15.5 MPH) or more.
6. Steer to the left. (Rotate it once or more.)
7. Stop the vehicle.
8. Perform the self-diagnosis with CONSULT-III.

B

Is "B2504" detected?

- YES >> Refer to [EXL-45, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-35, "Intermittent Incident"](#).

C

## Diagnosis Procedure

INFOID:0000000003846455

### 1.CHECK SWIVEL POSITION SENSOR SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check the voltage between the AFS control unit harness connector and the ground.

D

Terminals		Voltage (Approx.)	
AFS control unit		Ground	
Connector	Terminal		
RH	M16		9
LH			29

E

Is the measurement value within the standard value?

F

YES >> GO TO 2.

G

Less than the standard value >>GO TO 6.

H

Higher than the standard value>>GO TO 9.

I

### 2.CHECK SWIVEL MOTOR

J

Check the swivel motor.[EXL-48, "Component Inspection"](#).

K

Is the inspection result normal?

L

YES >> GO TO 3.

M

NO >> Replace the front combination lamp.

N

### 3.CHECK SWIVEL MOTOR OPEN CIRCUIT

O

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector and the headlamp swivel actuator connector.
3. Check continuity between the AFS control unit harness connector and the headlamp swivel actuator harness connector.

P

# B2503, B2504 SWIVEL ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

AFS control unit		Headlamp swivel actuator		Continuity
Connector	Terminal	Connector	Terminal	
RH	M16	11	E29	8
		13		7
		32		3
		34		4
LH	M16	15	E59	3
		17		4
		36		8
		38		7

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4.CHECK SWIVEL MOTOR SHORT CIRCUIT

Check continuity between the AFS control unit harness connector and the ground.

AFS control unit		Continuity
Connector	Terminal	
RH	M16	11
		13
		32
		34
		15
		17
		36
		38
Ground		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

## 5.CHECK SWIVEL MOTOR CIRCUIT VOLTAGE OUTPUT


1. Connect AFS control unit connector.
2. Turn the ignition switch ON.
3. Turn the headlamp ON.
4. Select "LOW BEAM TEST RIGHT" or LOW BEAM TEST LEFT" of ADAPTIVE LIGHT active test item.
5. With operating the test item, check the voltage between the AFS control unit harness connector and the ground.

# B2503, B2504 SWIVEL ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals		Condition	Voltage (Approx.)		
(+)	(-)				
AFS control unit		Swivel motor	8 - 12 V		
Connector	Terminal				
RH	11				
	32				
	15				
LH	M16				
	36				
RH	M16				
	13				
	34				
LH	M16				
	17				
	38				



Is the measurement value within the standard value?

YES >> Replace the front combination lamp.

NO >> Replace AFS control unit.

## 6.CHECK SWIVEL POSITION SENSOR SIGNAL OUTPUT

Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
AFS control unit		Ground	
Connector	Terminal		
RH	M16		
	4		
	24		
LH	M16		
	24		

Is the measurement value normal?

YES >> GO TO 7.

NO >> GO TO 9.

## 7.CHECK SWIVEL POSITION SENSOR POWER SUPPLY CIRCUIT INPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the headlamp swivel actuator connector.
3. Turn the ignition switch ON.
4. Check the voltage between the headlamp swivel actuator harness connector and the ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
Headlamp swivel actuator		Ground	
Connector	Terminal		
RH	E29		
	2		
	2		
LH	E59		
	2		

Is the measurement value normal?

YES >> GO TO 8.

NO >> Repair the harnesses or connectors.

## 8.CHECK SWIVEL POSITION SENSOR SIGNAL SHORT CIRCUIT

# B2503, B2504 SWIVEL ACTUATOR

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between the AFS control unit harness connector and the headlamp swivel actuator harness connector.

AFS control unit		Headlamp swivel actuator		Continuity
Connector	Terminal	Connector	Terminal	
RH	M16	9	E29	1
LH		29	E59	1

### Does continuity exist?

- YES >> Replace the front combination lamp.  
NO >> Repair the harnesses or connectors.

## 9.CHECK SWIVEL POSITION SENSOR GROUND CIRCUIT VOLTAGE OUTPUT

Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)
(+)		
AFS control unit		Ground
Connector	Terminal	
RH	M16	2
LH		27

### Is the measurement value normal?

- YES >> GO TO 10.  
NO >> Replace AFS control unit.

## 10.CHECK SWIVEL POSITION SENSOR SHORT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector and the headlamp swivel actuator connector.
3. Check continuity between the AFS control unit harness connector and the headlamp swivel actuator harness connector.

AFS control unit		Headlamp swivel actuator		Continuity
Connector	Terminal	Connector	Terminal	
RH	M16	2	E29	6
LH		27	E59	6

### Does continuity exist?

- YES >> Replace the front combination lamp.  
NO >> Repair the harnesses or connectors.

## Component Inspection

INFOID:0000000003846456

### 1.CHECK SWIVEL MOTOR SINGLE PART

1. Disconnect the swivel actuator connector.
2. Check the resistance among each swivel actuator connector terminal.

Swivel actuator		Resistance (Approx.)
Terminal	Terminal	
3	7	7.2 Ω
4	8	7.2 Ω
3	4	10 MΩ or more

## B2503, B2504 SWIVEL ACTUATOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Is the measurement value normal?

YES    >> Swivel actuator is normal.

NO    >> Replace the front combination lamp.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## B2514 HEIGHT SENSOR UNUSUAL [RR]

### Description

INFOID:0000000003846457

The height sensor is installed to the rear suspension arm. The height sensor detects the suspension arm displacement as the vehicle height change. The height sensor transmits the height sensor signal to AFS control unit.

**NOTE:**

The sensor angle of the unloaded vehicle position is the reference value.

### DTC Logic

INFOID:0000000003846458

#### DTC DETECTION LOGIC

##### [B2514] Height sensor unusual [RR]

DTC detection condition	DTC erase condition	Possible cause
An applicable DTC is indicated when any of the following conditions is detected continuously for 2 seconds or more. <ul style="list-style-type: none"><li>• The height sensor power supply is 6 V or more, or 4 V or less.</li><li>• The height sensor signal is 0.25 V or less, or 4.75 V or more.</li></ul>	Ignition switch OFF	Height sensor <ul style="list-style-type: none"><li>• Height sensor</li><li>• Harness and connector</li><li>• AFS control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.DTC ERASE

Erase the DTC memory of AFS with CONSULT-III.

>> GO TO 2.

#### 2.DTC CONFIRMATION

1. Start the engine.
2. Turn the headlamp ON.
3. Select the self-diagnosis with CONSULT-III.
4. Check the self-diagnosis result. Refer to [EXL-187, "DTC Index"](#).

##### Is "B2514" detected?

YES >> Refer to [EXL-50, "Diagnosis Procedure"](#).

NO >> Refer to [GI-35, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:0000000003846459

#### 1.CHECK HEIGHT SENSOR POWER SUPPLY OUTPUT

1. Turn the ignition switch ON.
2. Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
AFS control unit	Connector	Ground	5 V
M16	6		

##### Is the measurement value within the standard value?

YES >> GO TO 2.

NO >> Replace AFS control unit.

#### 2.CHECK HEIGHT SENSOR POWER SUPPLY INPUT

Check the voltage between the AFS control unit harness connector and the ground.

# B2514 HEIGHT SENSOR UNUSUAL [RR]

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals		Voltage (Approx.)
(+)	(-)	
AFS control unit		
Connector	Terminal	Ground
M16	28	0.25 - 4.75 V

Is the measurement value within the standard value?

YES >> Replace AFS control unit.

Less than the standard value >> GO TO 3.

Higher than the standard value>>GO TO 6.

## 3.CHECK HEIGHT SENSOR POWER SUPPLY CIRCUIT OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the height sensor connector.
3. Turn the ignition switch ON.
4. Check the voltage between the height sensor harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Height sensor		
Connector	Terminal	Ground
B32	1	5 V

Is the measurement value within the standard value?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4.CHECK HEIGHT SENSOR SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between the AFS control unit harness connector and the height sensor harness connector.

AFS control unit		Height sensor		Continuity
Connector	Terminal	Connector	Terminal	
M16	28	B32	2	Existed

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 5.CHECK HEIGHT SENSOR SIGNAL SHORT CIRCUIT

Check continuity between the height sensor harness connector and the ground.

Height sensor		Continuity
Connector	Terminal	
B32	2	

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the height sensor.

## 6.CHECK HEIGHT SENSOR GROUND

Check the voltage between the AFS control unit harness connector and the ground.

# B2514 HEIGHT SENSOR UNUSUAL [RR]

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals		Voltage (Approx.)	
(+)	(-)		
AFS control unit			
Connector	Terminal		
M16	8	0 V	

Is the measurement value within the standard value?

YES >> GO TO 7.

NO >> Replace AFS control unit.

## 7.CHECK HEIGHT SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector and the height sensor connector.
3. Check continuity between the AFS control unit harness connector and the height sensor harness connector.

AFS control unit		Height sensor		Continuity
Connector	Terminal	Connector	Terminal	
M16	8	B32	3	Existed

Does continuity exist?

YES >> Replace the height sensor.

NO >> Repair the harnesses or connectors.

## Component Inspection

INFOID:000000003846460

### 1.CHECK HEIGHT SENSOR

1. Remove the height sensor (the height sensor connector is connected).
2. Start the engine.
3. Turn the light switch 2ND.
4. Select "HI SEN OTP RR" of AFS data monitor item.
5. With moving the sensor lever, check the monitor status.

Monitor item	Condition		Monitor status [Standard value (Approx.)]
HI SEN OTP RR	Sensor lever position	Contact with stopper	0.9 V
		Moving between two positions	Smooth movement
		90° from stopper	4.5 V

Is the output value normal?

YES >> Height sensor is normal.

NO >> Replace the height sensor.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**B2516 SHIFT SIGNAL [P, R]****Description**

INFOID:0000000003846461

AFS control unit receives the shift position signal from TCM with CAN communication.

**DTC Logic**

INFOID:0000000003846462

**DTC DETECTION LOGIC**

[B2516] Shift signal [P, R]

DTC detection condition	DTC erase condition	Possible causes
The shift position signal is not received.	Ignition switch OFF	<ul style="list-style-type: none"><li>• TCM</li><li>• AFS control unit</li></ul>

**DTC CONFIRMATION PROCEDURE****1.DTC ERASE**

Erase the DTC memory of AFS with CONSULT-III.

&gt;&gt; GO TO 2.

**2.DTC CONFIRMATION**

1. Turn the ignition ON.
2. Select the self-diagnosis with CONSULT-III.
3. Check the self-diagnosis result. Refer to [EXL-187, "DTC Index"](#).

Is "B2516" detected?

- YES >> Refer to [EXL-53, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-35, "Intermittent Incident"](#).

**Diagnosis Procedure**

INFOID:0000000003846463

**1.TCM SELF-DIAGNOSIS**

Check the self-diagnosis result with CONSULT-III. Check that TCM does not detect any DTCs.

Is any DTC detected?

- YES >> Check TCM. Refer to [TM-151, "Reference Value"](#).  
NO >> GO TO 2.

**2.DTC ERASE**

Erase the DTC memory of AFS with CONSULT-III.

Is the memory erased?

- YES >> Inspection end.  
NO >> Replace AFS control unit.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## B2517 VEHICLE SPEED SIGNAL

### Description

INFOID:0000000003846464

AFS control unit receives the vehicle speed signal from the unified meter and A/C amp. with CAN communication.

### DTC Logic

INFOID:0000000003846465

#### DTC DETECTION LOGIC

[B2517] Vehicle speed signal

DTC detection condition	DTC erase condition	Possible causes
The vehicle speed signal is not received.	Ignition switch OFF	<ul style="list-style-type: none"><li>• Unified meter and A/C amp.</li><li>• AFS control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.DTC ERASE

Erase the DTC memory of AFS with CONSULT-III.

>> GO TO 2.

#### 2.DTC CONFIRMATION

1. Turn the ignition ON.
2. Select the self-diagnosis with CONSULT-III.
3. Check the self-diagnosis result. Refer to [EXL-187, "DTC Index"](#).

##### Is "B2517" detected?

YES >> Refer to [EXL-54, "Diagnosis Procedure"](#).

NO >> Refer to [GI-35, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:0000000003846466

#### 1.UNIFIED METER AND A/C AMP. SELF-DIAGNOSIS

Check the self-diagnosis result with CONSULT-III. Check that the unified meter and A/C amp. does not detect any DTCs.

##### Is any DTC detected?

YES >> Check the unified meter and A/C amp. Refer to [MWI-112, "DTC Index"](#).

NO >> GO TO 2.

#### 2.DTC ERASE

Erase the DTC memory of AFS with CONSULT-III.

##### Is the memory erased?

YES >> Inspection end.

NO >> Replace AFS control unit.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**B2519 LEVELIZER CALIBRATION****Description**

INFOID:0000000003846467

AFS control unit transmits the height sensor signal from the height sensor.

**DTC Logic**

INFOID:0000000003846468

[B2519] Levelizer calibration

DTC detection condition	DTC erase condition	Possible causes
The height sensor adjustment position is not recognized.	When the levelizer adjustment is completed	AFS control unit

**Diagnosis Procedure**

INFOID:0000000003846469

**1. LEVELIZER ADJUSTMENT**

Perform the levelizer adjustment.

>> Refer to [EXL-7, "LEVELIZER ADJUSTMENT : Special Repair Requirement"](#).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**B2521 ECU CIRCUIT****Description**

INFOID:0000000003846470

AFS control unit judges the vehicle condition from each signal. AFS control unit controls AFS function and the headlamp aiming.

**DTC Logic**

INFOID:0000000003846471

**DTC DETECTION LOGIC**

[B2521] ECU circuit

Error detection condition	DTC erase condition	Possible cause
<ul style="list-style-type: none"> <li>• AFS control unit indicates an applicable DTC when detecting any of the following conditions continuously for 2 seconds or more.</li> <li>- The swivel position sensor is shorted to the power supply or the ground.</li> <li>- The swivel position sensor signal is shorted to the ground.</li> <li>- The height sensor power supply is shorted to the power supply or the ground.</li> <li>- The height sensor signal is shorted to the ground.</li> <li>• AFS control unit RAM/ROM error</li> </ul>	Ignition switch OFF	<ul style="list-style-type: none"> <li>Swivel position sensor</li> <li>• Swivel position sensor</li> <li>• Harness and connector</li> <li>• AFS control unit</li> <li>Height sensor</li> <li>• Height sensor</li> <li>• Harness and connector</li> <li>• AFS control unit</li> <li>AFS control unit (RAM/ROM)</li> <li>• AFS control unit</li> </ul>

**DTC CONFIRMATION PROCEDURE****1.DTC ERASE**

Erase the DTC memory of AFS with CONSULT-III.

&gt;&gt; GO TO 2.

**2.DTC CONFIRMATION PROCEDURE**

1. Turn the ignition ON.
2. Select the self-diagnosis with CONSULT-III.
3. Check the self-diagnosis result. Refer to [EXL-187, "DTC Index"](#).

Is "B2521" detected?

YES >> Refer to [EXL-56, "Diagnosis Procedure"](#).

NO >> Refer to [GI-35, "Intermittent Incident"](#).

**Diagnosis Procedure**

INFOID:0000000003846472

**1.CHECK EACH SENSOR POWER SUPPLY**

1. Turn the ignition switch ON.
2. Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
AFS control unit		
Connector	Terminal	
M16	4	
	6	
	24	5 V

Is the measurement value within the standard value?

YES >> GO TO 2.

Less than the standard value >>GO TO 3.

Higher than the standard value>>GO TO 4.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**2.CHECK EACH SENSOR SIGNAL**

Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
AFS control unit	Connector	Ground
9		
28		
29		

Is the measurement value within the standard value?

YES &gt;&gt; Replace AFS control unit.

Less than the standard value &gt;&gt;GO TO 5.

Higher than the standard value&gt;&gt;GO TO 6.

**3.CHECK EACH SENSOR POWER SUPPLY SHORT CIRCUIT**

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between the AFS control unit harness connector and the ground.

AFS control unit		Continuity
Connector	Terminal	
M16	4	Ground
	6	
	24	
		Not existed

Does continuity exist?

YES &gt;&gt; Repair the harnesses or connectors.

NO &gt;&gt; Replace AFS control unit.

**4.CHECK EACH SENSOR POWER SUPPLY CIRCUIT**

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
AFS control unit	Connector	Ground
9		
28		
29		

Is the measurement value normal?

YES &gt;&gt; Replace AFS control unit.

NO &gt;&gt; Repair the harnesses or connectors.

**5.CHECK EACH SENSOR SIGNAL SHORT CIRCUIT**

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between the AFS control unit harness connector and the ground.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

AFS control unit		Ground	Continuity
Connector	Terminal		
M16	9		
	28		
	29		Not existed

Does continuity exist?

- YES >> Repair the harnesses or connectors.  
 NO >> Replace AFS control unit.

## 6.CHECK EACH SENSOR SIGNAL SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Turn the ignition switch ON.
4. Check the voltage between the AFS control unit harness connector and the ground.

Terminals		Ground	Voltage (Approx.)
(+)	(-)		
AFS control unit			0 V

Is the measurement value normal?

- YES >> Replace AFS control unit.  
 NO >> Repair the harnesses or connectors.

## C0126 STEERING ANGLE SENSOR SIGNAL

### Description

INFOID:0000000003846473

AFS control unit receives the steering angle sensor signal from the steering angle sensor with CAN communication.

### DTC Logic

INFOID:0000000003846474

#### DTC DETECTION LOGIC

[C0126] Steering angle sensor signal

DTC detection condition	DTC erase condition	Possible causes
In any of the following conditions <ul style="list-style-type: none"><li>• The steering angle sensor signal is not received.</li><li>• The steering angle sensor signal error is received.</li><li>• Out-of-standard signal (-900°- +900°) is received.</li></ul>	The ignition switch OFF	<ul style="list-style-type: none"><li>• Steering angle sensor</li><li>• AFS control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.DTC ERASE

Erase the DTC memory of AFS with CONSULT-III.

>> GO TO 2.

#### 2.DTC CONFIRMATION

1. Start the engine.
2. Turn the steering wheel to the maximum right/left.
3. Select the self-diagnosis with CONSULT-III.
4. Check the self-diagnosis result. Refer to [EXL-187, "DTC Index"](#).

##### Is "C0126" detected?

- YES >> Refer to [EXL-59, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-35, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:0000000003846475

#### 1.ABS ACTUATOR AND ELECTRICAL UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Check the self-diagnosis result with CONSULT-III. Check that ABS actuator and electrical unit (control unit) does not detect any DTCs.

EXL

##### Is any DTC detected?

- YES >> Check ABS actuator and electrical unit (control unit).Refer to [BRC-121, "DTC Index"](#).  
NO >> GO TO 2.

#### 2.DTC ERASE

Erase DTC memory of AFS with CONSULT-III.

##### Is the memory erased?

- YES >> Inspection end.  
NO >> Replace AFS control unit.

## C0428 STEERING ANGLE SENSOR CALIBRATION

### Description

INFOID:0000000003846476

AFS control unit receives the steering angle sensor signal from the steering angle sensor with CAN communication.

### DTC Logic

INFOID:0000000003846477

[C0428] Steering angle sensor calibration

DTC detection condition	DTC erase condition	Possible causes
The steering angle sensor neutral position is not recognized.	When the steering angle sensor neutral position registration is completed	Steering angle sensor

### Diagnosis Procedure

INFOID:0000000003846478

#### 1. STEERING ANGLE SENSOR NEUTRAL POSITION ADJUSTMENT

Perform the steering angle sensor neutral position adjustment.

**CAUTION:**

Perform the steering angle sensor neutral position adjustment on VDC side. VDC may activate incorrectly.

>> Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement".](#)

< DTC/CIRCUIT DIAGNOSIS >

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000003846479

CAN (Controller Area Network) is the serial transmission for real time application. CAN is the multiplex communication for the vehicle with superior data transmission speed and error detection ability. Many electronic control units are equipped on the vehicle. These control units do not operate individually, but associates with other control units by sharing information. In CAN communication, each control unit is connected with two communication lines (CAN-H and CAN-L). Much information is transmitted with fewer communication lines than before. Each control unit transmits/receives data and reads the necessary data only.

CAN Communication Signal Chart. Refer to [LAN-32, "CAN Communication Signal Chart"](#).

### DTC Logic

INFOID:000000003846480

#### DTC DETECTION LOGIC

[U1000] CAN communication circuit

DTC detection condition	DTC erase condition	Possible causes
When AFS control unit does not transmit/receive CAN communication signal continuously for 2 seconds or more	Ignition switch OFF	CAN communication system

### Diagnosis Procedure

INFOID:000000003846481

#### 1. PERFORM SELF DIAGNOSTIC

1. Turn the ignition switch ON and wait for 2 seconds or more.
2. Select the self-diagnosis with CONSULT-III.
3. Check the self-diagnosis result.

Is "CAN COMM CIRCUIT" displayed?

- YES    >> Refer to [LAN-22, "Trouble Diagnosis Flow Chart"](#).  
NO    >> Refer to [GI-35, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**U1010 CONTROL UNIT (CAN)****DTC Logic**

INFOID:000000003846482

**DTC DETECTION LOGIC**

[U1000] CAN communication circuit

DTC	CONSULT-III display description	DTC detection condition	Possible causes
U1010	CONTROL UNIT (CAN)	AFS control unit detected internal CAN communication circuit malfunction.	AFS control unit

**Diagnosis Procedure**

INFOID:000000003846483

**1. REPLACE AFS CONTROL UNIT**

When DTC [U1010] is detected, replace AFS control unit.

&gt;&gt; Replace AFS control unit.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000004068507

#### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
BCM			
Connector	Terminal		
M118	1	Ground	
M119	11		
		Battery voltage	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M119	13	

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000004068508

#### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Signal name	Fuses and fusible link No.
	D
Battery power supply	50
	51

Is the fuse fusing?

- YES    >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.  
 NO     >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		
Connector	Terminal	Ground
E4	1	Battery voltage

Is the measurement value normal?

- YES    >> GO TO 3.  
 NO     >> Repair harness or connector.

## 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		Existed
E5	12		
E6	41		

Does continuity exist?

- YES    >> INSPECTION END  
 NO     >> Repair harness or connector.

## AFS CONTROL UNIT

### AFS CONTROL UNIT : Diagnosis Procedure

INFOID:000000003846191

#### 1.FUSE INSPECTION

Check that the following fuses are not fusing.

Signal name	Connection position	Fuse No.	Capacity
Ignition power supply	FUSE BLOCK (J/B)	3	10 A

Is the fuse fusing?

- YES    >> Repair the applicable circuit. And then replace the fuse.  
 NO     >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit harness connector.
3. Turn the ignition switch ON.
4. Check voltage between the AFS control unit harness connector and the ground.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals		Voltage (Approx.)	
(+)	(-)		
AFS control unit			
Connector	Terminal		
M16	1	Battery voltage	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

## 3.CHECK GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the AFS control unit harness connectors and the ground.

AFS control unit		Continuity
Connector	Terminal	
M16	25	

Does continuity exist?

YES >> Repair the harness or connector.

NO >> Power supply and ground circuit are normal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# EXTERIOR LAMP FUSE

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## EXTERIOR LAMP FUSE

### Description

INFOID:0000000003846192

Fuse list

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A
Headlamp LO (RH)	IPDM E/R	#57	15 A
Front fog lamp	IPDM E/R	#58	15 A
• Parking lamp • Front side marker lamp	IPDM E/R	#52	10 A
• Tail lamp • Rear side marker lamp • License plate lamp • Each illumination	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

### Diagnosis Procedure

INFOID:0000000003846193

#### 1. CHECK FUSE

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A
Headlamp LO (RH)	IPDM E/R	#57	15 A
Front fog lamp	IPDM E/R	#58	15 A
• Parking lamp • Front side marker lamp	IPDM E/R	#52	10 A
• Tail lamp • Rear side marker lamp • License plate lamp • Each illumination	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

#### Is the fuse fusing?

YES >> Repair the applicable circuit. And then replace the fuse.

NO >> The fuse is normal.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;


## HEADLAMP (HI) CIRCUIT

### Description

INFOID:0000000003846194

The high beam solenoid drives the mobile valve shade. And the mobile valve shade switches the high beam and low beam of headlamp.

- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (2) is switched to the high beam position.
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.



JPLIA1158ZZ

### Component Function Check

INFOID:0000000003846195

#### 1. CHECK HEADLAMP (HI) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

- Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
- Check that the headlamp switches to the high beam.

##### CONSULT-III ACTIVE TEST

- Select "EXTERNAL LAMPS" of IPDM E/R active test item.
- With operating the test items, check that the headlamp switches to the high beam.

EXL

**Hi** : Headlamp switches to the high beam.

**Off** : Headlamp OFF

**NOTE:**

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

**Does the headlamp switch to the high beam?**

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-67, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000003846196

#### 1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

- Turn the ignition switch OFF.
- Disconnect the front combination lamp connector.
- Turn the ignition switch ON.
- Select "EXTERNAL LAMPS" of IPDM E/R active test item.
- With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

P

# HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS Ground	EXTERNAL LAMPS
Connector	Terminal		Hi      Battery voltage
RH	89		Off      0 V
E8			Hi      Battery voltage
LH	90		Off      0 V

Is the measurement value normal?

- YES    >> GO TO 2.  
NO     >> GO TO 3.

## 2.CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	89	E28	1	Existed
LH	90	E58	1	

Does continuity exist?

- YES    >> GO TO 5.  
NO     >> Repair the harnesses or connectors.

## 3.CHECK HEADLAMP (HI) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp HI (LH)	IPDM E/R	#54	10 A

Is the fuse fusing?

- YES    >> GO TO 4.  
NO     >> Replace IPDM E/R.

## 4.CHECK FRONT COMBINATION LAMP (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector terminal and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	89		
E8	90		Not existed
LH			

Does continuity exist?

- YES    >> Repair the harnesses or connectors. And then replace the fuse.  
NO     >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

## HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

### 5.CHECK HEADLAMP (HI) GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28		3
LH	E58	Existed	

Does continuity exist?

YES >> Replace the front combination lamp.

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

## HEADLAMP (LO) CIRCUIT

### Description

INFOID:0000000003846197

Headlamp (LO) circuit is connected to HID control unit integrated in the headlamp. Headlamp (LO) circuit turns xenon headlamp ON.

For the details of HID control unit and the xenon headlamp, refer to [EXL-72, "Description"](#).

### Component Function Check

INFOID:0000000003846198

#### 1.CHECK HEADLAMP (LO) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp is turned ON.

**Low** : Headlamp ON

**Off** : Headlamp OFF

#### Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-70, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000003846199

#### 1.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the headlamp connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)	
(+)	(-)			
IPDM E/R	Connector	EXTERNAL LAMPS		
			Low	
			Battery voltage	
	Terminal		Off	
			0 V	
			Low	
			Battery voltage	
RH	83	Ground	Off	
	E8		0 V	
LH	84		Low	
			Battery voltage	

#### Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2.CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the headlamp harness connector.

# HEADLAMP (LO) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Headlamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E8	83	E25	1	Existed
LH		84	E55	1	

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 3.CHECK HEADLAMP (LO) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Lotion	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#57	15 A
Headlamp LO (LH)	IPDM E/R	#56	15 A

Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

## 4.CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	83	Not existed
LH		84	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

## 5.CHECK HEADLAMP (LO) GROUND OPEN CIRCUIT

Check continuity between the headlamp harness connector and the ground.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

Headlamp		Ground	Continuity
Connector	Terminal		
RH	E25	2	Existed
LH		E55	

Does continuity exist?

YES >> Perform the xenon headlamp diagnosis. Refer to EXL-72, "Description".

NO >> Repair the harnesses or connectors.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**XENON HEADLAMP****Description**

INFOID:0000000003846200

**OUTLINE**


- The lamp light source is by the arch discharge by applying high voltage into the xenon gas-filled bulb instead of the halogen bulb filament.
- Sight becomes more natural and brighter because the amount of light are gained adequately and the color of light is sunshine-like white.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

**ILLUMINATION PRINCIPLE**

- Discharging starts in high voltage pulse between bulb electrodes.
- Xenon gas is activated by current between electrodes. Pale light is emitted.
- The luminous tube (bulb) temperature elevates. Evaporated halide is activated by discharge. The color of light changes into white.

**NOTE:**

- Brightness and the color of light may change slightly immediately after the headlamp turned ON until the xenon bulb becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.



JPL/A0421GB

**PRECAUTIONS FOR TROUBLE DIAGNOSIS**

Representative malfunction examples are, "Light does not turn ON", "Light blinks", and "Brightness is inadequate." The cause often be the xenon bulb. Such malfunctions, however, are occurred occasionally by HID control unit malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

**WARNING:**

- Never touch the harness, HID control unit, the inside and metal part of lamp when turning the headlamp ON or operating the light switch.
- Never work with wet hands.

**CAUTION:**

- Never perform HID control unit circuit diagnosis with a circuit tester or an equivalent.
- Temporarily install the headlamp on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.
- Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.
- Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.

**NOTE:**

- Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

**Diagnosis Procedure**

INFOID:0000000003846201

**1.CHECK XENON BULB**

Install the normal bulb to the applicable headlamp. Check that the xenon bulb is turned ON.

Is the headlamp turned ON?

- YES    >> Replace the xenon bulb.  
NO    >> GO TO 2.

**2.CHECK HID CONTROL UNIT**

Install the normal HID control unit to the applicable headlamp. Check that the lamp is turned ON.

Is the headlamp turned ON?

## XENON HEADLAMP

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace HID control unit.  
NO >> GO TO 3.

A

### 3.CHECK XENON HEADLAMP HOUSING ASSEMBLY

Install the normal xenon headlamp housing assembly to the applicable headlamp. Check that the xenon headlamp is turned ON.

B

Is the headlamp turned ON?

C

- YES >> Replace the front combination lamp. (Xenon headlamp housing voltage converter malfunctions.)  
NO >> Xenon headlamp is normal. Check the headlamp control system.

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# HEADLAMP LEVELIZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP LEVELIZER CIRCUIT

### Description

INFOID:0000000003846202

The headlamp levelizer adjusts the headlamp light axis upward and downward with the aiming motor integrated in the front combination lamp.

### Component Function Check

INFOID:0000000003846203

#### 1. CHECK AIMING MOTOR OPERATION

##### ( CONSULT-III ACTIVE TEST

1. Start the engine.
2. Turn the lighting switch 2ND.
3. Select "LEVELIZER TEST" of ADAPTIVE LIGHT active test item.
4. With operating the test item, check the operation.

Test item	Light axis angle (Reference value)	10 m (32.8 ft)-forward light axis change refer- ence quantity (Approx.)
LEVELIZER TEST		
Origin	0°	—
Peak	2.5°	450 mm (17.9 in)

Is the operation normal?

YES >> Headlamp levelizer circuit is normal.

NO >> Refer to [EXL-74, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000003846204

#### 1. CHECK AIMING MOTOR DRIVE SIGNAL OUTPUT

##### ( CONSULT-III ACTIVE TEST

1. Start the engine.
2. Turn the light switch 2ND.
3. Select "LEVELIZER TEST" of ADAPTIVE LIGHT active test item.
4. With operating the test item, check the voltage between the AFS control unit harness connector and the ground.

Terminals		Test item	Voltage (Approx.)	
(+)	(-)			
AFS control unit		LEVELIZER TEST		
Connector	Terminal			
RH	19		Origin 8.8 V	
M16	40		Peak 1.9 V	
			Origin 8.8 V	
			Peak 1.9 V	

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK AIMING MOTOR DRIVE SIGNAL CIRCUIT INPUT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector and aiming motor connector.
3. Check continuity between the AFS control unit harness connector and the aiming motor harness connector.

# HEADLAMP LEVELIZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

AFS control unit		Aiming motor		Continuity
Connector	Terminal	Connector	Terminal	
RH	M16	19	E26	2
LH		40	E56	2

Does continuity exist?

- YES >> Replace the front combination lamp.  
NO >> Repair the harnesses and connectors.

## 3.CHECK AIMING MOTOR DRIVE SIGNAL SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AFS control unit connector and aiming motor connector.
3. Check continuity between the AFS control unit harness connector and the ground.

AFS control unit		Ground	Continuity
Connector	Terminal		
RH	M16	19	Not existed
LH		40	

Does continuity exist?

- YES >> Repair the harness and connectors.  
NO >> Replace AFS control unit.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:0000000003846487

#### 1. CHECK FRONT FOG LAMP OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, Check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Is the front fog lamp turned ON?

YES >> Front fog lamp circuit is normal.

NO >> Refer to [EXL-76, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000003846488

#### 1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#58	15 A

Is the fuse fusing?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front fog lamp connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	86	
LH		87	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

#### 3. CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 4.

NO >> Replace the bulb.

#### 4. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Disconnect the front fog lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

## FRONT FOG LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		External Lamps  Ground	External Lamps
Connector	Terminal		External Lamps
RH	86		Fog      Battery voltage
LH	E8		Off      0 V
	87		Fog      Battery voltage
			Off      0 V

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

### 5.CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front fog lamp harness connector.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	86	E34	1	Existed
LH	E8	E64	1	
LH	87			

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

### 6.CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between the front fog lamp harness connector and the ground.

Front fog lamp			Ground	Continuity
Connector	Terminal			
RH	E34	2		Existed
LH	E64	2		

Does continuity exist?

YES >> Replace the front fog lamp.

NO >> Repair the harnesses or connectors.

# PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## PARKING LAMP CIRCUIT

### Component Function Check

INFOID:0000000003846207

#### 1. CHECK PARKING LAMP OPERATION

IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).

2. Check that the parking lamp is turned ON.

CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON

Off : Parking lamp OFF

Is the parking lamp turned ON?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-78, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000003846208

#### 1. CHECK PARKING LAMP FUSE

1. Turn the ignition switch OFF.

2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#52	10 A

Is the fuse fusing?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front combination lamp connector.

2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E9	91	Not existed
		92	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if fusing is found again.)

#### 3. CHECK PARKING LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 4.

NO >> Replace the bulb.

#### 4. CHECK PARKING LAMP OUTPUT VOLTAGE

CONSULT-III ACTIVE TEST

1. Disconnect the front combination lamp connector.

2. Turn the ignition switch ON.

3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

# PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	Battery voltage
Connector	Terminal		
RH	91		0 V
LH	E9		0 V
	92	TAIL	Battery voltage
			0 V

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

## 5.CHECK PARKING LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E9	91	E28	4
LH		92	E58	4

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

## 6.CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp			Ground	Continuity
Connector	Terminal			
RH	E28	3		Existed
LH	E58	3		

Does continuity exist?

YES >> Replace the front combination lamp.

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

---

TURN SIGNAL LAMP CIRCUIT

## Description

INFOID:0000000003846209

BCM performs the high flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

**NOTE:**

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

## Component Function Check

INFOID:0000000003846210

---

**1.CHECK TURN SIGNAL LAMP**

## CONSULT-III ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

**LH : Turn signal lamp LH blinking**

**RH : Turn signal lamp RH blinking**

**Off : The turn signal lamp OFF**

Does the turn signal lamp blink?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-80, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:0000000003846211

---

**1.CHECK TURN SIGNAL LAMP BULB**

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

---

**2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE**





## CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector or the rear combination lamp connector.
3. Turn the ignition switch ON.
4. Select "FLASHER" of BCM (FLASHER) active test item.
5. With operating the turn signal switch, check the voltage between the BCM harness connector and the ground.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Front				Test item	Voltage (Approx.)	A B C D E F G H	
Terminals		(+)	(-)				
BCM		Connector	Terminal	FLASHER		A B C D E F G H	
RH	M119		17		RH	 PKID0926E	
LH		Ground	18	FLASHER	Off	0 V	I J K EXL M N O P
RH	M119		17		LH	 PKID0926E	
LH		Ground	18	FLASHER	Off	0 V	
Rear							
Terminals				Test item	Voltage (Approx.)	I J K EXL M N O P	
(+)		(-)					
BCM		Connector	Terminal	FLASHER		I J K EXL M N O P	
RH	M120		20		RH	 PKID0926E	
LH		Ground	25	FLASHER	Off	0 V	
RH	M120		20		LH	 PKID0926E	
LH		Ground	25	FLASHER	Off	0 V	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace BCM.

### 3.CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check the continuity between the BCM harness connector and the front combination lamp or the rear combination lamp harness connector.

# TURN SIGNAL LAMP CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Front turn signal lamp

BCM		Front combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	M119	17	E28	2	Existed
LH		18	E58	2	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	M120	20	B232	3	Existed
LH		25	B60	3	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector and the ground.

Front

BCM		Ground	Continuity
Connector	Terminal		
RH	M119	17	
LH		18	Not existed

Rear

BCM		Ground	Continuity
Connector	Terminal		
RH	M120	20	
LH		25	Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

## 5.CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check the continuity between the BCM harness connector and the front combination lamp or the rear combination lamp and the ground.

Front turn signal lamp

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28	3	
LH	E58	3	Existed

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B232	4	
LH	B60	4	Existed

Does continuity exist?

YES >> Replace the front combination lamp or the rear combination lamp.

NO >> Repair the harnesses or connectors.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

A

**OPTICAL SENSOR**

B

**Description**

INFOID:0000000003846212

C

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.

D

**Component Function Check**

INFOID:0000000003846213

E

**1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT-III**

F

**(B)CONSULT-III DATA MONITOR**

G

1. Turn the ignition switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEADLAMP) data monitor item.
3. Turn the lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

H

Monitor item	Condition		Voltage (Approx.)
OPTICAL SENSOR	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

I

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

J

**Is the item status normal?**

K

- YES    >> Optical sensor is normal.  
 NO    >> Refer to [EXL-83, "Diagnosis Procedure"](#).

L

**Diagnosis Procedure**

INFOID:0000000003846214

M

**1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT**

N

1. Turn the ignition switch ON.
2. Turn the lighting switch AUTO.
3. Check the voltage between the optical sensor harness connector and the ground.

O

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		
Connector	Terminal	Ground
M94	1	5 V

P

**Is the measurement value normal?**

Q

R

S

- YES    >> GO TO 2.  
 NO    >> GO TO 4.

**2.CHECK OPTICAL SENSOR GROUND INPUT**

T

Check the voltage between the optical sensor harness connector and the ground.

U

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		
Connector	Terminal	Ground
M94	3	0 V

V

**Is the measurement value normal?**

W

- YES    >> GO TO 3.  
 NO    >> GO TO 6.

**3.CHECK OPTICAL SENSOR SIGNAL OUTPUT**

X

# OPTICAL SENSOR

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

With illuminating the optical sensor, check the voltage between the optical sensor harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Optical sensor		Optical sensor	Ground
Connector	Terminal		
M94	2		When illuminating
			3.1 V or more *
			When shutting off light
			0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

### Is the measurement value normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

## 4.CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and the BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	1	M123	138	Existed

### Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 5.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M94	1		Not existed

### Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

## 6.CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	3	M123	137	Existed

### Does continuity exist?

YES >> Replace BCM.

NO >> Repair the harnesses or connectors.

## 7.CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and the BCM connector.

# OPTICAL SENSOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	2	M123	113	Existed

Does continuity exist?

YES >> GO TO 8.

NO >> Repair the harnesses or connectors.

## 8.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M94	2		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**HAZARD SWITCH****Description**

INFOID:0000000003846215

Hazard switch is integrated in the multifunction switch. Hazard switch inputs the signals to BCM when pressing the switch.

**Component Function Check**

INFOID:0000000003846216

**1.CHECK HAZARD SWITCH SIGNAL BY CONSULT-III****CONSULT-III DATA MONITOR**

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	While pressing the switch	On
		While not pressing the switch	Off

Is the item status normal?


- YES    >> Hazard switch circuit is normal.  
 NO    >> Refer to [EXL-86, "Diagnosis Procedure"](#).

**Diagnosis Procedure**

INFOID:0000000003846217

**1.CHECK HAZARD SWITCH SIGNAL INPUT**

With operating the hazard switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM	Connector	Hazard switch	
			0 V
		While pressing the switch	
Ground	Terminal	While not pressing the switch	(V) 15 10 5 0
			0 V
			

JPMIA0012GB

Is the measurement value normal?

- YES    >> Replace BCM.  
 NO    >> GO TO 2.

**2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT**

1. Turn the ignition switch OFF.
2. Disconnect the multifunction switch connector and the BCM connector.
3. Check continuity between the multifunction switch harness connector and the BCM harness connector.

Multifunction switch	BCM		Continuity	
Connector	Terminal	Connector	Terminal	
M72	16	M122	110	Existed

Does continuity exist?

## HAZARD SWITCH

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between the multifunction switch harness connector and the ground.

Multifunction switch		Ground	Continuity
Connector	Terminal		Not existed
M72	16		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 4.

### 4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between the multifunction switch harness connector and the ground.

Multifunction switch		Ground	Continuity
Connector	Terminal		Existed
M72	1		

Does continuity exist?

YES >> Replace the hazard switch (multifunction switch).

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**TAIL LAMP CIRCUIT****Component Function Check**

INFOID:0000000003846218

**1.CHECK TAIL LAMP OPERATION** **IPDM E/R AUTO ACTIVE TEST**

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

 **CONSULT-III ACTIVE TEST**

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL : Tail lamp ON****Off : Tail lamp OFF****Is the tail lamp turned ON?**

YES &gt;&gt; Tail lamp circuit is normal.

NO >> Refer to [EXL-88, "Diagnosis Procedure"](#).**Diagnosis Procedure**

INFOID:0000000003846219

**1.CHECK TAIL LAMP FUSE**

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"> <li>• Tail lamp</li> <li>• Rear side marker lamp</li> <li>• License plate lamp</li> </ul>	IPDM E/R	#53	10 A

**Is the fuse fusing?**

YES &gt;&gt; Repair the malfunctioning part before replacing the fuse.

NO &gt;&gt; GO TO 2.

**2.CHECK TAIL LAMP OUTPUT VOLTAGE** **CONSULT-III ACTIVE TEST**

1. Disconnect the rear combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	
Connector	Terminal	Ground	Battery voltage
E5	7	TAIL	0 V

**Is the measurement value normal?**

YES &gt;&gt; GO TO 3.

NO &gt;&gt; Replace IPDM E/R.

**3.CHECK TAIL LAMP OPEN CIRCUIT**

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.

## TAIL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E5	7	B232	1	Existed
LH			B60	1	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

### 4. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B232	4	Existed
LH	B60	4	

Does continuity exist?

YES >> Replace the rear combination lamp.

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## LICENSE PLATE LAMP CIRCUIT

### Component Function Check

INFOID:000000003846220

#### NOTE:

Check the tail lamp circuit if the tail lamp and the license plate lamp are not turned ON.

### 1.CHECK LICENSE PLATE LAMP OPERATION

#### ☒IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

#### ⒷCONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

TAIL : License plate lamp ON

Off : License plate lamp OFF

#### Is the license plate lamp turned ON?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-90, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003846221

### 1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

#### Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

### 2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector and the license plate lamp connector.
3. Check continuity between the IPDM E/R harness connector and the license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E5	7	D117	1
LH			D112	1

#### Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

### 3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp			Ground	Continuity
Connector	Terminal			
RH	D117	2		Existed
LH	D112	2		

#### Does continuity exist?

YES >> Replace the license plate lamp.

NO >> Repair the harnesses or connectors.

# HEADLAMP SYSTEM


[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP SYSTEM

### Wiring Diagram - HEADLAMP -

INFOID:0000000003846222



JCLWM1773GB

# HEADLAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

HEADLAMP		Connector No. E1		Connector No. E5		Connector No. E6		Connector No. E8	
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
Wire To Wire		TH80FW-CS16-TM4	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH20FW-CS12-M4-IV	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH80BW-CS	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	NS80BW-CS	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type									
Terminal No.		Signal Name [Specification]		Terminal No.		Signal Name [Specification]		Terminal No.	
80	L	12	B	39	P	37	38	83	R
81	P	-	-	40	L	-	-	84	P
82	L	-	-	41	B	-	-	89	BR
83	P	-	-	-	-	-	-	90	Y

Connector No. E25		Connector No. E28		Connector No. E55		Connector No. E56	
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
HEADLAMP RH		FRONT COMBINATION LAMP RH		HEADLAMP LH		FRONT COMBINATION LAMP LH	
Connector Type	E02FGY-RS	RS04FB-FR	Connector Type	E02FGY-RS	RS04FB-FR	Connector Type	E02FGY-RS
Terminal No.		Signal Name [Specification]		Terminal No.		Signal Name [Specification]	
1	R	2	B	1	P	-	-
2	B	-	-	2	B	-	-

Connector No. E27		Connector No. E29		Connector No. E57	
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
HEADLAMP RH		FRONT COMBINATION LAMP RH		HEADLAMP LH	
Connector Type	E02FGY-RS	RS04FB-FR	Connector Type	E02FGY-RS	RS04FB-FR
Terminal No.		Signal Name [Specification]		Terminal No.	
1	R	2	B	1	P
2	B	-	-	2	B

JCLWM1774GB

# HEADLAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

HEADLAMP					
Connector No.	M1	Connector No.	M2	Connector No.	M6
Connector Name	WIRE TO WIRE	Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE
Connector Type	THB0FW-CS16-TM4	Connector Type	NS10FW-CS	Connector Type	THB0MW-CS16-TM4
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	L	-	6B	Y	-
48	P	-			
49	W	-			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	-	47	L	-
7A	R	-	48	P	-
			96	W	-
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
9	10	11	12	13	14
10	11	12	13	14	15
11	12	13	14	15	16
12	3	4	5	6	7
13	4	5	6	7	8
14	5	6	7	8	
15	6	7	8	9	
16	7	8	9	10	
			17	11	
			18	12	
			19	13	
			20	14	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-	2	SB	OUTPUT 4
80	L	-	5	L	OUTPUT 3
81	P	-	7	V	INPUT 3
82	L	-	8	O	OUTPUT 5
83	P	-	9	Y	INPUT 2
			10	R	INPUT 4
			11	LG	INPUT 1
			12	P	OUTPUT 1
			13	BR	INPUT 5
			14	G	OUTPUT 2

JCLWM1775GB

EXL

M

Z

O

P

A

B

D

T

G

I

# HEADLAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

HEADLAMP		Connector No.	M66	Connector No.	M119
Connector Name	UNIFIED METER AND A/C AMP	Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4DFW-NH	Connector Type	TH32FW-NH	Connector Type	NS16FW-CS
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMM (AMP->METER)	53	G	IGN
27	LG	COMM (METER->AMP)	54	Y	BAT
			55	B	GND
			56	L	CAN-H
			71	B	GND
			72	P	CAN-L
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
87	BR	COMBI SW INPUT 5	142	O	COMBI SW OUTPUT 5
88	V	COMBI SW INPUT 3	143	P	COMBI SW OUTPUT 1
90	P	CAN-1	144	G	COMBI SW OUTPUT 2
91	L	CAN-H	145	L	COMBI SW OUTPUT 3
107	LG	COMBI SW INPUT 1	146	S	COMBI SW OUTPUT 4
108	R	COMBI SW INPUT 4			
109	Y	COMBI SW INPUT 2			

JCLWM1776GB

# AUTO LIGHT SYSTEM


[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## AUTO LIGHT SYSTEM

### Wiring Diagram - AUTO LIGHT SYSTEM -

INFOID:0000000003846223



JCLWM1782GB

2008/03/04

# AUTO LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

AUTO LIGHT SYSTEM		B1		B16		FRONT DOOR SWITCH (DRIVER SIDE)		B23		REAR DOOR SWITCH LH		B201		
Connector No.	Connector Name	Connector No.	Connector Name	Connector Type	Connector Type	Connector Type	Connector Name	Connector No.	Connector Name	Connector Type	Connector Type	Connector No.	Connector Name	
Connector No. B1	Connector Name WIRE TO WIRE	Connector No. B16	Connector Name FRONT DOOR SWITCH (DRIVER SIDE)	Connector Type A03FW	Connector Type A03FW	Connector Type A03FW	Connector Name REAR DOOR SWITCH LH	Connector No. B23	Connector Name WIRE TO WIRE	Connector Type TH0FW-CS16-TM4	Connector Type TH0FW-CS16-TM4	Connector No. B201	Connector Name WIRE TO WIRE	
Connector Name TH0FW-CS16-TM4	Connector Type A03FW	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	Diagram	
[Terminal Color of Wire No. Signal Name [Specification]]														
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
78	GR	-	2	GR	-	2	W	-	60	GR	-	39	P	-
79	W	-	79	W	-	65	O	-	42	R	-	40	L	-
80	L	-	80	L	-	43	GR	-	43	GR	-	41	B	-
81	P	-	81	P	-	44	GR	-	44	GR	-	45	GR	-
82	L	-	82	L	-	45	GR	-	45	GR	-	46	GR	-
83	P	-	83	P	-	46	GR	-	46	GR	-	47	GR	-

B216		B223		E5		E6		
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	
Connector No. B216	Connector Name FRONT DOOR SWITCH (PASSENGER SIDE)	Connector No. B223	Connector Name REAR DOOR SWITCH RH	Connector No. E5	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector No. E6	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	
Connector Type A03FW	Connector Type A03FW	Connector Type A03FW	Connector Type A03FW	Connector Type TH0FW-CS12-M4-IV	Connector Type TH0FW-CS12-M4-IV	Connector Type TH0FW-NH	Connector Type TH0FW-NH	
[Terminal Color of Wire No. Signal Name [Specification]]								
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-	2	O	-	39	P	-
7	GR	-	7	R	-	40	L	-
12	O	-	12	B	-	41	B	-

JCLWM1783GB

# AUTO LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

AUTO LIGHT SYSTEM		EB		FUSE BLOCK (J/B)		M1		OPTICAL SENSOR		COMBINATION SWITCH		M33		M94						
Connector No.	IPDM-E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector No.	WIRE TO WIRE	Connector No.	FUSE BLOCK (J/B)	Connector No.	WIRE TO WIRE	Connector No.	WIRE TO WIRE	Connector No.	WIRE TO WIRE	Connector No.	WIRE TO WIRE	Connector No.	WIRE TO WIRE					
Connector Type	NSDIFW-CS	Connector Type	TH80FW-CS16-TM4	Connector Type	NSDIFW-M2	Connector Type	TH80MW-CS16-TM4	Connector Type	TH80MW-CS16-TM4	Connector Type	TH80FW-NH	Connector Type	TH80FW	Connector Type	TH80FW					
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]			
83	R	-	47	L	-	7A	R	-	47	L	-	1	2	3	1	2	3			
84	P	-	48	P	-				48	P	-	4	5	6	4	5	6			
89	BR	-	96	W	-				96	W	-	7	8	9	10	11	12	13	14	
90	Y	-																		
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]			
84	83	-	9	10	11	12	13	14	15	16	-	1	2	3	4	5	6			
90	89	88	87	86	-	12	3	4	5	6	7	8	9	10	11	12	13	14		
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]			
78	GR	-	6	L	-	14	P	-	2	SB	OUTPUT 4	1	Y	POWER	1	Y	POWER	1	Y	POWER
79	R	-	79	R	-				5	L	OUTPUT 3	2	P	OUTPUT	2	P	OUTPUT	2	P	OUTPUT
80	L	-	80	L	-				7	V	INPUT 3	3	B	GND	3	B	GND	3	B	GND
81	P	-							8	O	OUTPUT 5									
82	L	-							9	Y	INPUT 2									
83	P	-							10	R	INPUT 4									

JCLWM1784GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
EXL

# AUTO LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

AUTO LIGHT SYSTEM		Connector No.	Connector No.	Connector No.	Connector No.	Connector No.		
Connector No.	M117	Connector No.	M118	Connector No.	M119	Connector No.	M121	
Connector Name	WIRE TO WIRE	Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	TH80BMW-CS 6-TM4	Connector Type	MD3FB-LC	Connector Type	NS16FW-CS	Connector Type	TH40FG-NH	
								
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
80	LG	-	1	W	BAT (F/L)	11	R	BAT (FUSE)
65	BR	-				13	B	GND
								
Terminal No.		Signal Name [Specification]		Terminal No.		Signal Name [Specification]		
1		BAT (F/L)		11		R		
13		B		68		BR		
69		R		69		R		

JCLWM1785GB

# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

### Description


INFOID:0000000003885172

The headlamp levelizer adjusts the headlamp light axis upward and downward with the aiming motor integrated in the front combination lamp.

### Wiring Diagram - HEADLAMP AIMING CONTROL SYSTEM (MANUAL) -

INFOID:0000000003885173

### HEADLAMP AIMING CONTROL (MANUAL)




2008/03/04

JCLWM1793GB

# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]



JCLWM1794GB

INFOID:0000000003885174

## Component Inspection

### 1. CHECK HEADLAMP AIMING SWITCH

1. Remove the headlamp aiming switch.

# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

< DTC/CIRCUIT DIAGNOSIS >


[XENON TYPE]

2. Check the resistance among each headlamp aiming switch terminal.

Headlamp aiming switch	Condition	Resistance (Approx.)
Terminal	Switch position	
1	2	0 A: 910 Ω
		1 B: 680 Ω
		2 C: 510 Ω
		3 D: 390 Ω
	3	E: 390 Ω

Is the measurement value normal?

- YES >> Headlamp aiming switch is normal.  
NO >> Replace the headlamp aiming switch.



A  
B  
C  
D  
E

F  
G  
H  
I  
J

EXL

M  
N  
O  
P

# DAYTIME RUNNING LIGHT SYSTEM


**< DTC/CIRCUIT DIAGNOSIS >**

**[XENON TYPE]**

## DAYTIME RUNNING LIGHT SYSTEM

### Wiring Diagram - DAYTIME LIGHT SYSTEM -

INFOID:0000000003846224



2008/03/04

JCLWM1777GB

# DAYTIME RUNNING LIGHT SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

**[XENON TYPE]**


## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	Bl
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4
	

Terminal No.	Color of Wire	Signal Name [Specification]
30	L	-
31	P	-
32	L	-
33	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
12	B	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-IV



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	- [Without NAVI]
1	L	- [With NAVI]
2	B/W	- [Without NAVI]
2	GR	- [With NAVI]

Terminal No.	Color of Wire	Signal Name [Specification]
37	GR	-
38	W	-
39	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
40	L	-
41	B	-


Connector No.	E6
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	THBDFW-CS16-TM4



Connector No.	E34
Connector Name	FRONT FOG LAMP RH
Connector Type	FHZ2FB



Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
29	LG	-
47	L	-
48	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
29	LG	-
47	L	-

Terminal No.	Color of Wire	Signal Name [Specification]
29	LG	-
47	L	-

Terminal No.	Color of Wire	Signal Name [Specification]
29	LG	-
47	L	-

Terminal No.	Color of Wire	Signal Name [Specification]
29	LG	-
47	L	-

JCLWM1778GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
EXL

# DAYTIME RUNNING LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	E107
Connector Name	PARKING BRAKE SWITCH
Connector Type	TBOFW



Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Type	RS20MB+PR



Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
5	GR	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
5	G	-

Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	-
7A	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	2A	-
5	6A	-

Terminal No.	Color of Wire	Signal Name [Specification]
2A	Y	-
7A	Y	-


# DAYTIME RUNNING LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH














Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMM (AMP->METER)
27	LG	COMM (METER->AMP)
3	GR	PARKING BRAKE SW
27	V	

Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMM (AMP->METER)
27	LG	COMM (METER->AMP)



EXL

M

Z

O


P

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

# DAYTIME RUNNING LIGHT SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]



JCLWM1781GB

# FRONT FOG LAMP SYSTEM


[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## FRONT FOG LAMP SYSTEM

### Wiring Diagram - FRONT FOG LAMP -

INFOID:0000000003846225



JCLWM1795GB

2008/03/04

# FRONT FOG LAMP SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

**[XENON TYPE]**

## FRONT FOG LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4
	

Connector No.	E5
Connector Name	IOPM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-IV

Connector No.	E6
Connector Name	IOPM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	THBDFW-NH

Connector No.	E8
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NSBDFW-CS

Terminal No.	Color of Wire	Signal Name [Specification]
80	L	-
81	P	-
82	L	-
83	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
12	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
37	GR	37/38
38	GR	37/38
39	GR	37/38
40	P	-
41	L	-
42	GR	-
43	GR	-
44	GR	-
45	GR	-

Terminal No.	Color of Wire	Signal Name [Specification]
84	GR	-
85	GR	-

Connector No.	E34
Connector Name	FRONT FOG LAMP RH
Connector Type	FHZ20FB

Connector No.	E66
Connector Name	WIRE TO WIRE
Connector Type	RS388FB_PR

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	- [Without NAVI]
1	L	- [With NAVI]
2	B/W	- [Without NAVI]
2	GR	- [With NAVI]

Terminal No.	Color of Wire	Signal Name [Specification]
47	L	-
48	P	-
96	W	-

JCLWM1796GB

# FRONT FOG LAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## FRONT FOG LAMP

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BDGFW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
5	GR	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
7A	R	-	47	L	-
			48	P	-
96	W	-	83	P	-


Connector No.	M1
Connector Name	FUSE BLOCK (J/U/B)
Connector Type	NS306FW-N2



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	RS30MB-PR



Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	THD0MW-CS16-TM4



Connector No.	M23
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Connector No.	M118
Connector Name	BCM(BODY CONTROL MODULE)
Connector Type	ND5FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	V	OUTPUT 2

Terminal No.	Color of Wire	Signal Name [Specification]
11	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1

Terminal No.	Color of Wire	Signal Name [Specification]
13	BR	INPUT 5
14	G	OUTPUT 2

Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (F-L)
13	B	GND

JCLWM1797GB

# FRONT FOG LAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

FRONT FOG LAMP			
Connector No.	M122		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	TH40FB-NH		
			
Connector No.	M123		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	TH40FG-NH		
			
Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
87	BR	COMBI SW INPUT 5	COMBI SW OUTPUT 5
88	V	COMBI SW INPUT 3	O
90	P	CAN-L	P
91	L	CAN-H	G
107	LG	COMBI SW INPUT 1	COMBI SW OUTPUT 3
108	R	COMBI SW INPUT 4	L
109	Y	COMBI SW INPUT 2	SB
			COMBI SW OUTPUT 4

JCLWM1798GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### Wiring Diagram - TURN AND HAZARD WARNING LAMPS -

INFOID:0000000003846226

#### TURN SIGNAL AND HAZARD WARNING LAMPS



2008/03/04

JCLWM1799GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

**[XENON TYPE]**


TURN SIGNAL AND HAZARD WARNING LAMPS																			
<b>B1</b> Connector No. E60 Connector Name WIRE TO WIRE Connector Type TH80FW-CS16-TM4	Connector No. B201 Connector Name WIRE TO WIRE Connector Type TH80FW-CS16-TM4																		
																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>3</td> <td>G</td> <td>-</td> </tr> <tr> <td>4</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	3	G	-	4	B	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>3</td> <td>V</td> <td>-</td> </tr> <tr> <td>4</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	3	V	-	4	B	-
Terminal No.	Color of Wire	Signal Name [Specification]																	
3	G	-																	
4	B	-																	
Terminal No.	Color of Wire	Signal Name [Specification]																	
3	V	-																	
4	B	-																	
																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>V</td> <td>-</td> </tr> <tr> <td>3</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	V	-	3	B	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>G</td> <td>-</td> </tr> <tr> <td>3</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	G	-	3	B	-
Terminal No.	Color of Wire	Signal Name [Specification]																	
2	V	-																	
3	B	-																	
Terminal No.	Color of Wire	Signal Name [Specification]																	
2	G	-																	
3	B	-																	
																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>V</td> <td>-</td> </tr> <tr> <td>3</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	V	-	3	B	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>3</td> <td>V</td> <td>-</td> </tr> <tr> <td>4</td> <td>B</td> <td>-</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	3	V	-	4	B	-
Terminal No.	Color of Wire	Signal Name [Specification]																	
2	V	-																	
3	B	-																	
Terminal No.	Color of Wire	Signal Name [Specification]																	
3	V	-																	
4	B	-																	

JCLWM1800GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]




JCLWM1801GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]


TURN SIGNAL AND HAZARD WARNING LAMPS			
Connector No.	M72	Connector No.	M118
Connector Name	MULTIFUNCTION SWITCH	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH16FW-NH	Connector Type	MODFB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
16	G	HAZARD ON


Terminal No.	Color of Wire	Signal Name [Specification]
76	V	-

Terminal No.	Color of Wire	Signal Name [Specification]
4	5	WIRE TO WIRE
6	7	-
8	9	-
10	11	-
12	13	-
14	15	-
16	17	-
18	19	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F.C.)

Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (FUSE)
13	E	GND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)



Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH	Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
25	G	TURN SIGNAL LH (REAR)

Terminal No.	Color of Wire	Signal Name [Specification]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
90	P	CAN-L
91	L	CAN-H
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]
11	R	COMBI SW OUTPUT 5
13	P	COMBI SW OUTPUT 1
14	G	COMBI SW OUTPUT 2
15	L	COMBI SW OUTPUT 3
16	S8	COMBI SW OUTPUT 4

JCLWM1802GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### Wiring Diagram - PARKING LICENSE PLATE AND TAIL LAMPS -

INFOID:0000000003846227











JCLWM1810GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS		
Connector No.	B1	
Connector Name	WIRE TO WIRE	
Connector Type	TH80FW-CS16-TM4	
		
Terminal No.	Color of Wire	Signal Name [Specification]
80	L	-
81	P	-
82	L	-
83	P	-
		
		
		
		
		
		
		
		
		
		
		
		
		
		

JCLWM1811GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	D101	Connector No.	D102
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC	Connector Type	TH24FW-NH

Connector No.	D112	Connector Name	LICENSE PLATE LAMP LH
Connector Name		Connector Name	
Connector Type	TK02FBR	Connector Type	TK02FBR




Terminal No.	Color of Wire	Signal Name [Specification]
6	GR	-
19	P	-

Connector No.	D101	Connector Name	LICENSE PLATE LAMP RH
Connector Name		Connector Name	
Connector Type	TK02FBR	Connector Type	TK02FBR




Connector No.	E9	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		Connector Name	
Connector Type	TH05FW-NH	Connector Type	TH05FW-NH



Connector No.	E28	Connector Name	FRONT COMBINATION LAMP RH
Connector Name		Connector Name	
Connector Type	RS04FB-PR	Connector Type	RS04FB-PR




Connector No.	E6	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		Connector Name	
Connector Type	TH05FW-CS12-M4-TV	Connector Type	TH05FW-NH



Connector No.	E9	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		Connector Name	
Connector Type	TH05FW-NH	Connector Type	TH05FW-NH



Connector No.	E1	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		Connector Name	
Connector Type	TH05FW-NH	Connector Type	TH05FW-NH



Connector No.	E1	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		Connector Name	
Connector Type	TH05FW-NH	Connector Type	TH05FW-NH



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
EXL

JCLWM1812GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]


PARKING, LICENSE PLATE AND TAIL LAMPS		Connector No. M1		Connector No. E106		Connector No. M33		Connector No. M24		Connector No. M6		Connector No. M7		Connector No. M24		Connector No. M33			
Connector No.	E58	Connector Name	FRONT COMBINATION LAMP LH	Connector No.	THB0FW-CS16-TM4	Connector Name	WIRE TO WIRE	Connector No.	THB0FW-CS16-TM4	Connector Name	WIRE TO WIRE	Connector No.	THB0FW-CS16-TM4	Connector Name	DATA LINK CONNECTOR	Connector No.	THB0FW-CS16-TM4	Connector Name	DATA LINK CONNECTOR
Connector Name		Connector Type	RS0DFB-PR	Connector Type		Connector Type	NS16FW-CS	Connector Type		Connector Type	NS16FW-M2	Connector Type		Connector Type	SD16FW	Connector Type		Connector Type	SD16FW
Connector Type																			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
3	B	-	9F	R	-	47	L	-	6	L	-	9	R	-	2	SB	OUTPUT 4		
4	O	-	10F	GF	3F 2F 1F 10F 15F 14F 13F 12F 11F 10F 9F 8F	48	P	-	7A	R	-	11	Y	INPUT 3	5	L	OUTPUT 3		
						82	L	-				10	R	INPUT 2	7	V	INPUT 2		
						83	P	-				12	P	INPUT 1	8	O	OUTPUT 5		
												13	BR	OUTPUT 1	9	G	OUTPUT 2		
												14	G	OUTPUT 2					

JCLWM1813GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]



JCLWM1814GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
EXL

# STOP LAMP


< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## STOP LAMP

### Wiring Diagram - STOP LAMP -


INFOID:0000000003846228



# STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]



JCLWM1804GB

A      B      C      D      M      T      G      EXL

EXL      M      Z      O      P

# STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

STOP LAMP		Connector No. D102		Connector No. D106		Connector No. E91		Connector No. M6		Connector No. M2		Connector No. E110		Connector No. E106			
Color	WIRE TO WIRE	Connector Name	HIGH-MOUNTED STOP LAMP	Connector Name	ICC BRAKE HOLD RELAY	Connector Name	FUSE BLOCK (J/B)	Color	WIRE TO WIRE	Connector Name	FUSE BLOCK (J/B)	Connector Name	STOP LAMP SWITCH	Color	WIRE TO WIRE		
Connector Type	TH24FW-NH	Connector Type	TB02MW	Connector Type	M05FW-R-US	Connector Type	NS16FW-CS	Connector Type	TH04FW-OS	Connector Type	TH04FW-CS16-TM4	Connector Type	MOAFW-LC	Connector Type	TH04FW-CS16-TM4		
Diagram		Diagram		Diagram		Diagram		Diagram		Diagram		Diagram		Diagram			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
18	LG	-	1	LG	-	1	L	-	2	B	-	2	B	-	1	L	-
			2	B	-	2	B	-	3	G	-	3	G	-	3	G	-
						4	G	-	4	G	-	4	G	-	4	G	-
						6	W	-	6	W	-	6	W	-	6	W	-
						7	L	-	7	L	-	7	L	-	7	L	-

JCLWM1805GB

# STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

A

B

C

D

E

F

G

H

I

J

K


EXL

M

N

O

P

STOP LAMP	
Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	THBDMW-CS16-TM4
	
Signal Name [Specification]	
Terminal No.	Color of Wire
40	V
77	LG

JCLWM1806GB

# BACK-UP LAMP

< DTC/CIRCUIT DIAGNOSIS >


[XENON TYPE]

## BACK-UP LAMP

### Wiring Diagram - BACK-UP LAMP -

INFOID:0000000003846229

BACK-UP LAMP



2008/03/04  
JCLWM1807GB

# BACK-UP LAMP

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## BACK-UP LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4
	

Terminal No.	Color of Wire	Signal Name [Specification]
6	GR	-
32	O	-

Connector No.	B27
Connector Name	WIRE TO WIRE
Connector Type	MID6AW-LC

Connector No.	B28
Connector Name	WIRE TO WIRE
Connector Type	TH24AW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	2	3
4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
1	2	3
4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
1	2	3
4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
1	2	3
4	5	6

P

Z

M

M

EXL

D

T

G

M

C

B

A

# BACK-UP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

BACK-UP LAMP			
Connector No.	F103	Connector No.	M151
Connector Name	WIRE TO WIRE	Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	TK3SFV-NS10	Connector Type	SPI10FG
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
31	R	7	L
Signal Name [Specification]		Signal Name [Specification]	
-	-	REV LAMP RLY	-
Connector No.	M69	Connector No.	M116
Connector Name	BACK-UP LAMP RELAY	Connector Name	WIRE TO WIRE
Connector Type	MSOFI-M2-LC	Connector Type	TK3MMI-NS10
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	R	1	W
2	W	2	-
3	R	3	-
5	O	5	-
Signal Name [Specification]		Signal Name [Specification]	
-	-	-	-

JCLWM1809GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## ECU DIAGNOSIS INFORMATION BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:000000004068509

### VALUES ON THE DIAGNOSIS TOOL

#### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Monitor Item	Condition	Value/Status
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the Intelligent Key is not pressed	Off
	PANIC button of the Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Monitor Item	Condition	Value/Status
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O


P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## TERMINAL LAYOUT




## PHYSICAL VALUES

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	12 V
4 (P)	Ground	Interior room lamp power supply (Battery saver signal)	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
5 (V)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)
					ACC or ON
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch RH







PKID0926E

6.5 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
18 (O)	Ground	Turn signal LH (Front)	Output	Turn signal switch OFF			
				0 V			
19 (SB)	Ground	Room lamp timer	Output	Turn signal switch LH			
				 PKID0926E 6.5 V			
20 (V)	Ground	Turn signal RH (Rear)	Output	Turn signal switch OFF			
				0 V			
25 (G)	Ground	Turn signal LH (Rear)	Output	Turn signal switch ON			
				 PKID0926E 6.5 V			
26 (G)	Ground	Rear wiper	Output	Turn signal switch RH			
				0 V			
34 (SB)	Ground	Luggage room antenna (-)	Output	Turn signal switch OFF			
				 JMKIA0062GB			
				When Intelligent Key is in the passenger compartment			
				 JMKIA0063GB			
				When Intelligent Key is not in the passenger compartment			

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment
				 JMKA0062GB
38 (B)	Ground	Back door antenna (-)	Output When the back door opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is not in the passenger compartment
				 JMKA0063GB
39 (W)	Ground	Back door antenna (+)	Output When the back door opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area
				 JMKA0062GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output Ignition switch	OFF or ACC
				12 V
				ON
				0 V

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N





O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
48 (W)	Ground	Back door opener switch operation	Output	Back door opener switch	Not pressed	12 V
					Pressed	0 V
52 (LG)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	12 V
					When selector lever is not in P or N position	0 V
61 (W)	Ground	Back door opener request switch	Input	Back door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
64 (L)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	12 V
65 (O)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	 <small>JPMIA0016GB</small> 1.0 V
					Not in stop position	0 V
66 (LG)	Ground	Back door switch	Input	Back door switch	OFF (Door close)	12 V
					ON (Door open)	0 V
67 (P)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 <small>JPMIA0594GB</small> 8.5 - 9.0 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	 <small>JPMIA0594GB</small> 8.5 - 9.0 V
					ON (Door open)	0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
69 (R)	Ground	Rear LH door switch	Input	 JPMIA0594GB 8.5 - 9.0 V
				ON (Door open) 0 V
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	 JMKIA0062GB
				When Intelligent Key is not in the passenger compartment
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	 JMKIA0062GB
				When Intelligent Key is in the passenger compartment

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
75 (BR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB



JMKIA0062GB









JMKIA0063GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	Ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N



O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (P)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch OFF or ACC 0 V ON 12 V
83 (GR)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting  JKMKIA0064GB
				When operating either button on the Intelligent Key  JKMKIA0065GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
87 (BR)	Ground	Combination switch INPUT 5	Input	All switches OFF (Wiper intermittent dial 4)   <small>JPMIA0041GB</small> 1.4 V	A
				Front fog lamp switch ON (Wiper intermittent dial 4)   <small>JPMIA0037GB</small> 1.3 V	B
				Rear wiper switch ON (Wiper intermittent dial 4)   <small>JPMIA0039GB</small> 1.3 V	C
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>  <small>JPMIA0040GB</small> 1.3 V	D
<b>EXL</b>					

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N






O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
88 (V)	Ground	Combination switch INPUT 3	Input	 All switches OFF (Wiper intermittent dial 4)   Lighting switch HI (Wiper intermittent dial 4)   Lighting switch 2ND (Wiper intermittent dial 4)   Rear washer switch ON (Wiper intermittent dial 4)   Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3
				JPMIA0041GB 1.4 V
				JPMIA0036GB 1.3 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
89 (SB)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (Push switch) Pressed Not pressed
				0 V
				12 V
90 (P)	Ground	CAN-L	Input/ Output	—
91 (L)	Ground	CAN-H	Input/ Output	—

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	12 V
					Blinking	 <small>JPMIA0015GB</small>
					ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ON or ACC	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		12 V
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	12 V
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	12 V
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small>
						1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small>
						1.0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		12 V

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N






O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC 12 V
				ON 0 V	
107 (LG)	Ground	Combination switch INPUT 1	Input	All switches OFF	 JPMIA0041GB 1.4 V
				Turn signal switch LH	 JPMIA0037GB 1.3 V
				Turn signal switch RH	 JPMIA0036GB 1.3 V
				Front wiper switch LO	 JPMIA0038GB 1.3 V
				Front washer switch ON	 JPMIA0039GB 1.3 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)				
	Signal name	Input/ Output						
108 (R)	Ground	Combination switch INPUT 4	Input	All switches OFF (Wiper intermittent dial 4)	 (V) 15 10 5 0 2 ms			
					JPMIA0041GB 1.4 V			
				Lighting switch AUTO (Wiper intermittent dial 4)	 (V) 15 10 5 0 2 ms			
				Lighting switch 1ST (Wiper intermittent dial 4)	 (V) 15 10 5 0 2 ms			
				Rear wiper switch INT (Wiper intermittent dial 4)	 (V) 15 10 5 0 2 ms			
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	 (V) 15 10 5 0 2 ms			
					JPMIA0039GB 1.3 V			

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
109 (Y)	Ground	Combination switch INPUT 2	Combination switch (Wiper intermittent dial 4)	All switches OFF
				 1.4 V <small>JPMIA0041GB</small>
				 1.3 V <small>JPMIA0037GB</small>
				 1.3 V <small>JPMIA0036GB</small>
				 1.3 V <small>JPMIA0038GB</small>
110 (G)	Ground	Hazard switch	Hazard switch	ON
				 0 V
			OFF	 1.1 V <small>JPMIA0012GB</small>

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
111 (GR)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V
					LOCK or UNLOCK	 (V) 15 10 5 0 50 ms <small>JMKIA0066GB</small>
					For 15 seconds after UN-LOCK	12 V
					15 seconds or later after UNLOCK	0 V
112 (GR)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON	 (V) 15 10 5 0 10ms <small>JPMIA0156GB</small>	8.7 V
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
116 (BR)	Ground	Stop lamp switch 1	Input	—		Battery voltage
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	Battery voltage
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 (V) 15 10 5 0 10ms <small>JPMIA0594GB</small>
					UNLOCK status (Unlock switch sensor ON)	0 V
121 (BR)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot		12 V
				When the Intelligent Key is not inserted into key slot		0 V
122 (V)	Ground	ACC feedback	Input	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 <small>JPMIA0594GB</small> 8.5 - 9.0 V
					ON (Door opene)	0 V
132 (O)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 <small>JPMIA0013GB</small> 10.2 V
				Ignition switch OFF or ACC	12 V	
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (B)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
140 (R)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	12 V
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 <small>JPMIA0014GB</small> 11.3 V
					OFF	12 V
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	 <small>JPMIA0031GB</small> 10.7 V
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
143 (P)	Ground	Combination switch OUTPUT 1	Output	All switches OFF (Wiper intermittent dial 4)  Front wiper switch HI (Wiper intermittent dial 4)  Rear wiper switch INT (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>
144 (G)	Ground	Combination switch OUTPUT 2	Output	All switches OFF (Wiper intermittent dial 4)  Front washer switch ON (Wiper intermittent dial 4)  Rear wiper switch ON (Wiper intermittent dial 4)  Rear washer switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>
145 (L)	Ground	Combination switch OUTPUT 3	Output	All switches OFF  Front wiper switch INT  Front wiper switch LO  Lighting switch AUTO
146 (SB)	Ground	Combination switch OUTPUT 4	Output	All switches OFF  Front fog lamp switch ON  Lighting switch 2ND  Lighting switch PASS  Turn signal switch LH

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
150 (GR)	Ground	Driver door switch	Input	Driver door switch
				OFF (Door close)
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger
				Active
				Not activated



JPMIA0594GB

8.5 - 9.0 V

0 V

Battery voltage


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## Wiring Diagram - BCM -

INFOID:000000004068510




JCMWM1990GB

2008/03/04

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]




JCMWW1991GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]




A B C D E F G H I J K L M N O P EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

◆PM: With automatic drive positioner




JCMW1993GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]





JCMWW1994GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

BCM (BODY CONTROL MODULE)																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Connector No.</th> <th>M33</th> <th></th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>COMBINATION SWITCH</td> <td></td> </tr> <tr> <td>Connector Type</td> <td>TH16FW-NH</td> <td></td> </tr> </tbody> </table> 	Connector No.	M33		Connector Name	COMBINATION SWITCH		Connector Type	TH16FW-NH		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Connector No.</th> <th>M118</th> <th></th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>BCM (BODY CONTROL MODULE)</td> <td></td> </tr> <tr> <td>Connector Type</td> <td>MD3FB-LC</td> <td></td> </tr> </tbody> </table> 	Connector No.	M118		Connector Name	BCM (BODY CONTROL MODULE)		Connector Type	MD3FB-LC		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Connector No.</th> <th>M119</th> <th></th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>BCM (BODY CONTROL MODULE)</td> <td></td> </tr> <tr> <td>Connector Type</td> <td>NS16FW-CS</td> <td></td> </tr> </tbody> </table> 	Connector No.	M119		Connector Name	BCM (BODY CONTROL MODULE)		Connector Type	NS16FW-CS	
Connector No.	M33																												
Connector Name	COMBINATION SWITCH																												
Connector Type	TH16FW-NH																												
Connector No.	M118																												
Connector Name	BCM (BODY CONTROL MODULE)																												
Connector Type	MD3FB-LC																												
Connector No.	M119																												
Connector Name	BCM (BODY CONTROL MODULE)																												
Connector Type	NS16FW-CS																												
																													
																													
																													
																													
																													
																													

JCMWM1995GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

BCM (BODY CONTROL MODULE)		
Connector No.	Signal Name [Specification]	Terminal No.
M122	KEYLESS ENTRY RECEIVER SIGNAL COMBI SW INPUT 5	83 GR
	COMBI SW INPUT 3	87 BR
	PUSH SW	88 V
	CAN-H	89 SB
	OAN-H	90 P
	KEY SLOT TLL ON IND	91 L
	ACC RELAY CONT	92 LG
	A-T SHIFT SELECTOR POWER SUPPLY	93 V
	S/L CONDITION 1	95 O
	S/L CONDITION 2	96 GR
	SHIFT P	97 L
	PASSANGER DOOR REQUEST SW	98 P
	DRIVER DOOR REQUEST SW	99 R
	ROOM ANT2-	100 G
	ROOM ANT2+	101 SB
	PASSENGER DOOR ANT-	102 O
	PASSENGER DOOR ANT+	103 BR
	DRIVER DOOR ANT-	104 W
	DRIVER DOOR ANT-	105 V
	ROOM ANT1-	106 R
	ROOM ANT1+	107 G
	IMMOB ANTENNA CONTROL	108 Y
	IMMOB ANTENNA SIGNAL	109 Y
	IGN RELAY (F/B) CONT	110 G
	IGN RELAY (F/B) CONT	111 GR
	IGN RELAY (F/B) CONT	112 P
	RECEIVER SENSOR GND	137 B
	SENSOR POWER SUPPLY	138 Y
	SHIFT N/P	140 R
	SECURITY INDICATOR OUTPUT	141 G
	COMBI SW OUTPUT 5	142 O
	COMBI SW OUTPUT 1	143 P
	COMBI SW OUTPUT 2	144 G
	COMBI SW OUTPUT 3	145 L
	COMBI SW OUTPUT 4	146 SE
	DRIVER DOOR SW	150 GR
	REAR WINDOW DEFOGGER RELAY CONT	151 G

JCMWM1996GB

INFOID:0000000005176731

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

A B C D E F G H I K M O P

EXL

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

**[XENON TYPE]**

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (battery voltage)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Power position: IGN</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>• Interlock/PNP switch signal (CAN): OFF</li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (battery voltage)</li> <li>- PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>• BCM steering lock control status</li> <li>• Steering lock condition No. 1 signal status</li> <li>• Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering lock unit status signal (CAN) is received normally</li> <li>• The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering condition No. 1 signal: LOCK (0 V)</li> <li>• Steering condition No. 2 signal: LOCK (Battery voltage)</li> </ul>

## HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

## FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

### NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT position, BCM operates a fail-safe control.

## REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

## DTC Inspection Priority Chart

INFOID:000000004068512

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"><li>• U1000: CAN COMM</li><li>• U1010: CONTROL UNIT (CAN)</li></ul>
3	<ul style="list-style-type: none"><li>• B2190: NATS ANTENNA AMP</li><li>• B2191: DIFFERENCE OF KEY</li><li>• B2192: ID DISCORD BCM-ECM</li><li>• B2193: CHAIN OF BCM-ECM</li><li>• B2195: ANTI SCANNING</li></ul>
4	<ul style="list-style-type: none"><li>• B2013: ID DISCORD BCM-S/L</li><li>• B2014: CHAIN OF S/L-BCM</li><li>• B2553: IGNITION RELAY</li><li>• B2555: STOP LAMP</li><li>• B2556: PUSH-BTN IGN SW</li><li>• B2557: VEHICLE SPEED</li><li>• B2560: STARTER CONT RELAY</li><li>• B2601: SHIFT POSITION</li><li>• B2602: SHIFT POSITION</li><li>• B2603: SHIFT POSI STATUS</li><li>• B2604: PNP SW</li><li>• B2605: PNP SW</li><li>• B2606: S/L RELAY</li><li>• B2607: S/L RELAY</li><li>• B2608: STARTER RELAY</li><li>• B2609: S/L STATUS</li><li>• B260A: IGNITION RELAY</li><li>• B260B: STEERING LOCK UNIT</li><li>• B260C: STEERING LOCK UNIT</li><li>• B260D: STEERING LOCK UNIT</li><li>• B260F: ENG STATE SIG LOST</li><li>• B2612: S/L STATUS</li><li>• B2614: ACC RELAY CIRC</li><li>• B2615: BLOWER RELAY CIRC</li><li>• B2616: IGN RELAY CIRC</li><li>• B2617: STARTER RELAY CIRC</li><li>• B2618: BCM</li><li>• B2619: BCM</li><li>• B261A: PUSH-BTN IGN SW</li><li>• B261E: VEHICLE TYPE</li><li>• B26E9: S/L STATUS</li><li>• B26EA: KEY REGISTRATION</li><li>• U0415: VEHICLE SPEED SIG</li></ul>
5	<ul style="list-style-type: none"><li>• B2621: INSIDE ANTENNA</li><li>• B2622: INSIDE ANTENNA</li><li>• B2623: INSIDE ANTENNA</li></ul>
6	B26E7: TPMS CAN COMM

## DTC Index

INFOID:000000004068513

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [EXL-32, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Reference page
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	<a href="#">BCS-34</a>
U1010: CONTROL UNIT (CAN)	—	—	—	<a href="#">BCS-35</a>
U0415: VEHICLE SPEED SIG	—	—	—	<a href="#">BCS-36</a>
B2013: ID DISCORD BCM-S/L	×	×	—	<a href="#">SEC-50</a>
B2014: CHAIN OF S/L-BCM	×	×	—	<a href="#">SEC-51</a>
B2190: NATS ANTENNA AMP	×	—	—	<a href="#">SEC-42</a>
B2191: DIFFERENCE OF KEY	×	—	—	<a href="#">SEC-45</a>
B2192: ID DISCORD BCM-ECM	×	—	—	<a href="#">SEC-46</a>
B2193: CHAIN OF BCM-ECM	×	—	—	<a href="#">SEC-48</a>
B2195: ANTI SCANNING	×	—	—	<a href="#">SEC-49</a>
B2553: IGNITION RELAY	—	×	—	<a href="#">PCS-50</a>
B2555: STOP LAMP	—	×	—	<a href="#">SEC-54</a>
B2556: PUSH-BTN IGN SW	—	×	×	<a href="#">SEC-56</a>
B2557: VEHICLE SPEED	×	×	×	<a href="#">SEC-58</a>
B2560: STARTER CONT RELAY	×	×	×	<a href="#">SEC-59</a>
B2562: LOW VOLTAGE	—	×	—	<a href="#">BCS-37</a>
B2601: SHIFT POSITION	×	×	×	<a href="#">SEC-60</a>
B2602: SHIFT POSITION	×	×	×	<a href="#">SEC-63</a>
B2603: SHIFT POSI STATUS	×	×	×	<a href="#">SEC-65</a>
B2604: PNP SW	×	×	×	<a href="#">SEC-68</a>
B2605: PNP SW	×	×	×	<a href="#">SEC-70</a>
B2606: S/L RELAY	×	×	×	<a href="#">SEC-72</a>
B2607: S/L RELAY	×	×	×	<a href="#">SEC-73</a>
B2608: STARTER RELAY	×	×	×	<a href="#">SEC-75</a>
B2609: S/L STATUS	×	×	×	<a href="#">SEC-77</a>
B260A: IGNITION RELAY	×	×	×	<a href="#">PCS-52</a>
B260B: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-81</a>
B260C: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-82</a>
B260D: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-83</a>
B260F: ENG STATE SIG LOST	×	×	×	<a href="#">SEC-84</a>
B2612: S/L STATUS	×	×	×	<a href="#">SEC-88</a>
B2614: ACC RELAY CIRC	—	×	×	<a href="#">PCS-54</a>
B2615: BLOWER RELAY CIRC	—	×	×	<a href="#">PCS-56</a>
B2616: IGN RELAY CIRC	—	×	×	<a href="#">PCS-58</a>
B2617: STARTER RELAY CIRC	×	×	×	<a href="#">SEC-92</a>
B2618: BCM	×	×	×	<a href="#">PCS-60</a>
B2619: BCM	×	×	×	<a href="#">SEC-94</a>
B261A: PUSH-BTN IGN SW	—	×	×	<a href="#">SEC-95</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-98</a>

A

B

C

D

E

F

G

H

I

J

EXL

M

N

O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Reference page
B2621: INSIDE ANTENNA	—	×	—	<a href="#">DLK-61</a>
B2622: INSIDE ANTENNA	—	×	—	<a href="#">DLK-63</a>
B2623: INSIDE ANTENNA	—	×	—	<a href="#">DLK-65</a>
B26E7: TPMS CAN COMM	—	—	—	<a href="#">BCS-38</a>
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-86</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	<a href="#">SEC-87</a>

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
 <ECU DIAGNOSIS INFORMATION> **[XENON TYPE]**

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**

**Reference Value**

INFOID:000000004068514

**VALUES ON THE DIAGNOSIS TOOL**

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	Off
		• Front fog lamp switch ON • Daytime running light activated (Only for Canada)	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**<ECU DIAGNOSIS INFORMATION>** **[XENON TYPE]**


Monitor Item	Condition	Value/Status
ST/INHI RLY	Ignition switch ON	Off
	At engine cranking	INHI → ST
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> <li>• Press the selector button with selector lever in P position</li> <li>• Selector lever in any position other than P</li> </ul>
	Release the selector button with selector lever in P position	On
S/L RLY -REQ	None of the conditions below are present	Off
	<ul style="list-style-type: none"> <li>• Open the driver door after the ignition switch is turned OFF (for a few seconds)</li> <li>• Press the push-button ignition switch when the steering lock is activated</li> </ul>	On
S/L STATE	Steering lock is activated	LOCK
	Steering lock is deactivated	UNLOCK
	[DTC: B210A] is detected	UNKWN
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
OIL P SW	Ignition switch OFF, ACC or engine running	Open
	Ignition switch ON	Close
HOOD SW	Close the hood	Off
	Open the hood	On
HL WASHER REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
THFT HRN REQ	Not operation	Off
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On
HORN CHIRP	Not operating	Off
	Door locking with Intelligent Key (horn chirp mode)	On
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[XENON TYPE]

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
4 (V)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch HI	Front wiper switch HI	Battery voltage
7 (R)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
				Lighting switch 1ST	Lighting switch 1ST	Battery voltage
10 <sup>*1</sup> (SB)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

<ECU DIAGNOSIS INFORMATION>

[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
11 (BR)	Ground	Steering lock unit power supply	Output	Ignition switch OFF A few seconds after opening the driver door
				Ignition switch LOCK Press the push-button ignition switch
				Ignition switch ACC or ON 0 V
12 (B)	Ground	Ground	—	Ignition switch ON 0 V
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON 0 V
				• Approximately 1 second after turning the ignition switch ON • Engine running Battery voltage
16 (LG)	Ground	Front wiper stop position	Input	Ignition switch ON Front wiper stop position 0 V
				Any position other than front wiper stop position Battery voltage
19 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF 0 V
				Ignition switch ON Battery voltage
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF 0 V
				Ignition switch ON Battery voltage
26 <sup>*2</sup> (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF 0 V
				Ignition switch ON Battery voltage
27 (Y)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC Battery voltage
				Ignition switch ON 0 V
28 (O)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch 0 V
				Release the push-button ignition switch Battery voltage
30 (GR)	Ground	Starter relay control	Input	Ignition switch ON Selector lever in any position other than P or N 0 V
				Selector lever P or N Battery voltage
32 (SB)	Ground	Steering lock unit condition-1	Input	Steering lock is activated 0 V
				Steering lock is deactivated Battery voltage
33 (P)	Ground	Steering lock unit condition-2	Input	Steering lock is activated Battery voltage
				Steering lock is deactivated 0 V
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF Battery voltage
39 (P)	—	CAN-L	Input/ Output	— —
40 (L)	—	CAN-H	Input/ Output	— —
41 (B)	Ground	Ground	—	Ignition switch ON 0 V
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC 0 V
				Ignition switch ON 0.7 V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[XENON TYPE]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
43 (SB)	Ground	Control device (Detention switch)	Input	<ul style="list-style-type: none"> <li>Press the selector button (Selector lever P)</li> <li>Selector lever in any position other than P</li> </ul>
				Release the selector button (selector lever P)
44 (W)	Ground	Horn relay control	Input	The horn is deactivated
				The horn is activated
45 (G)	Ground	Anti theft horn relay control	Input	The horn is deactivated
				The horn is activated
46 (BR)	Ground	Starter relay control	Input	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Selector lever in any position other than P or N</li> </ul>
				Selector lever P or N
48 (L)	Ground	A/C relay power supply	Output	<ul style="list-style-type: none"> <li>A/C switch OFF</li> <li>A/C switch ON (A/C compressor is operating)</li> </ul>
49 (W)*1 (SB)*3	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>
51 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF
				Battery voltage
52*1 (W)	Ground	Ignition relay power supply	Output	Ignition switch ON
				Battery voltage
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>
54 (R)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>
55 (BR)	Ground	ECM power supply	Output	Ignition switch OFF
56 (O)*1 (V)*3	Ground	Ignition relay power supply	Output	Ignition switch ON
				Battery voltage
57 (LG)*1 (R)*3	Ground	Ignition relay power supply	Output	Ignition switch OFF
				Battery voltage

A

B

C

D

E

F

G

H

I

J

K

EXL




M

N

O

P

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**<ECU DIAGNOSIS INFORMATION>** [XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
58 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF
				Battery voltage
69 (W)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)
70 (O)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF
				0 – 1.0 V ↓ Battery voltage ↓ 0 V
74 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF
				Battery voltage
75 (Y)	Ground	Oil pressure switch	Input	Ignition switch ON
				0 V
				Engine stopped
				Battery voltage
				Engine running
76 (P) <sup>*1</sup> (V) <sup>*3</sup>	Ground	Power generation command signal	Output	Ignition switch ON
				 6.3 V
				40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"
				 3.8 V
				80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"
				 1.4 V
77 (B) <sup>*1</sup> (L) <sup>*3</sup>	Ground	Fuel pump relay control	Output	• Approximately 1 second after turning the ignition switch ON • Engine running
				0 – 1.0 V
				Approximately 1 second or more after turning the ignition switch ON
80 (W)	Ground	Starter motor	Output	At engine cranking
				Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[XENON TYPE]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (R)	Ground	Headlamp LO (RH)	Output Ignition switch ON	Lighting switch OFF
				Battery voltage
84 (P)	Ground	Headlamp LO (LH)	Output Ignition switch ON	Lighting switch OFF
				Battery voltage
86 (W)	Ground	Front fog lamp (RH)	Output Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Can-ada)</li> </ul>
				0 V
87 (GR)	Ground	Front fog lamp (LH)	Output Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Can-ada)</li> </ul>
				0 V
88 (G)	Ground	Washer pump power supply	Output Ignition switch ON	Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>
				0 V
90 (Y)	Ground	Headlamp HI (LH)	Output Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>
				0 V
91 (P)	Ground	Parking lamp (RH)	Output Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch 1ST</li> <li>Lighting switch OFF</li> </ul>
				0 V
92 (O)	Ground	Parking lamp (LH)	Output Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch 1ST</li> <li>Lighting switch OFF</li> </ul>
				0 V
97 (V)	Ground	Cooling fan control	Output Engine idling	0 – 5 V
104 (LG)	Ground	Hood switch	Input Close the hood	Battery voltage
				0 V

\*1: VK engine models

\*2: Only for the models with ICC system

\*3: VQ engine models

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## Wiring Diagram - IPDM E/R -

INFOID:000000004068515


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)



2008/03/04

JCMWM2014GB


**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**< ECU DIAGNOSIS INFORMATION >** [XENON TYPE]



JCMWW2015GB



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
EXL  
M  
N  
O  
P

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
<ECU DIAGNOSIS INFORMATION> **[XENON TYPE]**





JCMWM2016GB

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
 < ECU DIAGNOSIS INFORMATION > **[XENON TYPE]**

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			
Connector No.	ED	Connector No.	
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	L02FB-MC	Connector Type	TH20FW-CS12-M4-IV
			
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	W	-	
2	L	-	
Terminal No.	Color of Wire	Signal Name [Specification]	
4	V	-	
5	L	-	
7	R	-	
10	SB	-	
11	BR	-	
12	B	-	
13	Y	-	
16	LG	-	
19	W	-	
25	G	-	
26	R	-	
Terminal No.	Color of Wire	Signal Name [Specification]	
57	LG	- (With VK engine)	
58	Y	-	
69	W	-	
70	O	-	
74	G	-	
75	Y	- (With VQ engine)	
76	P	- (With VK engine)	
77	L	- (With VQ engine)	
78	B	- (With VK engine)	
80	V	-	
Terminal No.	Color of Wire	Signal Name [Specification]	
48	L	-	
49	W	- (With VK engine)	
49	SB	- (With VQ engine)	
51	G	-	
52	W	-	
53	W	-	
54	R	-	
55	BR	-	
56	V	- (With VQ engine)	
56	O	- (With VQ engine)	
57	R	- (With VQ engine)	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			
Connector No.	E5	Connector No.	
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4	Connector Type	TH20FW-CS
			
			
Terminal No.	Color of Wire	Signal Name [Specification]	
9	10	11 12 13 14	
3	4	5 6 7 8	
15	16	17 18 19 20 21 22 23 24	
35	36	37 38	
Terminal No.	Color of Wire	Signal Name [Specification]	
39	P	-	
40	L	-	
41	B	-	
42	Y	-	
43	SB	-	
44	W	-	
45	G	-	
46	BR	-	
Terminal No.	Color of Wire	Signal Name [Specification]	
55	84	83	
56	89	88	
57	97	96	
58	95	94	
59	93	92	
60	91	90	
65	104	103	
66	105	102	
67	101	100	
68	102	99	
Terminal No.	Color of Wire	Signal Name [Specification]	
83	R	-	
84	P	-	
86	W	-	
87	GR	-	
88	G	-	
89	BR	-	
90	Y	-	
Terminal No.	Color of Wire	Signal Name [Specification]	
91	P	-	
92	V	-	
97	GR	-	
104	LG	-	

JCMWM2017GB

INFOID:0000000004068516

## Fail-safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

A B C D E F G H I J K L M N O P EXL

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**<ECU DIAGNOSIS INFORMATION>** [XENON TYPE]

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>• Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>• Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>
• Parking lamps • License plate lamps • Side marker lamps • Illuminations • Tail lamps	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF
Steering lock unit	Steering lock relay OFF

#### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC "B2098: IGN RELAY ON"</li> <li>• Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

#### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**< ECU DIAGNOSIS INFORMATION >** [XENON TYPE]

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

**NOTE:**

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

**STARTER MOTOR PROTECTION FUNCTION**

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

**DTC Index**

INFOID:000000004068517

**NOTE:**

- The details of time display are as follows.
- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
- The number is 0 when is detected now.
- The number increases like 1 → 2 … 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
- The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

x: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-16</a>
B2098: IGN RELAY ON	×	<a href="#">PCS-17</a>
B2099: IGN RELAY OFF	—	<a href="#">PCS-18</a>
B2108: STRG LCK RELAY ON	—	<a href="#">SEC-99</a>
B2109: STRG LCK RELAY OFF	—	<a href="#">SEC-100</a>
B210A: STRG LCK STATE SW	—	<a href="#">SEC-101</a>
B210B: START CONT RLY ON	—	<a href="#">SEC-105</a>
B210C: START CONT RLY OFF	—	<a href="#">SEC-106</a>
B210D: STARTER RELAY ON	—	<a href="#">SEC-107</a>
B210E: STARTER RELAY OFF	—	<a href="#">SEC-108</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-110</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-112</a>

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## AFS CONTROL UNIT

### Reference Value


INFOID:0000000003846447

### VALUES ON THE DIAGNOSIS TOOL

#### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
STR ANGLE SIG	Steering	Straight-forward
		Approx. 0°
VHCL SPD	Driving at 40 km/h (25 MPH)	Approx. -900° - +900°
		40 km/h
SLCT LVR POSI	Selector lever operation	P - 1
HEAD LAMP	Light switch	2ND
		On
AFS SW	AFS OFF switch	Other than 2ND
		Off
HI SEN OTP RR	Vehicle rear height	ON
		Off
LEV ACTR VLTG	Headlamp leveling	Unloaded vehicle condition
		Approx. 2.5 V
		Low (Leveling operation downward edge)
SWVL SEN RH	Right headlamp swivel activation	Approx. 1.6 V (With 20-inch wheel)
		Approx. 1.8 V (With 21-inch wheel)
		Unloaded vehicle condition
SWVL SEN LH	Left headlamp swivel activation	Approx. 70.0%
		Low (Leveling operation downward edge)
		Approx. 40.8% (With 20-inch wheel)
SWVL ANGLE RH	Right headlamp swivel activation	Approx. 41.8% (With 21-inch wheel)
		Standard position
SWVL ANGLE LH	Left headlamp swivel activation	Approx. 0°
		Activation
SWVL ANGLE RH	Right headlamp swivel activation	Positive degree (+°)
		Standard position
SWVL ANGLE LH	Left headlamp swivel activation	Positive degree (+°)
		Activation

#### TERMINAL LAYOUT





JPLIA0176ZZ

#### PHYSICAL VALUES

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



[XENON TYPE]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A	
	+	-				
1 (Y)	Ground	Ignition power supply	Input	Ignition switch ON	Battery voltage	
2 (LG)	Ground	Right swivel position sensor ground	Input	Ignition switch ON	0 V	
3 (GR)	Ground	AFS switch signal	Input	AFS OFF switch	0 V	
				ON	Battery voltage	
4 (Y)	Ground	Right swivel position sensor power supply	Output	Ignition switch ON	5 V	
6 (W)	Ground	Height sensor power supply	Output	Ignition switch ON	5 V	
7 (P)	Ground	CAN-L	Input/ output	—	—	
8 (B)	Ground	Height sensor ground	Input	Ignition switch ON	0 V	
9 (GR)	Ground	Right swivel position sensor signal	Output	Right headlamp swivel angle	0°	
				15°	2.8 V	
11 (R)	Ground	Right swivel motor 1-phase (-)	Output	Right headlamp swivel	Activation	Reference waveform (V)  SKIB2408J 8 - 12 V
13 (B)	Ground	Right swivel motor 2-phase (-)	Output	Right headlamp swivel	Stopped	9.5 - 11.5 V
15 (G)	Ground	Left swivel motor 1-phase (+)	Output	Left headlamp swivel	Activation	Reference waveform (V)  SKIB2408J 8 - 12 V
17 (W)	Ground	Left swivel motor 2-phase (+)	Output	Left headlamp swivel	Stopped	9.5 - 11.5 V
19 (SB)	Ground	Right levelizer signal	Output	Right headlamp leveling	Unloaded vehicle condition	8.8 V
					Leveling operation downward edge	5.1 V (With 20-inch wheel)
						5.2 V (With 21-inch wheel)
24 (V)	Ground	Left swivel position sensor power supply	Output	Ignition switch ON		5 V
25 (B)	Ground	Ground	—	Ignition switch ON		0 V
27 (BR)	Ground	Left swivel position sensor ground	Input	Ignition switch ON		0 V

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ output			
28 (SB)	Ground	Height sensor signal	Output	Vehicle rear height	Unloaded ve-hicle condition	2.5 V
					Low (Leveling operation downward edge)	1.6 V (With 20-inch wheel)
						1.8 V (With 21-inch wheel)
29 (O)	Ground	Left swivel position sensor signal	Output	Left headlamp swivel angle	0°	0.7 V
					17°	3.0 V
30 (L)	Ground	CAN-H	Input/ output	—		—
32 (G)	Ground	Right swivel motor 2-phase (+)	Output	Right headlamp swivel	Activation	Reference waveform  SKIB2408J 8 - 12 V
34 (W)	Ground	Right swivel motor 1-phase (+)	Output	Right headlamp swivel	Stopped	9.5 - 11.5 V
36 (R)	Ground	Left swivel motor 2-phase (-)	Output	Left headlamp swivel	Activation	Reference waveform  SKIB2408J 8 - 12 V
38 (B)	Ground	Left swivel motor 1-phase (-)	Output	Left headlamp swivel	Stopped	9.5 - 11.5 V
40 (O)	Ground	Left levelizer signal	Output	Right headlamp leveling	Unloaded ve-hicle condition	8.8 V
					Leveling operation downward edge	5.1 V (With 20-inch wheel)
						5.2 V (With 21-inch wheel)


# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## Wiring Diagram - ACTIVE AFS -

INFOID:000000003846240



2008/03/04


JCLWM1786GB

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

- : With VQ engine
- : With VK engine
- : With automatic drive positioner
- : Without automatic drive positioner
- : AWD models with ICC
- \*1 114 :
- 105 :
- \*2 113 :
- 101 :



\*: This connector is not shown in "Harness Layout".

JCLWM1787GB


# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## ACTIVE AFS


Connector No.	B32	Connector No.	E5
Connector Name	HEIGHT SENSOR	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE E/ENGINE ROOM)
Connector Type	RH05FB	Connector Type	TH20BW-CS12-M4-I/V TH08BW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	SB	-
3	GR	-


Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
44	V	-
45	GR	-
80	L	-
81	P	-
82	L	-
83	P	-

Connector No.	E22	Connector No.	E59
Connector Name	WIRE TO WIRE	Connector Name	HEADLAMP SWIVEL ACTUATOR LH
Connector Type	TH08BW-CS16-TM4	Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	Y	-
3	G	-
4	W	-
6	LG	-
7	B	-
8	R	-

Connector No.	E5	Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE E/ENGINE ROOM)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE E/ENGINE ROOM)
Connector Type	TH20BW-CS12-M4-I/V	Connector Type	TH20BW-CS12-M4-I/V



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-

Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	Y	-
42	G	-
43	GR	-
44	W	-
45	LG	-
46	B	-

Connector No.	E56	Connector No.	E59
Connector Name	FRONT COMBINATION LAMP LH	Connector Name	HEADLAMP SWIVEL ACTUATOR LH
Connector Type	TRK03FB	Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	O	-
3	B	-
4	GR	-
5	W	-
6	LG	-
7	W	-
8	B	-

JCLWM1788GB

EXL M Z O P

A B C D E G T M

# AFS CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**

**[XENON TYPE]**

ACTIVE AFS		
Connector No.	E103	
Connector Name	FUSE BLOCK (J/B)	
Connector Type	NS18FW-CS	
		
Terminal No.	Color of Wire	Signal Name [Specification]
4F	G	-
47	G	-
48	P	-

F106		
Connector No.	E123	
Connector Name	WIRE TO WIRE	
Connector Type	TH34FW-NH	
		
Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	G	-
3	B	-
4	W	-
5	R	-
6	SHIELD	-
7	Y	-
8	GR	-
9	LG	-
13	O	-
14	R	-

F151		
Connector No.	M1	
Connector Name	FUSE BLOCK (J/B)	
Connector Type	NS06FW-M2	
		
Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	G	-
3	B	-
4	W	-
5	R	-
6	SHIELD	-
7	Y	-
8	GR	-

F103		
Connector No.	F103	
Connector Name	WIRE TO WIRE	
Connector Type	TK38FW-NS10	
		
Terminal No.	Color of Wire	Signal Name [Specification]
5	W	-
4	G	-
3	B	-
2	Y	-
1	GR	-
10	R	-
9	LG	-
8	O	-
7	SHIELD	-
6	W	-
5	G	-
4	B	-
3	Y	-
2	GR	-
1	O	-

F51		
Connector No.	A/T ASSEMBLY	
Connector Name	TRANSMISSION CONTROL MODULE	
Connector Type	SP10FG	
		
Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

F102		
Connector No.	E124	
Connector Name	WIRE TO WIRE	
Connector Type	TK38FW-DG/Y	
		
Terminal No.	Color of Wire	Signal Name [Specification]
5	W	-
4	G	-
3	B	-
2	Y	-
1	GR	-
10	R	-
9	LG	-
8	O	-
7	SHIELD	-
6	W	-
5	G	-
4	B	-
3	Y	-
2	GR	-
1	O	-

F101		
Connector No.	E123	
Connector Name	WIRE TO WIRE	
Connector Type	TH34FW-NH	
		
Terminal No.	Color of Wire	Signal Name [Specification]
3	R	CAN-H
8	BR	CAN-L

JCLWM1789GB

# AFS CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**

**[XENON TYPE]**


A B C D E F G H I J K L M N O P EXL

## ACTIVE AFS

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH

Connector No.	M6
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS1DFW-CS



Connector Type TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
SB	Y	-
47	R	-
48	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
28	GR	-
44	W	-
46	B	-
80	L	-
81	P	-
82	L	-
83	P	-

Connector No. M7  
Connector Name WIRE TO WIRE  
Connector Type TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
15	B	-
16	W	-
17	R	-
18	SHIELD	-
19	V	-
20	O	-
21	BR	-



Connector No. M16  
Connector Name AFS CONTROL UNIT  
Connector Type TH40FW-NH



AMDS-2 (+)  
AMDS-R  
PSV-L  
GND  
PSG-L  
PSG-R  
PS-L  
CAN-H  
CAN-L  
SMF-2 (+)  
SMF-1 (+)  
SMF-2 (-)  
SMI-2 (-)  
SMI-1 (-)

Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	G	-
3	B	-
4	W	-
5	R	-
6	SHIELD	-
7	Y	-
8	GR	-
9	LG	-
10	O	-
11	G	-
12	11	9
13	22	10
14	23	8
15	21	7
16	19	6
17	18	5
18	17	4
19	16	3
20	15	2
21	14	1

SML-2 (+)  
SML-2 (-)  
IGN  
PSG-R  
SW  
PSV-R  
HSV-R  
CAN-L  
HSG-R  
PS-R  
SMR-1 (-)  
SMR-2 (-)  
SMI-1 (+)

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	IGN
2	LG	PSG-R
3	GR	SW
4	Y	PSV-R
6	W	HSV-R
7	P	CAN-L
8	B	HSG-R
9	GR	PS-R
11	R	SMR-1 (-)
13	B	SMR-2 (-)
15	G	SMI-1 (+)
40	O	AMDS-L

JCLWM1790GB

# AFS CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**

**[XENON TYPE]**

## ACTIVE AFS

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M21	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
AFS OFF SWITCH	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
Connector Name			13	L	GND	3		
Connector Type			14	P	IGN	8	GR	
TK08FW-IV								

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M24	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
DATA LINK CONNECTOR	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
BD16FW			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M37	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
STEERING ANGLE SENSOR	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
TH08FW-NH			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M67	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
UNIFIED METER AND A/C AMP	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
TH32FW-NH			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M68	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
UNIFIED METER AND A/C AMP	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
TH40FW-NH			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M107	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
ECM (WITH VQ ENGINE)	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
RH44FGY-RZ6-R-HZ			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M116	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
WIRE TO WIRE	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
TK36BW-NS10			13	L	GND	3		
			14	P	IGN	8	GR	

Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M125	Y	-	6	L	CAN-H	1	LG	COMM (METER->AMP)
VEHCAN-HI	GR	-	12	P	CAN-L	2	GR	COMM (AMP->METER)
VEHCAN-LI			13	L	GND	3		
			14	P	IGN	8	GR	

JCLWM1791GB

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

A

B

C

D

E

F

G

H

I

J

K


EXL

M

N

O

P



JCLWM1792GB

# AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[XENON TYPE]

## Fail-Safe

INFOID:000000003846448

DTC	Fail-safe	AFS OFF indicator lamp	Cancellation
CAN COMM CIRCUIT [U1000]	<ul style="list-style-type: none"> <li>Right and left swivel motors stop at the position when DTC is detected.</li> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
CONTROL UNIT (CAN) [U1010]	<ul style="list-style-type: none"> <li>Right and left swivel motors stop at the position when DTC is detected.</li> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
SWIVEL ACTUATOR [RH, LH] [B2503, B2504]	<ul style="list-style-type: none"> <li>Right and left swivel motors stop at the position when DTC is detected.</li> <li>The signal, approximately 2 V decreased from the levelizer signal when DTC detected, is output.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
HI SEN UNUSUAL [RR] [B2514]	<ul style="list-style-type: none"> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	—	Ignition switch OFF
ST ANG SEN SIG [C0126]	<ul style="list-style-type: none"> <li>Right and left swivel motor swivel angle returns to 0° and fixed.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
SHIFT SIG [P, R] [B2516]	<ul style="list-style-type: none"> <li>Right and left swivel motor swivel angle returns to 0° and fixed.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
VEHICLE SPEED SIG [B2517]	<ul style="list-style-type: none"> <li>Right and left swivel motor swivel angle returns to 0° and fixed.</li> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	Blinks 1 second each.	Ignition switch OFF
LEVELIZER CALIB [B2519]	<ul style="list-style-type: none"> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	—	When the levelizer adjustment is completed.
ST ANGLE SEN CALIB [C0428]	<ul style="list-style-type: none"> <li>Right and left swivel motor swivel angle returns to 0° and fixed.</li> </ul>	Blinks 1 second each.	When the steering angle sensor neutral position registration is completed
ECU CIRC [B2521]	<ul style="list-style-type: none"> <li>Right and left swivel motors stop at the position when DTC is detected.</li> <li>Right and left aiming motors stop at the position when DTC is detected.</li> </ul>	Blinks 1 second each.	Ignition switch OFF

## DTC Inspection Priority Chart

INFOID:000000003846449

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

### NOTE:

- If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000.
- If DTC U1010 is displayed with other DTC, first perform the trouble diagnosis for DTC U1010.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>• U1000 CAN COMM CIRCUIT</li> <li>• U1010 CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• B2519 LEVELELIZER CALIB</li> <li>• B2521 ECU CIRC</li> <li>• C0428 ST ANG SEN CALIB</li> </ul>
3	<ul style="list-style-type: none"> <li>• B2503 SWIVEL ACTUATOR [RH]</li> <li>• B2504 SWIVEL ACTUATOR [LH]</li> <li>• B2514 HI SEN UNUSUAL [RR]</li> <li>• B2516 SHIFT SIG [P, R]</li> <li>• B2517 VEHICLE SPEED SIG</li> <li>• C0126 ST ANG SEN SIG</li> </ul>

# AFS CONTROL UNIT

[XENON TYPE]

< ECU DIAGNOSIS INFORMATION >

## DTC Index

INFOID:000000003846450

x: Applicable

CONSULT indication	Fail-safe	AFS OFF indicator lamp	Reference
U1000: CAN COMM CIRCUIT	×	×	<a href="#">EXL-61, "Description"</a>
U1010: CONTROL UNIT (CAN)	×	×	<a href="#">EXL-62, "DTC Logic"</a>
B2503, B2504: SWIVEL ACTUATOR [RH, LH]	×	×	<a href="#">EXL-44, "Description"</a>
B2514: HI SEN UNUSUAL [RR]	×		<a href="#">EXL-50, "Description"</a>
B2516: SHIFT SIG [P, R]	×	×	<a href="#">EXL-53, "Description"</a>
B2517: VEHICLE SPEED SIG	×	×	<a href="#">EXL-54, "Description"</a>
B2519: LEVELIZER CALIB	×		<a href="#">EXL-55, "Description"</a>
B2521: ECU CIRC	×	×	<a href="#">EXL-56, "Description"</a>
C0126: ST ANG SEN SIG	×	×	<a href="#">EXL-59, "Description"</a>
C0428: ST ANGLE SEN CALIB	×	×	<a href="#">EXL-60, "Description"</a>

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

<SYMPTOM DIAGNOSIS>

[XENON TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000003846244

#### **CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> <li>Fuse</li> <li>Harness between IPDM E/R and the front combination lamp</li> <li>Front combination lamp (High beam solenoid)</li> <li>IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-67</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to <a href="#">EXL-192</a> .	
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		<ul style="list-style-type: none"> <li>Combination meter</li> <li>Unified meter and A/C amp.</li> </ul>	<ul style="list-style-type: none"> <li>Unified meter and A/C amp.</li> <li>Data monitor "HI-BEAM IND"</li> <li>BCM (HEAD LAMP) Active test "HEADLAMP"</li> </ul>
Headlamp does not switch to the low beam.	One side	Front combination lamp (High beam solenoid)	—
	Both sides	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between the combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-80</a> .
		High beam request signal	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>Fuse</li> <li>Xenon bulb</li> <li>Harness between IPDM E/R and the front combination lamp</li> <li>Front combination lamp (xenon headlamp)</li> <li>IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-70</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-193</a> .	
Headlamp is not turned OFF.	When the ignition switch is turned ON	IPDM E/R	—
	The ignition switch is turned OFF (After activating the battery saver.)	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between the combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-80</a> .
Headlamp is not turned ON/OFF with the lighting switch AUTO.		<ul style="list-style-type: none"> <li>Optical sensor</li> <li>Harness between the optical sensor and BCM</li> <li>BCM</li> </ul>	Optical sensor Refer to <a href="#">EXL-83</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between IPDM E/R and the front fog lamp</li> <li>• IPDM E/R</li> </ul>
	Both side	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-195</a> .
Front fog lamp is not turned ON.		
Front fog lamp indicator lamp is not turned ON. (Front fog lamp is turned ON.)		<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Unified meter and A/C amp.</li> </ul>
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp</li> <li>• IPDM E/R</li> </ul>
Tail lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• Rear combination lamp</li> </ul>
License plate lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Harness between IPDM E/R and the license plate lamp</li> <li>• License plate lamp</li> </ul>
Tail lamp and license plate lamp are not turned ON.		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• IPDM E/R</li> </ul>
<ul style="list-style-type: none"> <li>• Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned ON.</li> <li>• Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned OFF. (Each illumination is turned ON/OFF.)</li> </ul>	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-194</a> .	
Tail lamp indicator lamp is not turned ON. (Parking and tail lamps are turned ON.)		<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Unified meter and A/C amp.</li> </ul>
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul>
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>
Turn signal indicator lamp does not blink. (The turn signal indicator lamp is normal.)	One side	Combination meter
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>- Unified meter and A/C amp.</li> <li>- BCM</li> <li>• Combination meter</li> </ul>
	Both sides (Only when activating the hazard warning lamp with the ignition switch OFF.)	<ul style="list-style-type: none"> <li>• The combination meter power supply and the ground circuit</li> <li>• Combination meter</li> </ul>

## EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between the hazard switch and BCM</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-86</a> .
Headlamp auto aiming does not activate. (AFS is normal.)	<ul style="list-style-type: none"> <li>• Harness between AFS control unit and aiming motor</li> <li>• Front combination lamp (Aiming motor)</li> <li>• AFS control unit</li> </ul>	Headlamp levelizer circuit Refer to <a href="#">EXL-74</a> .
AFS OFF indicator lamp is not turned ON.	<ul style="list-style-type: none"> <li>• AFS OFF indicator lamp signal</li> <li>- Unified meter and A/C amp.</li> <li>- AFS control unit</li> <li>• Combination meter</li> </ul>	Unified meter and A/C amp. Data monitor "AFS OFF IND"

< SYMPTOM DIAGNOSIS >

## NORMAL OPERATING CONDITION

### Description

INFOID:000000003846245

#### XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area etc.) while using the auto light system. This causes for the control difference. This is normal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

### Description

INFOID:0000000003846246

The headlamp (both sides) does not switch to the high beam when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:0000000003846247

#### 1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-80, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		Except for HI or PASS	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3. HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-67](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:0000000003846248

The headlamps (both sides) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:0000000003846249

#### 1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-80, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-70](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:0000000003846250

The parking, side marker, license plate, tail lamps and each illumination are not turned ON in any condition.

### Diagnosis Procedure

INFOID:0000000003846251

#### 1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-80, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3. TAIL LAMP CIRCUIT INSPECTION

Check the tail lamp circuit. Refer to [EXL-88](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:0000000003846252

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:0000000003846253

#### 1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-80, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (Lighting switch 2ND)	ON	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3. FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-76](#).

Is the front fog lamp circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

&lt; PRECAUTION &gt;

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004068518

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precautions For Xenon Headlamp Service

INFOID:000000004115431

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

#### **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

&lt; PERIODIC MAINTENANCE &gt;

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:000000003846429

#### PREPARATION BEFORE ADJUSTING

**NOTE:**

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

**NOTE:**

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

**CAUTION:**

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.
- Headlamp aiming switch sets to "0". (with manual headlamp aiming control system.)

#### AIMING ADJUSTMENT SCREW



A Headlamp RH (UP/DOWN) adjustment screw   B. Headlamp LH (UP/DOWN) adjustment screw

←: Vehicle center

**NOTE:**

The figure is the vehicle without AFS. Each adjustment screw is applied to the vehicle with AFS.

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	UP
		Counterclockwise	DOWN
B	Headlamp LH (UP/DOWN)	Clockwise	UP
		Counterclockwise	DOWN

## Aiming Adjustment Procedure

INFOID:000000003846430

1. Place the screen.

**NOTE:**

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.

3. Start the engine. Turn the headlamp (LO) ON.

**NOTE:**

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.


**CAUTION:**

Never cover the lens surface with a tape etc. The lens is made of resin.

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

**Light axis measurement range (R) :  $350 \pm 175$  mm (13.78 ± 6.89 in)**

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



**Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)**

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:0000000003846431

#### PREPARATION BEFORE ADJUSTING

**NOTE:**

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

**NOTE:**

- Do not remove the temporary tire, jack and on-vehicle tool.
- Wipe out dirt on the headlamp.

**CAUTION:**

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: UP

B: DOWN

- For the position and direction of the adjusting screw, refer to the figure.

**NOTE:**

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



JPMIA1100ZZ

### Aiming Adjustment Procedure

INFOID:0000000003846432

1. Place the screen.

**NOTE:**

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Turn the front fog lamp ON.

**NOTE:**

Shut off the front fog lamp light with the board to prevent from illuminating the adjustment screen.

**CAUTION:**

**Never cover the lens surface with a tape etc. The lens is made of resin.**

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 200 mm (7.87 in).

EXL

M

N

O


P

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Front fog lamp light distribution on the screen



JPLIA0008ZZ

A : Cutoff line

B : High illuminance area

H : Horizontal center line of front fog lamp

V : Vertical center line of front fog lamp

X : Cutoff line height

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REMOVAL AND INSTALLATION FRONT COMBINATION LAMP

### Exploded View

INFOID:000000003846260


### REMOVAL



1. Front combination lamp

### DISASSEMBLY

Without AFS



- |                                       |                                       |                                |
|---------------------------------------|---------------------------------------|--------------------------------|
| 1. Front side marker lamp bulb        | 2. Front side marker lamp bulb socket | 3. Front turn signal lamp bulb |
| 4. Front turn signal lamp bulb socket | 5. Parking lamp bulb                  | 6. Parking lamp bulb socket    |
| 7. Resin cap                          | 8. Seal packing                       | 9. Xenon bulb socket           |
| 10. Xenon bulb                        | 11. Bumper bracket                    | 12. Seal packing               |
| 13. HID control unit                  | 14. Headlamp housing assembly         | 15. Retaining spring           |


Refer to [GI-4, "Components"](#) for symbols not described above.

With AFS

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]



- |                                       |                                       |                                |
|---------------------------------------|---------------------------------------|--------------------------------|
| 1. Front side marker lamp bulb        | 2. Front side marker lamp bulb socket | 3. Front turn signal lamp bulb |
| 4. Front turn signal lamp bulb socket | 5. Parking lamp bulb                  | 6. Parking lamp bulb socket    |
| 7. Resin cap                          | 8. Seal packing                       | 9. Xenon bulb socket           |
| 10. Xenon bulb                        | 11. Bumper bracket                    | 12. Seal packing               |
| 13. HID control unit                  | 14. Headlamp housing assembly         | 15. Retaining spring           |

Refer to [GI-4, "Components"](#) for symbols not described above.

INFOID:0000000003846261


## Removal and Installation

### REMOVAL

#### CAUTION:

**Disconnect the battery negative terminal or remove the fuse.**

1. Remove the front bumper fascia. Refer to [EXT-12, "Exploded View"](#).
2. Remove the headlamp mounting bolts.
3. Remove the holding clip (A)\* and the harness clip (B).  
\*: Left side only
4. Pull out the headlamp assembly forward the vehicle.
5. Disconnect the connector before removing the headlamp assembly.



### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-197, "Description"](#).

### Replacement

INFOID:0000000003846262

#### CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**

# FRONT COMBINATION LAMP

[XENON TYPE]

## < REMOVAL AND INSTALLATION >


- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### HEADLAMP BULB

1. Remove the engine room cover\*. Refer to [EM-174, "Exploded View"](#).  
\* : VK Engine Models
2. Remove the fender rubber protector. Keep a service area.
3. Rotate the resin cap counterclockwise and unlock it.
4. Rotate the bulb socket counterclockwise and unlock it.
5. Remove the retaining spring lock. Remove the bulb from the headlamp.

#### CAUTION:

Never break the xenon bulb ceramic tube when replacing the bulb.



### PARKING LAMP BULB

1. Remove the engine room cover\*. Refer to [EM-174, "Exploded View"](#).  
\* : VK Engine Models
2. Remove the fender rubber protector. Keep a service area.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Remove the bulb from the bulb socket.

### FRONT TURN SIGNAL LAMP BULB

1. Remove the engine room cover\*. Refer to [EM-174, "Exploded View"](#).  
\* : VK Engine Models
2. Remove the fender rubber protector. Keep a service area.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Remove the bulb from the bulb socket.

### FRONT SIDE MARKER LAMP BULB

1. Remove the engine room cover\*. Refer to [EM-174, "Exploded View"](#).  
\* : VK Engine Models
2. Remove the fender rubber protector. Keep a service area.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Remove the bulb from the bulb socket.

## Disassembly and Assembly

INFOID:0000000003846263

### DISASSEMBLY

1. Rotate the resin cap counterclockwise and unlock it.
2. Rotate the xenon bulb socket counterclockwise and unlock it.
3. Remove the retaining spring lock. Remove the xenon bulb.
4. Remove the bumper bracket.
5. Remove the HID control unit installation screw.
6. Remove the screw. Disconnect the connector from HID control unit.
7. Pull out the xenon bulb socket from the headlamp housing assembly.
8. Rotate the parking lamp bulb socket counterclockwise and unlock it.
9. Remove the bulb from the parking lamp bulb socket.
10. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
11. Remove the bulb from the front turn signal lamp bulb socket.

## FRONT COMBINATION LAMP

[XENON TYPE]

### < REMOVAL AND INSTALLATION >

12. Rotate the front side marker lamp bulb socket counterclockwise and unlock it.
13. Remove the bulb from the front side marker lamp bulb socket.

### ASSEMBLY

Assemble in the reverse order of disassembly.

#### CAUTION:

- Install HID control unit securely.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.

# FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## FRONT FOG LAMP

### Exploded View

INFOID:0000000003846433



1. Front fog lamp
2. Front fog lamp finisher

○ : Pawl

### Removal and Installation

INFOID:0000000003846434

#### CAUTION:

Disconnect the battery negative terminal or remove the fuse.

#### REMOVAL

1. Remove the front fender protector. Keep a service area. Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
2. Remove the front fog lamp connector.
3. Remove the screw.
4. Disengage the pawl. And then remove the front fog lamp.

#### INSTALLATION

Installation is the reverse order of removal.

#### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-199, "Description"](#)

### Replacement

INFOID:0000000003846435

#### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### FRONT FOG LAMP BULB


1. Remove the front fender protector. Keep a service area. Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).

## FRONT FOG LAMP

[XENON TYPE]

### < REMOVAL AND INSTALLATION >

2. Remove the front fog lamp bulb connector (1).
3. Rotate the bulb (2) counterclockwise and unlock it.



JPMIA1107ZZ

# OPTICAL SENSOR


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## OPTICAL SENSOR

### Exploded View

INFOID:0000000003846265



1. Optical sensor

### Removal and Installation

INFOID:0000000003846266

#### REMOVAL

1. Insert an appropriate tool between the optical sensor and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the connector. Remove the optical sensor.

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## LIGHTING & TURN SIGNAL SWITCH

### Exploded View

INFOID:000000003846267

The lighting & turn signal switch is integrated in the combination switch. [BCS-83, "Exploded View".](#)

# HEADLAMP AIMING SWITCH


[XENON TYPE]

< REMOVAL AND INSTALLATION >

## HEADLAMP AIMING SWITCH

### Exploded View

INFOID:0000000003887189



1. Headlamp aiming switch

A. Pawls

### Removal and Installation

INFOID:0000000003887190

#### REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-11, "Exploded View"](#).
2. Disengage the pawls. And then remove the headlamp aiming switch.

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## HAZARD SWITCH

### Exploded View

INFOID:000000003846268


The hazard switch is integrated in the multifunction switch. Refer to [AV-262, "Exploded View".](#)

< REMOVAL AND INSTALLATION >

### AFS CONTROL UNIT

#### Exploded View

INFOID:0000000003846269



1. AFS control unit

#### Removal and Installation

INFOID:0000000003846270

##### REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-11, "Exploded View"](#).
2. Remove the AFS control unit mounting bolt.
3. Disconnect the AFS control unit connector.
4. Remove the AFS control unit.

##### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

K  
EXL

M  
N  
O  
P

# STEERING ANGLE SENSOR

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## STEERING ANGLE SENSOR

### Removal and Installation

INFOID:000000003846271


Refer to [SR-8, "Removal and Installation".](#)

< REMOVAL AND INSTALLATION >

### AFS OFF SWITCH

#### Exploded View

INFOID:0000000003846272



JPMIA111ZZ

1. AFS OFF switch

A Pawls

#### Removal and Installation

INFOID:0000000003846273

##### REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-11, "Exploded View"](#).
2. Widen the pawls. And then remove the AFS OFF switch.

##### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# HEIGHT SENSOR


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## HEIGHT SENSOR

### Exploded View

INFOID:0000000003846274



JPMIA111ZZZ

1. Height sensor
- A Height sensor mounting nut
- B Height sensor lever link bracket mounting bolt

## Removal and Installation

INFOID:0000000003846275

### REMOVAL

1. Remove the height sensor mounting nut.
2. Remove the height sensor lever link bracket mounting bolt.
3. Disconnect the height sensor connector.
4. Remove the height sensor.

### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

Perform the levelizer adjustment when removing the height sensor. Refer to [EXL-7, "LEVELIZER ADJUSTMENT : Special Repair Requirement"](#).

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REAR COMBINATION LAMP

### Exploded View


INFOID:0000000003846276

### REMOVAL



1. Rear combination lamp
2. Rear combination lamp lower finisher
3. Rear combination lamp upper finisher

### DISASSEMBLY



1. Rear turn signal lamp bulb
2. Rear turn signal lamp bulb socket
3. Rear side marker lamp bulb socket
4. Rear side marker lamp bulb

### Removal and Installation

INFOID:0000000003846277

#### CAUTION:

Disconnect the battery negative terminal or remove the fuse.

### REMOVAL

1. Remove the rear combination lamp lower and upper finisher.
2. Remove the rear combination lamp mounting bolts.
3. Disconnect the rear combination lamp connector.
4. Pull the rear combination lamp toward outside of the vehicle. Remove the rear combination lamp.

### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## Replacement

INFOID:000000003846278

### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### STOP/TAIL LAMP

Replacement integral with rear combination lamp assembly. Refer to [EXL-215, "Exploded View"](#).

### REAR SIDE MARKER LAMP BULB

1. Remove the rear combination lamp. Refer to [EXL-215, "Exploded View"](#).
2. Rotate the rear side marker lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb from the rear side marker lamp bulb socket.

### REAR TURN SIGNAL LAMP BULB

1. Remove the rear combination lamp. Refer to [EXL-215, "Exploded View"](#).
2. Rotate the rear turn signal lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb from the rear turn signal lamp bulb socket.

# HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## HIGH-MOUNTED STOP LAMP

### Exploded View

INFOID:0000000003846279



JPMIA1115ZZ

1. Seal packing
2. High-mounted stop lamp

Refer to [GI-4. "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:0000000003846280

#### REMOVAL

1. Remove the back door plate. Refer to [INT-32. "Exploded View"](#).
2. Remove the high-mounted stop lamp mounting nuts.
3. Disconnect the high-mounted stop lamp connector.
4. Pull the high-mounted stop lamp toward rear of the vehicle. Remove the high-mounted stop lamp.

#### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

**Seal packing cannot be reused.**

EXL

M

N

O

P

# BACK-UP LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## BACK-UP LAMP

### Exploded View

INFOID:0000000003846283



1. Seal packing
2. Back-up lamp

Refer to [GI-4, "Components"](#) for symbols in the figure.

JPMIA1116ZZ

### Removal and Installation

INFOID:0000000003846284

#### CAUTION:

**Disconnect the battery negative terminal or remove the fuse.**

#### REMOVAL

1. Remove the back door finisher inner. Refer to [INT-32, "Exploded View"](#).
2. Remove the back-up lamp mounting nuts.
3. Disconnect the back-up lamp connector. And then remove the back-up lamp.

#### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

**Seal packing cannot be reused.**

### Replacement

INFOID:0000000003846285

#### CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

#### BACK-UP LAMP BULB


1. Remove the back door finisher inner. Refer to [INT-32, "Exploded View"](#).

## BACK-UP LAMP

[XENON TYPE]

### < REMOVAL AND INSTALLATION >

2. Rotate the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



A  
B  
C  
D

E

F

G

H

I

J

K

EXL

M

N

O

P

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## LICENSE PLATE LAMP

### Exploded View

INFOID:0000000003846286



1. License plate lamp

### Removal and Installation

INFOID:0000000003846287

#### CAUTION:

Disconnect the battery negative terminal or remove the fuse.

#### REMOVAL

1. Remove the door handle cover. Refer to [EXT-49, "Exploded View"](#).
2. Remove the screw. And then remove the license plate lamp.
3. Disconnect the license plate lamp connector.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement


INFOID:0000000003846288

#### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### LICENSE PLATE LAMP BULB

1. Remove the back door finisher inner. Refer to [INT-32, "Exploded View"](#).
2. Rotate the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000003846289

Item	Type	Wattage (W)
Front combination lamp	Headlamp (HI/LO)	D2S (Xenon)
	Front turn signal lamp	WY21W (Amber)
	Parking lamp	W5W
	Front side marker lamp	W5W
Front fog lamp	H8	35
Rear combination lamp	Stop lamp/Tail lamp	LED
	Rear turn signal lamp	W21W
	Rear side marker lamp	W5W
Back-up lamp	W21W	21
License plate lamp	W5W	5
High-mounted stop lamp	LED	—

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P