

# MWI

## SECTION

### METER, WARNING LAMP & INDICATOR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

## CONTENTS

<p><b>BASIC INSPECTION</b> ..... 4</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> ..... 4</p> <p style="padding-left: 20px;">Work flow .....4</p> <p><b>SYSTEM DESCRIPTION</b> ..... 6</p> <p><b>METER SYSTEM</b> ..... 6</p> <p><b>METER SYSTEM</b> .....6</p> <p style="padding-left: 20px;">METER SYSTEM : System Diagram .....6</p> <p style="padding-left: 20px;">METER SYSTEM : System Description .....6</p> <p style="padding-left: 20px;">METER SYSTEM : Component Parts Location ..... 10</p> <p style="padding-left: 20px;">METER SYSTEM : Component Description ..... 11</p> <p><b>SPEEDOMETER</b> ..... 12</p> <p style="padding-left: 20px;">SPEEDOMETER : System Diagram ..... 12</p> <p style="padding-left: 20px;">SPEEDOMETER : System Description ..... 12</p> <p style="padding-left: 20px;">SPEEDOMETER : Component Parts Location ..... 13</p> <p style="padding-left: 20px;">SPEEDOMETER : Component Description ..... 14</p> <p><b>TACHOMETER</b> ..... 14</p> <p style="padding-left: 20px;">TACHOMETER : System Diagram ..... 14</p> <p style="padding-left: 20px;">TACHOMETER : System Description ..... 14</p> <p style="padding-left: 20px;">TACHOMETER : Component Parts Location ..... 15</p> <p style="padding-left: 20px;">TACHOMETER : Component Description ..... 16</p> <p><b>ENGINE COOLANT TEMPERATURE GAUGE</b> ..... 16</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : System Diagram ..... 16</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : System Description ..... 16</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location ..... 17</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : Component Description ..... 18</p> <p><b>FUEL GAUGE</b> ..... 18</p> <p style="padding-left: 20px;">FUEL GAUGE : System Diagram ..... 18</p> <p style="padding-left: 20px;">FUEL GAUGE : System Description ..... 18</p> <p style="padding-left: 20px;">FUEL GAUGE : Component Parts Location ..... 19</p> <p style="padding-left: 20px;">FUEL GAUGE : Component Description ..... 20</p>	<p><b>ODO/TRIP METER</b> .....20</p> <p style="padding-left: 20px;">ODO/TRIP METER : System Diagram .....20</p> <p style="padding-left: 20px;">ODO/TRIP METER : System Description .....20</p> <p style="padding-left: 20px;">ODO/TRIP METER : Component Parts Location .....21</p> <p style="padding-left: 20px;">ODO/TRIP METER : Component Description .....22</p> <p><b>SHIFT POSITION INDICATOR</b> .....22</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : System Diagram...22</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : System Description .....22</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : Component Parts Location .....24</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : Component De- scription .....25</p> <p><b>WARNING LAMPS/INDICATOR LAMPS</b> .....25</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : System Diagram .....25</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : System Description .....25</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : Com- ponent Parts Location .....26</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : Com- ponent Description .....27</p> <p><b>METER ILLUMINATION CONTROL</b> .....27</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : System Di- agram .....27</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : System De- scription .....27</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : Component Parts Location .....29</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : Component Description .....30</p> <p><b>METER EFFECT FUNCTION</b> .....30</p> <p style="padding-left: 20px;">METER EFFECT FUNCTION : System Diagram....30</p> <p style="padding-left: 20px;">METER EFFECT FUNCTION : System Description .....30</p> <p style="padding-left: 20px;">METER EFFECT FUNCTION : Component Parts Location .....32</p>
--	---

MWI

METER EFFECT FUNCTION : Component Description .....	33	<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>58</b>
<b>INFORMATION DISPLAY .....</b>	<b>33</b>	<b>COMBINATION METER .....</b>	<b>58</b>
INFORMATION DISPLAY : System Diagram .....	33	COMBINATION METER : Diagnosis Procedure ....	58
INFORMATION DISPLAY : System Description ...	33	<b>UNIFIED METER AND A/C AMP. ....</b>	<b>58</b>
INFORMATION DISPLAY : Component Parts Location .....	37	UNIFIED METER AND A/C AMP. : Diagnosis Procedure .....	58
INFORMATION DISPLAY : Component Description .....	38	<b>BCM (BODY CONTROL MODULE) .....</b>	<b>59</b>
<b>COMPASS .....</b>	<b>39</b>	BCM (BODY CONTROL MODULE) : Diagnosis Procedure .....	59
Description .....	39	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	<b>60</b>
Component Parts Location .....	41	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	60
Special Repair Requirement .....	41	<b>FUEL LEVEL SENSOR SIGNAL CIRCUIT .....</b>	<b>62</b>
<b>CLOCK .....</b>	<b>42</b>	Description .....	62
Component Parts Location .....	42	Component Function Check .....	62
<b>DIAGNOSIS SYSTEM (METER) .....</b>	<b>43</b>	Diagnosis Procedure .....	62
Diagnosis Description .....	43	Component Inspection .....	63
<b>DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.) .....</b>	<b>45</b>	<b>METER CONTROL SWITCH SIGNAL CIRCUIT .....</b>	<b>65</b>
CONSULT-III Function (METER/M&A) .....	45	Description .....	65
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>49</b>	Diagnosis Procedure .....	65
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>49</b>	Component Inspection .....	66
Description .....	49	<b>TRIP A/B RESET SWITCH SIGNAL CIRCUIT..</b>	<b>67</b>
DTC Logic .....	49	Description .....	67
Diagnosis Procedure .....	49	Diagnosis Procedure .....	67
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>50</b>	Component Inspection .....	67
Description .....	50	<b>OIL PRESSURE SWITCH SIGNAL CIRCUIT ...</b>	<b>69</b>
DTC Logic .....	50	Description .....	69
Diagnosis Procedure .....	50	Component Function Check .....	69
<b>B2201 COMMUNICATION ERROR 1 .....</b>	<b>51</b>	Diagnosis Procedure .....	69
Description .....	51	Component Inspection .....	69
DTC Logic .....	51	<b>PARKING BRAKE SWITCH SIGNAL CIRCUIT .....</b>	<b>70</b>
Diagnosis Procedure .....	51	Description .....	70
<b>B2202 COMMUNICATION ERROR 2 .....</b>	<b>53</b>	Diagnosis Procedure .....	70
Description .....	53	Component Inspection .....	70
DTC Logic .....	53	<b>WASHER LEVEL SWITCH SIGNAL CIRCUIT..</b>	<b>72</b>
Diagnosis Procedure .....	53	Description .....	72
<b>B2205 VEHICLE SPEED .....</b>	<b>55</b>	Diagnosis Procedure .....	72
Description .....	55	Component Inspection .....	72
DTC Logic .....	55	<b>COMPASS .....</b>	<b>73</b>
Diagnosis Procedure .....	55	Wiring Diagram - COMPASS - .....	73
<b>B2267 ENGINE SPEED .....</b>	<b>56</b>	<b>CLOCK .....</b>	<b>75</b>
Description .....	56	Wiring Diagram - CLOCK - .....	75
DTC Logic .....	56	<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>77</b>
Diagnosis Procedure .....	56	<b>COMBINATION METER .....</b>	<b>77</b>
<b>B2268 WATER TEMP .....</b>	<b>57</b>		
Description .....	57		
DTC Logic .....	57		
Diagnosis Procedure .....	57		

Reference Value .....	77	<b>THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY</b> .....	169	A
Wiring Diagram - METER - .....	80	Description .....	169	
Fail-Safe .....	91	Diagnosis Procedure .....	169	B
DTC Index .....	92	<b>THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY</b> .....	170	C
<b>UNIFIED METER AND A/C AMP.</b> .....	93	Description .....	170	
Reference Value .....	93	Diagnosis Procedure .....	170	
Wiring Diagram - METER - .....	100	<b>THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT</b> .....	171	D
Fail-Safe .....	111	Description .....	171	
DTC Index .....	112	Diagnosis Procedure .....	171	E
<b>BCM (BODY CONTROL MODULE)</b> .....	114	<b>NORMAL OPERATING CONDITION</b> .....	172	
Reference Value .....	114	<b>COMPASS</b> .....	172	F
Wiring Diagram - BCM - .....	138	COMPASS : Description .....	172	
Fail-safe .....	144	<b>INFORMATION DISPLAY</b> .....	172	G
DTC Inspection Priority Chart .....	147	INFORMATION DISPLAY : Description .....	172	
DTC Index .....	147	<b>PRECAUTION</b> .....	173	
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	150	<b>PRECAUTIONS</b> .....	173	H
Reference Value .....	150	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	173	I
Wiring Diagram - IPDM E/R - .....	157	<b>REMOVAL AND INSTALLATION</b> .....	174	
Fail-safe .....	160	<b>COMBINATION METER</b> .....	174	J
DTC Index .....	162	Exploded View .....	174	
<b>SYMPTOM DIAGNOSIS</b> .....	163	Removal and Installation .....	174	
<b>THE FUEL GAUGE POINTER DOES NOT MOVE</b> .....	163	Disassembly and Assembly .....	174	K
Description .....	163	<b>UNIFIED METER AND A/C AMP.</b> .....	175	
Diagnosis Procedure .....	163	Exploded View .....	175	L
<b>THE METER CONTROL SWITCH IS INOPERATIVE</b> .....	164	Removal and Installation .....	175	
Description .....	164	<b>METER CONTROL SWITCH</b> .....	176	M
Diagnosis Procedure .....	164	Exploded View .....	176	
<b>THE TRIP A/B RESET SWITCH IS INOPERATIVE</b> .....	165	Removal and Installation .....	176	
Description .....	165	<b>TRIP A/B RESET SWITCH</b> .....	177	MWI
Diagnosis Procedure .....	165	Exploded View .....	177	
<b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON</b> .....	166	Removal and Installation .....	177	
Description .....	166	<b>COMPASS</b> .....	178	O
Diagnosis Procedure .....	166	Exploded View .....	178	
<b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF</b> .....	167	Removal and Installation .....	178	
Description .....	167	<b>CLOCK</b> .....	179	P
Diagnosis Procedure .....	167	Exploded View .....	179	
<b>THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY</b> .....	168	Removal and Installation .....	179	
Description .....	168			
Diagnosis Procedure .....	168			

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work flow

INFOID:000000003887041

#### OVERALL SEQUENCE



- Reference 1...[MWI-43, "Diagnosis Description"](#).
- Reference 2...[MWI-112, "DTC Index"](#).
- Reference 3...[MWI-58, "COMBINATION METER : Diagnosis Procedure"](#).

#### DETAILED FLOW

##### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

##### 2.CHECK SYMPTOM

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

---

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

## 3.CHECK ON BOARD DIAGNOSIS OPERATION

---

Check that the on board diagnosis function operates. Refer to [MWI-43, "Diagnosis Description"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

## 4.CHECK CONSULT-III SELF-DIAGNOSIS RESULTS

---

Connect CONSULT-III and perform self-diagnosis. Refer to [MWI-45, "CONSULT-III Function \(METER/M&A\)"](#).

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> GO TO 8.

## 5.NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

---

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 7.

## 6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

---

Inspect combination meter power supply and ground circuits. Refer to [MWI-58, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 8.

## 7.REPLACE COMBINATION METER

---

Replace combination meter.

>> GO TO 9.

## 8.REPAIR OR REPLACE MALFUNCTIONING PARTS

---

Repair or replace the malfunctioning parts.

### **NOTE:**

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 9.

## 9.FINAL CHECK

---

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# METER SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### METER SYSTEM

### METER SYSTEM

### METER SYSTEM : System Diagram

INFOID:000000003887042



### METER SYSTEM : System Description

INFOID:000000003887043

#### COMBINATION METER

- The combination meter retrieves the information required for controlling the operations of the meters, indicator lamps/warning lamps and information display from the communication signals from the unified meter and A/C amp. and the signals from various switches and sensors.
- The combination meter incorporates a trip computer that displays warnings and messages on the information display according to the information received from various units.
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter integrates the meter circuit check function and the segment check function that checks the information display operation.

#### UNIFIED METER AND A/C AMP.

- Receives information required by the combination meter from various units via CAN communication line and transmits it to the combination meter with communication line.
- The unified meter and A/C amp. incorporates a power saving control function that reduces the power consumption according to the vehicle status. Refer to [BCS-13. "System Description"](#) for details.
- The unified meter and A/C amp. incorporates a diagnosis function that allows the technician to perform diagnoses with CONSULT-III.

# METER SYSTEM

## < SYSTEM DESCRIPTION >

Between unified meter and A/C amp. and combination meter.			
Unit	Communication line	Input from combination meter	Output to combination meter
Unified meter and A/C amp.	Communication line (METER <-> AMP.)	<ul style="list-style-type: none"> <li>• Parking brake switch signal</li> <li>• Washer level switch signal</li> <li>• Meter day/night condition signal</li> <li>• Illumination control switch signal</li> <li>• Refuel status signal</li> <li>• Low fuel warning lamp signal</li> <li>• Odo data signal</li> </ul>	<ul style="list-style-type: none"> <li>• Vehicle speed signal</li> <li>• Turn indicator signal</li> <li>• High beam request signal</li> <li>• Position light request signal</li> <li>• Engine speed signal</li> <li>• Fuel level sensor signal</li> <li>• Engine coolant temperature signal</li> <li>• A/T CHECK indicator signal</li> <li>• Oil pressure switch signal</li> <li>• Door switch signal</li> <li>• Buzzer output signal</li> <li>• Key warning lamp signal</li> <li>• AFS OFF indicator lamp signal</li> <li>• Tire pressure signal</li> <li>• AWD warning lamp signal</li> <li>• VDC OFF indicator lamp signal</li> <li>• SLIP indicator lamp signal</li> <li>• IBA OFF indicator lamp signal</li> <li>• ABS warning lamp signal</li> <li>• Brake warning lamp signal</li> <li>• Malfunction indicator lamp signal</li> <li>• Master warning signal</li> <li>• ICC warning lamp signal</li> <li>• Lane departure warning lamp signal</li> <li>• LDP ON indicator lamp signal</li> <li>• RAS warning lamp signal</li> <li>• Sports mode indicator lamp signal</li> <li>• Meter effect signal</li> <li>• Meter ring illumination request signal</li> </ul>
	Communication line (LCD <-> AMP.)	<ul style="list-style-type: none"> <li>• Average fuel consumption reset signal</li> <li>• Travel time reset signal</li> <li>• Possible driving distance reset signal</li> <li>• Average vehicle speed reset signal</li> <li>• Select switch signal</li> <li>• Enter switch signal</li> <li>• Trip A/B reset switch signal</li> <li>• Ambient air temperature display signal</li> </ul>	<ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Meter display signal</li> <li>• Door switch signal</li> <li>• Fuel level sensor signal</li> <li>• Parking brake switch signal</li> <li>• Washer level switch signal</li> <li>• Charge warning signal</li> <li>• Instantaneous fuel consumption display signal</li> <li>• Ambient air temperature display signal</li> <li>• Average fuel consumption display signal</li> <li>• Average vehicle speed display signal</li> <li>• Possible driving distance display signal</li> <li>• Engine speed signal</li> <li>• Vehicle speed signal</li> <li>• Meter effect signal</li> </ul>

### IPDM E/R

- IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
- IPDM E/R is equipped with the diagnosis function. It can perform the operation check of oil pressure warning lamp with the auto active test and the diagnosis with CONSULT-III.

### METER CONTROL FUNCTION LIST

# METER SYSTEM

## < SYSTEM DESCRIPTION >


X: Applicable

System		Description	Signal source	Via unified meter and A/C amp.
Meter/gauge	Speedometer	Receives vehicle speed signal and indicates vehicle speed.	ABS actuator and electric unit (control unit)	X
	Tachometer	Receives engine speed signal and indicates engine speed.	ECM	X
	Fuel gauge	Receives fuel level sensor signal and indicates fuel level.	Fuel level sensor unit	X
	Engine coolant temperature gauge	Receives engine coolant temperature signal and indicates coolant temperature.	ECM	X
Warning lamp/indicator lamp	Oil pressure warning lamp	Receives oil pressure warning lamp signal and illuminates warning lamp.	IPDM E/R	X
	Master warning	Illuminates according to warning output on information display.	—	X
Information display	Parking brake release warning	Receives parking brake switch signal and vehicle speed signal and displays warnings.	Parking brake switch	
			ABS actuator and electric unit (control unit)	X
	Low fuel warning	Receives fuel gauge signal and displays warning if fuel level decreases to 14 ℓ (3 - 5/7 US gal, 3 - 1/10 Imp gal) or less.	Fuel level sensor unit	X
	Low washer fluid warning	Receives washer level switch signal and displays warning.	Washer level switch	
	Low outside temperature warning	Monitors ambient sensor signal and displays warning if ambient temperature decreases to 3°C (37°F) or less. (If enabled)	Ambient sensor	X
	Door open warning	Receives door switch signals and displays warning.	BCM	X
	Instantaneous fuel consumption	Calculates instantaneous fuel consumption based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X
			ABS actuator and electric unit (control unit)	X
	Average fuel consumption	Calculates average fuel consumption in a reset-to-reset interval based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X
			ABS actuator and electric unit (control unit)	X
	Average vehicle speed	Calculates average vehicle speed in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X
	Travel time	Displays accumulated key switch ON time from reset to reset.	—	X
	Travel distance	Calculates accumulated travel distance in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X
	Possible driving distance	Calculates possible driving distance based on received fuel consumption monitor signal, vehicle speed signals and fuel level sensor signal and displays it.	ECM	X
ABS actuator and electric unit (control unit)			X	
Fuel level sensor unit			X	
Ambient air temperature	Corrects ambient air temperature value based on received ambient sensor signals and displays it.	Ambient sensor	X	

## ARRANGEMENT OF COMBINATION METER

# METER SYSTEM

## < SYSTEM DESCRIPTION >



A. VK50VE engine models

B. VQ35HR engine models

C. For U.S.A.

D. Except for U.S.A.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## METER SYSTEM : Component Parts Location

INFOID:000000003887044



# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |   |
|--|---|-------------------------------|---|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   | A |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             | B |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. | C |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |   |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |   |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          | D |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       | E |

## METER SYSTEM : Component Description

INFOID:000000003887045


Unit	Description
Combination meter	Controls the following with the signals from the unified meter and A/C amp, switches and sensors. <ul style="list-style-type: none"> <li>• Speedometer</li> <li>• Engine coolant temperature gauge</li> <li>• Warning lamps</li> <li>• Information display</li> <li>• Tachometer</li> <li>• Fuel gauge</li> <li>• Indicator lamps</li> </ul>
Unified meter and A/C amp.	<ul style="list-style-type: none"> <li>• The combination meter receives the necessary information from various units via CAN communication line and transmits them to the unified meter and A/C amp. with the communication line that connects both of them.</li> <li>• Transmits the fuel gauge signal from the fuel gauge unit with the communication line that connects the unified meter and A/C amp. and the combination meter.</li> <li>• Reads the signals from the A/T shift selector and paddle shifter transmits them to TCM with CAN communication line.</li> </ul>
IPDM E/R	IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with CAN communication line.
Fuel level sensor unit	Refer to <a href="#">MWI-62, "Description"</a> .
Oil pressure switch	Refer to <a href="#">MWI-69, "Description"</a> .
ECM	Transmits the following signals to the unified meter and A/C amp. with CAN communication line. <ul style="list-style-type: none"> <li>• Engine speed signal</li> <li>• Fuel consumption monitor signal</li> <li>• Engine coolant temperature signal</li> </ul>
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
BCM	<ul style="list-style-type: none"> <li>• Transmits signals provided by various units to the unified meter and A/C amp. with CAN communication line.</li> <li>• Transmits the security signal to the combination meter.</li> </ul>
A/T shift selector	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> <li>• Manual mode signal</li> <li>• Manual mode shift up signal</li> <li>• Not manual mode signal</li> <li>• Manual mode shift down signal</li> </ul>
Paddle shifter	Transmits the paddle shifter up signal and paddle shifter down signal to the unified meter and A/C amp.
TCM	Transmits shift position signal to the unified meter and A/C amp.
Meter control switch	Refer to <a href="#">MWI-65, "Description"</a> .
Trip A/B reset switch	Refer to <a href="#">MWI-67, "Description"</a> .
Washer level switch	Transmits the washer level signal to the combination meter.
Parking brake switch	Refer to <a href="#">MWI-70, "Description"</a> .

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SPEEDOMETER

### SPEEDOMETER : System Diagram



### SPEEDOMETER : System Description

INFOID:000000003887047


- The ABS actuator and electric unit (control unit) converts the pulse signal provided by the wheel sensor to a vehicle speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line and transmits it to the combination meter by means of communication line.
- The combination meter indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SPEEDOMETER : Component Parts Location

INFOID:000000003887048



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## SPEEDOMETER : Component Description


INFOID:000000003887049

Unit	Description
Combination meter	Indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line to the combination meter by means of communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

## TACHOMETER

### TACHOMETER : System Diagram

INFOID:000000003887050



### TACHOMETER : System Description

INFOID:000000003887051


- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the engine speed signal from ECM with CAN communication line and transmits it to the combination meter by means of communication line.
- Combination meter converses engine speed signal to the angle signal, and commands to tachometer.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## TACHOMETER : Component Parts Location

INFOID:000000003887052



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## TACHOMETER : Component Description


INFOID:000000003887053

Unit	Description
Combination meter	Indicates the engine speed according to the engine speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine speed signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine speed signal to the unified meter and A/C amp. with CAN communication line.

## ENGINE COOLANT TEMPERATURE GAUGE

### ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:000000003887054



### ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:000000003887055


- ECM converts a signal from engine coolant temperature sensor to engine coolant temperature signal, and transmits to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine coolant temperature signal to combination meter with communication line.
- Combination meter converts engine coolant temperature signal to the angle signal, and commands to engine coolant temperature gauge.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location

INFOID:000000003887056



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## ENGINE COOLANT TEMPERATURE GAUGE : Component Description


INFOID:000000003887057

Unit	Description
Combination meter	Indicates the engine coolant temperature gauge according to the engine coolant temperature signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine coolant temperature signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine coolant temperature signal to the unified meter and A/C amp. with CAN communication line.

## FUEL GAUGE

### FUEL GAUGE : System Diagram

INFOID:000000003887058



### FUEL GAUGE : System Description

INFOID:000000003887059

#### CONTROL OUTLINE

- The unified meter and A/C amp. reads the fuel level sensor signal from the fuel gauge unit and transmits it to the combination meter with the communication line.
- The combination meter indicates the fuel level on the fuel gauge according to the received fuel level sensor signal.

#### REFUEL CONTROL

The combination meter accelerates the fuel gauge segment if the all conditions listed below are met, or the ignition switch is ON from OFF.


- Ignition switch is ON position.
- The vehicle is not moving.
- The fuel level change by 15 ℓ (4 US gal, 3-3/10 Imp gal) or more.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## FUEL GAUGE : Component Parts Location

INFOID:000000003887060



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## FUEL GAUGE : Component Description


INFOID:000000003887061

Unit	Description
Combination meter	Indicates the fuel gauge according to the fuel level sensor signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the fuel level sensor signal from the fuel level sensor unit to the combination meter by means of communication line.
Fuel level sensor unit	Refer to <a href="#">MWI-62, "Description"</a> .

## ODO/TRIP METER

### ODO/TRIP METER : System Diagram

INFOID:000000003887062



### ODO/TRIP METER : System Description

INFOID:000000003887063


- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## ODO/TRIP METER : Component Parts Location

INFOID:000000003887064



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## ODO/TRIP METER : Component Description


INFOID:000000003887065

Unit	Description
Combination meter	The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.
Unified meter and A/C amp.	The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

## SHIFT POSITION INDICATOR

### SHIFT POSITION INDICATOR : System Diagram

INFOID:000000003887066



### SHIFT POSITION INDICATOR : System Description

INFOID:000000003928872

Shift position is displayed in the information display LCD in the combination meter.

#### MANUAL MODE

When Operated with A/T Shift Selector

- Unified meter and A/C amp. inputs manual mode signal and manual mode shift-up/down signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM processes manual mode signal and manual mode shift-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line.

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line. A
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal.

### When Operated with Paddle Shifter

- Unified meter and A/C amp. inputs manual mode signal from A/T shift selector (manual mode switch) or the paddle shifter-up/down signal from the paddle shifter. B
- Unified meter and A/C amp. transmits manual mode signal and manual mode shift-up/down signal to TCM with the CAN communication line. C
- TCM processes manual mode signal and manual mode shift-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line. D
- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line. D
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal. E

### NOT MANUAL MODE

- Unified meter and A/C amp. inputs not manual mode signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line. F
- TCM transmits shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits shift position signal to combination meter with the communication line.
- Combination meter indicates shift position when receiving shift position signal. G

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SHIFT POSITION INDICATOR : Component Parts Location

INFOID:00000003887068



JPNIA1104ZZ

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## SHIFT POSITION INDICATOR : Component Description


INFOID:000000003928873

Unit	Description
Combination meter	Displays the shift position on the information display with shift position signal and manual mode indicator signal received from unified meter and A/C amp.
Unified meter and A/C amp.	<ul style="list-style-type: none"> <li>Transmits the signals from the A/T shift selector and paddle shifter to TCM with CAN communication line.</li> <li>Transmits shift position signal and manual mode indicator signal received from TCM with CAN communication line to the combination meter by means of communication line.</li> </ul>
A/T shift selector	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> <li>Manual mode signal</li> <li>Manual mode shift up signal</li> <li>Not manual mode signal</li> <li>Manual mode shift down signal</li> </ul>
Paddle shifter	Transmits the paddle shifter up signal and paddle shifter down signal to the unified meter and A/C amp.
TCM	Transmits shift position signal and manual mode indicator signal to the unified meter and A/C amp.

## WARNING LAMPS/INDICATOR LAMPS

### WARNING LAMPS/INDICATOR LAMPS : System Diagram

INFOID:000000003887070



### WARNING LAMPS/INDICATOR LAMPS : System Description

INFOID:000000003887071

#### OIL PRESSURE WARNING LAMP


- IPDM E/R inputs oil pressure switch signal from oil pressure switch, and transmits the signal to unified meter and A/C amp. through BCM with CAN communication line.
- Unified meter and A/C amp. transmits oil pressure switch signal to combination meter with communication line.
- Let the combination meter turn oil pressure warning lamp ON with received oil pressure switch signal.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## WARNING LAMPS/INDICATOR LAMPS : Component Parts Location

INFOID:00000003887072



# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31. "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590. "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## WARNING LAMPS/INDICATOR LAMPS : Component Description


INFOID:000000003887073

Unit	Description
Combination meter	Turns the oil pressure warning lamp ON/OFF according to the oil pressure switch signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the oil pressure switch signal received from the IPDM E/R with BCM to the combination meter by means of communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals from the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
Oil pressure switch	Refer to <a href="#">MWI-69. "Description"</a> .
BCM	Transmits the oil pressure switch signal received from IPDM E/R via CAN communication to the unified meter and A/C amp. via CAN communication line.

## METER ILLUMINATION CONTROL

### METER ILLUMINATION CONTROL : System Diagram

INFOID:000000003887074



### METER ILLUMINATION CONTROL : System Description

INFOID:000000003887075

#### SYSTEM DESCRIPTION


The combination meter receives an illumination control switch signal from the meter control switch, and a position light request signal and a meter ring illumination request signal from BCM through the unified meter and A/C amp. to control meter illumination.

Daytime Mode

# METER SYSTEM

## < SYSTEM DESCRIPTION >

Meter illumination is adjusted to 5 steps by illumination control switch (1) in daytime mode.



### Nighttime Mode

- Combination meter is transferred to nighttime mode with position light request signal from BCM with CAN communication line.
- Meter illumination is adjusted to 22 steps by illumination control switch in nighttime.

### Driver Welcome Function

- BCM transmits a meter ring illumination request signal to the unified meter and A/C amp. through the CAN communication when the intelligent key is inside the vehicle and the door on the driver side is recognized as closed.
- The unified meter and A/C amp. receives a meter ring illumination request signal through the CAN communication and transmits the signal to the combination meter with communication line.
- The combination meter turns on meter ring illumination in stages by receiving a meter ring illumination request signal from the unified meter and A/C amp. through the communication line.

### **NOTE:**


Meter ring illumination turns off in stages after a set period of time.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## METER ILLUMINATION CONTROL : Component Parts Location

INFOID:000000003887076



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## METER ILLUMINATION CONTROL : Component Description


INFOID:000000003887077

Unit	Description
Combination meter	Controls the meter illumination with the illumination control switch signal from the meter control switch and the position light request signal and the meter ring illumination request signal from unified meter and A/C amp.
Unified meter and A/C amp.	Transmits the position light request signal and meter ring illumination request signal received from BCM via CAN communication to the combination meter by means of communication.
BCM	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> <li>• Position light request signal</li> <li>• Meter ring illumination request signal</li> </ul>
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>• Illumination control switch signal (+)</li> <li>• Illumination control switch signal (-)</li> </ul>

## METER EFFECT FUNCTION

### METER EFFECT FUNCTION : System Diagram

INFOID:000000003887239



### METER EFFECT FUNCTION : System Description

INFOID:000000003887240

#### SYSTEM DESCRIPTION

##### Engine-start Effect function

- The unified meter and A/C amp. receives an engine speed signal and engine status signal from ECM, a starter relay status signal from BCM, a shift position signal from TCM, a vehicle speed signal from ABS actu-

# METER SYSTEM

## < SYSTEM DESCRIPTION >

ator and electric unit (control unit) through the use of the CAN communication. After the end of cranking and recognition of engine revolution, the unified meter and A/C amp. transmits a meter effect signal to the combination meter through the communication line.

- Receiving a meter effect signal, the combination meter illuminates the meter light in stages and sweeps the needles of the speedometer and the tachometer.

**NOTE:**

The engine-start effect function enables ON/OFF with an operation of information display.

Cancel Conditions

- Meter effect is not performed during driving.
- Meter effect is not performed except when in P-range.

**NOTE:**

Meter effect is cancelled when the vehicle is moved during meter effect or the shift lever is shifted to the range except for P-range.

Ignition Switch OFF Effect Function

The unified meter and A/C amp. transmits a meter effect signal to the combination meter through the communication line when ignition switch is turned from ON to OFF. Receiving a meter effect signal, the combination meter turns off the meter illumination in stages. Illumination for the needle is turned off after the meter illumination is turned off.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## METER EFFECT FUNCTION : Component Parts Location

INFOID:00000003928871



# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## METER EFFECT FUNCTION : Component Description


INFOID:000000003887242

Unit	Description
Combination meter	Receives a meter effect signal through the unified meter and A/C amp. and performs meter effect.
Unified meter and A/C amp.	Receives signals from each unit with the CAN communication and transmits a meter effect signal to the combination meter through the communication line.
ECM	Transmits an engine speed signal and an engine status signal to the unified meter and A/C amp. with the CAN communication.
BCM	Transmits a starter relay status signal to the unified meter and A/C amp. with the CAN communication.
ABS actuator and electric unit (control unit)	Transmits a vehicle speed signal to the unified meter and A/C amp. with the CAN communication.
TCM	Transmits a shift position signal to the unified meter and A/C amp. with the CAN communication.

## INFORMATION DISPLAY

### INFORMATION DISPLAY : System Diagram

INFOID:000000003887078



### INFORMATION DISPLAY : System Description

INFOID:000000003887079

#### DESCRIPTION

- The combination meter retrieves the information required for controlling the operations of the information display from the communication signals from the unified meter and A/C amp., etc.

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- The combination meter incorporates a trip computer that displays the warning / information according to the information received from various units.

### PARKING BRAKE RELEASE WARNING

The combination meter indicates parking brake release warning judged with the vehicle speed signal received from the unified meter and A/C amp. by means of communication line and the parking brake switch signal from the parking brake switch.

#### Warning Operation Condition

Parking brake release warning is judged if all of the following conditions are fulfilled

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

### LOW FUEL WARNING

The combination meter indicates low fuel warning judged with the fuel level sensor signal received from the unified meter and A/C amp.

#### Warning Operation Condition


- Fuel level: Approx. 14 ℓ (3 - 5/7 US gal, 3 - 1/10 Imp gal) or less

### LOW WASHER FLUID WARNING

The combination meter indicates low washer fluid warning judged with the signal from the washer level switch.

#### Warning Operation Condition

- Indicates the warning when it is in washer level switch ON condition for 180 seconds or more. Release the warning when it is in washer level switch OFF condition for 30 seconds or more.



### LOW OUTSIDE TEMPERATURE WARNING

The combination meter indicates low outside temperature warning judged with the ambient sensor signal received from the unified meter and A/C amp. by means of communication line.

### DOOR OPEN WARNING

The combination meter indicates door open warning judged with each door switch signal received from the unified meter and A/C amp. by means of communication line.

### INSTANTANEOUS FUEL CONSUMPTION

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the instantaneous fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.

### AVERAGE FUEL CONSUMPTION

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the average fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.
- The average fuel consumption displayed on the information display is uploaded at approximately 30-second intervals.

#### NOTE:

When turning ON the ignition switch after triggering a reset or removing/installing the battery, “—” is indicated until 30 seconds/500 m (0.31 mile) of driving.

### AVERAGE VEHICLE SPEED

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line.
- Measures the time during the ignition switch ON with the unified meter and A/C amp.
- The unified meter and A/C amp. calculates the average vehicle speed according to the above signals. These signals are transmitted to the combination meter with the communication line.
- The average vehicle speed displayed on the information display is uploaded at approximately 30-second intervals.

### NOTE:

When turning ON the ignition switch after triggering a reset or removing/installing the battery, “—” is indicated until 30 seconds/500 m (0.31 mile) of driving.

### TRAVEL TIME

Measures the time during the ignition switch ON with the unified meter and A/C amp, and transmits it to the combination meter by means of communication line.

### TRAVEL DISTANCE

- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

### POSSIBLE DRIVING DISTANCE

The unified meter and A/C amp. calculates possible driving distance according to the vehicle speed signal and fuel consumption monitor signal transmitted via CAN communication and the fuel level sensor signal transmitted from the fuel level sensor. These signals are transmitted to the combination meter with the communication line.

### NOTE:

- When turning ON the ignition switch after removing/installing the battery, “—” is indicated until 30 seconds.
- The indicated values may not match each other when filling the fuel with the ignition switch ON. Refer to [MWI-172. "INFORMATION DISPLAY : Description"](#).

### AMBIENT AIR TEMPERATURE

- The unified meter and A/C amp. receives the ambient sensor signal from the ambient sensor.
- The unified meter and A/C amp. calculates the ambient temperature according to the ambient sensor signal, and transmits it to the combination meter.
- The indicated temperature does not increase if the vehicle speed is less than 20 km/h (12 MPH).

### NOTE:

- The ambient sensor input value that is displayed on “Data Monitor” of CONSULT-III is the value before the correction. It may not match the indicated temperature on the information display.
- Ambient temperature may be indicated higher than an actual temperature, depending on heat in the engine, a road surface temperature, and so on.

## SETTING

Setting item list

Items		Setting range	Setting unit	Description
ALERT	TIME TO REST	No setting - 6 hours	30 minutes, [60 minutes]*	Time to rest is displayed on the information display if the vehicle reached the set travel distance.
	ICY	ON/OFF	—	Low outside temp is displayed on the information display if the ambient temperature is 3°C (37°F) or less.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

## METER SYSTEM

### < SYSTEM DESCRIPTION >

Items		Setting range	Setting unit	Description
MAINTENANCE	ENGINE OIL	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The engine oil replacement interval is displayed on the information display if the vehicle reached the set distance.
	OIL FILTER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The oil filter replacement interval is displayed on the information display if the vehicle reached the set distance.
	TIRE	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The tire replacement interval is displayed on the information display if the vehicle reached the set distance.
	OTHER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The other replacement interval is displayed on the information display if the vehicle reached the set distance.
CUSTOMIZE	LANGUAGE	ENGLISH/FRANCAIS	—	Changing the language setting can be performed.
	UNIT	US/METRIC	—	Changing the unit setting can be performed.
	METER EFFECT	ON/OFF	—	Changing the meter effect setting can be performed.


\* : Press and hold the switch (1 second or more).

# METER SYSTEM

< SYSTEM DESCRIPTION >

## INFORMATION DISPLAY : Component Parts Location

INFOID:000000003887080



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- |  |   |                               |
|--|---|-------------------------------|
| 1. Fuel level sensor unit and fuel pump (main)   | 2. BCM  | 3. IPDM E/R                   |
| 4. ECM : <a href="#">EC-31, "Component Parts Location"</a> (VQ engine models)<br>ECM : <a href="#">EC-590, "Component Parts Location"</a> (VK engine models) | 5. Oil pressure switch (VQ engine models)           | 6. Ambient sensor             |
| 7. Oil pressure switch (VK engine models)  | 8. ABS actuator and electric unit (control unit)    | 9. Unified meter and A/C amp. |
| 10. Combination meter  | 11. Fuel level sensor unit (sub)                    |                               |
| A. Rear seat (bottom)  | B. Dash side finisher (passenger side)              | C. Hoodledge cover (RH)       |
| D. 2WD [oil pan (upper) RH side]   | E. AWD [oil filter bracket part (VQ engine models)] | F. Condenser (front)          |
| G. AWD [oil filter bracket part (VK engine models)]  | H. Hoodledge cover (LH)                             | I. Behind cluster lid C       |

## INFORMATION DISPLAY : Component Description

INFOID:000000003887081

Unit	Description
Combination meter	Controls the information display with the signals received from the unified meter and A/C amp. by means of communication and the signals from various switches and sensors.
Unified meter and A/C amp.	Transmits signals received from various units to the combination meter by means of communication.
Fuel level sensor unit	Refer to <a href="#">MWI-62, "Description"</a> .
ECM	Transmits the following signals to the unified meter and A/C amp. via CAN communication. <ul style="list-style-type: none"> <li>• Engine speed signal</li> <li>• Fuel consumption monitor signal</li> </ul>
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. via CAN communication.
BCM	Transmits signals provided by various units to the unified meter and A/C amp. via CAN communication.
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>• Enter switch signal</li> <li>• Select switch signal</li> </ul>
Washer level switch	Transmits the washer level signal to the combination meter.
Parking brake switch	Refer to <a href="#">MWI-70, "Description"</a> .
Door switch	Transmits the door switch signals to BCM.
Ambient sensor	Detects the ambient air temperature and transmits the ambient sensor signal to the unified meter and A/C amp.

# COMPASS

< SYSTEM DESCRIPTION >


## COMPASS

### Description

INFOID:000000003887082

### DESCRIPTION

- This electronic compass is able to display 8 primary directions: N, NE, E, SE, S, SW, W, NW.
- The compass switch (1) is used to operate the compass.



#### Switch Operation

Press	Compass is turned ON/OFF
Press and hold (for 3- 9 sec.)	Compass display (2) turns to zone variation change mode Compass
Press and hold (for more than 9 sec.)	Compass display turns to calibration mode

- All standard compasses determine direction relative to magnetic north; however, this electronic compass is designed to display direction relative to true north.
- The difference between magnetic north and true north varies from place to place across the surface of the earth.
- This electronic compass must be “told” approximately where it is on the earth’s surface so that the magnetic north reading can be properly converted into a true north display.
- To tell the electronic compass where it’s at, the earth is separated into numbered “zone variances”. The zone variance number in which the compass is to function must be entered into this electronic compass.
- Each zone is magnetically about 4.2° wide. Typically, anything under 22.5° total zone change is not noticed on the electronic compass display. However, over 22.5°, a reading may be off by one or more primary directions.
- On long trips, a vehicle may leave its original zone and enter one or more new zones. Generally, you do not need to reset the compass zone if you travel between 3 or 4 zones, such as business travel or vacation. The typical driver will not notice any difference on the display within 3 or 4 zones. However, if the vehicle is “permanently” moved to a new location, it is recommended that the compass zone be reset.

### ZONE VARIATION SETTING PROCEDURE


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# COMPASS

## < SYSTEM DESCRIPTION >

1. Press and hold the compass switch for 3 – 9 seconds.
2. The current zone setting appears on the compass display.
3. Find the current geographical location number in the zone variation chart.
4. Select the new zone number. (Press the compass switch until the new zone number appears on the compass display.)
5. After select the new zone number, the compass display will automatically shows a direction within a few seconds.
6. Perform the following calibration procedure for more accurate indications.



## CALIBRATION PROCEDURE

### NOTE:

The compass calibrates itself under normal driving conditions. However, occasional circumstances may cause the compass to operate inaccurately. Example: Driving from rural (wide open) areas to crowded city areas, or if an aftermarket (i.e., non original equipment) antenna with a magnetic base is attached to the vehicle. Calibrate the mirror compass if the display shows only one direction or a limited number of directions.

### NOTE:

- If “magnetic hats” are used in the dealership for vehicle identification, remove the hat from the vehicle before performing the following steps. Do not put the hat back on the vehicle after the procedure is completed.
  - Drive the vehicle to an open level area; away from large metallic objects, structures, and overhead power lines.
  - Turn off “non-essential” electrical accessories (rear window defrost, heater/air conditioning, wipers) and close the doors.
1. Verify the correct compass zone setting for the geographical location.
  2. Press and hold the compass switch for more than 9 seconds.
  3. “C” is displayed on the compass display, when calibration starts.
  4. Drive slowly [less than 8 km/h (5 MPH)] in a circle until the “C / CAL” is replaced with primary headings (N, NE, E, SE, S, SW, W, or NW).

### NOTE:

This will require driving at least 2 complete 360 degree circles; 3 complete circles may be required.

5. The compass calibration procedure is now complete. The compass should operate normally.

### NOTE:

If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, repeat the calibration procedure.


# COMPASS

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000003887083

- 1 : Compass switch
- 2 : Compass display



## Special Repair Requirement

INFOID:000000003887084

### 1.PERFORM ZONE VARIATION SETTING

Perform the zone variation setting. Refer to [MWI-39, "Description"](#).

>> GO TO 2.

### 2.PERFORM CALIBRATION

Perform the calibration. Refer to [MWI-39, "Description"](#).

>> Setting completion

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# CLOCK


< SYSTEM DESCRIPTION >

## CLOCK

### Component Parts Location

INFOID:000000003887085

1 : Clock



# DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (METER)

### Diagnosis Description

INFOID:000000003887086

### SELF-DIAGNOSIS MODE

- Information display LCD segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.


### OPERATION PROCEDURE

1. Turn ignition switch ON, and switch the trip meter to "trip A" or "trip B".


**NOTE:**

If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0". (The same way for "trip B".)

2. Turn ignition switch OFF.
3. While pressing the trip A/B reset switch (1), turn ignition switch ON again.
4. Make sure that the trip meter displays "0000.0".
5. Press the trip A/B reset switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)



6. The unified meter control unit is turned to self-diagnosis mode.
  - Displays "888888" (1) and "8888.8" (2) in the information display LCD (3) for approximately 5 seconds and then blinks the segment dots of the information display LCD alternately.
  - Engine coolant temperature gauge and fuel gauge return to zero, and at the same time.



**NOTE:**

- Check combination meter power supply and ground circuit when self-diagnosis mode of combination meter does not start. Replace combination meter if normal.
- If any of the segments is not displayed, replace combination meter.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

## DIAGNOSIS SYSTEM (METER)

### < SYSTEM DESCRIPTION >

7. Each meter activates during pressing trip A/B reset switch.



**NOTE:**

If any of the meter and gages is not activated, replace combination meter.

# DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### CONSULT-III Function (METER/M&A)

INFOID:000000003887087

#### CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes with CAN communication with the unified meter and A/C amp.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	Unified meter and A/C amp. checks the conditions and displays memorized error.
	Data Monitor	Displays unified meter and A/C amp. input/output data in real time.
	Ecu Identification	The unified meter and A/C amp. part number is displayed.

#### SELF DIAG RESULT

Refer to [MWI-112, "DTC Index"](#).

#### DATA MONITOR

##### Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h] or [mph]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h] or [mph]	X	Vehicle speed signal value transmitted to other units with CAN communication line. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h]		Odometer signal value transmitted to other units with CAN communication line.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM with CAN communication line. <b>NOTE:</b> 8191.875 is displayed when the malfunction signal is received.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°C] or [°F]	X	Value of engine coolant temperature signal received from ECM with CAN communication line. <b>NOTE:</b> 215 is displayed when the malfunction signal is input.
ABS W/L [On/Off]		Status of ABS warning lamp judged from ABS warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
VDC/TCS IND [On/Off]		Status of VDC OFF indicator lamp judged from VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
SLIP IND [On/Off]		Status of SLIP indicator lamp judged from SLIP indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
BRAKE W/L [On/Off]		Status of brake warning lamp judged from brake warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line. <b>NOTE:</b> Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.
DOOR W/L [On/Off]		Status of door warning judged from door switch signal received from BCM with CAN communication line.
HI-BEAM IND [On/Off]		Status of high beam indicator lamp judged from high beam request signal received from BCM with CAN communication line.

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
TURN IND [On/Off]		Status of turn indicator lamp judged from turn indicator signal received from BCM with CAN communication line.
FR FOG IND [On/Off]		This item is displayed, but cannot be monitored.
RR FOG IND [On/Off]		This item is displayed, but cannot be monitored.
LIGHT IND [On/Off]		Status of tail lamp indicator lamp judged from position light request signal received from BCM with CAN communication line.
OIL W/L [On/Off]		Status of oil pressure warning lamp judged from oil pressure switch signal received from IPDM E/R with CAN communication line.
MIL [On/Off]		Status of malfunction indicator lamp judged from malfunctioning indicator lamp signal received from ECM with CAN communication line.
GLOW IND [On/Off]		This item is displayed, but cannot be monitored.
C-ENG2 W/L [On/Off]		This item is displayed, but cannot be monitored.
CRUISE IND [On/Off]		<ul style="list-style-type: none"> <li>• Status of CRUISE indicator judged from ASCD status signal received from ECM with CAN communication line.</li> <li>• Status of CRUISE indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.</li> </ul>
SET IND [On/Off]		<ul style="list-style-type: none"> <li>• Status of SET indicator judged from ASCD status signal received from ECM with CAN communication line.</li> <li>• Status of SET indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.</li> </ul>
CRUISE W/L [On/Off]		Status of CRUISE warning lamp judged from ICC warning lamp signal received from ICC sensor integrated unit with CAN communication line.
BA W/L [On/Off]		Status of IBA OFF indicator lamp judged from IBA OFF indicator signal received from ICC sensor integrated unit with CAN communication line.
ATC/T-AMT W/L [On/Off]		Status of A/T check warning lamp judged from A/T check indicator lamp signal received from TCM with CAN communication line.
4WD W/L [On/Off]		Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line.
4WD LOCK IND [On/Off]		This item is displayed, but cannot be monitored.
FUEL W/L [On/Off]		Low-fuel warning status judged by the identified fuel level.
WASHER W/L [On/Off]		Status of washer warning judged from washer level switch input to combination meter.
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp judged from tire pressure signal received from BCM with CAN communication line.
KEY G/Y W/L [On/Off]		Status of key warning lamp (G/Y) judged from key warning signal received from BCM with CAN communication line.
AFS OFF IND [On/Off]		Status of AFS OFF indicator lamp judged from AFS OFF indicator lamp signal received from AFS control unit with CAN communication line.
4WAS/RAS W/L [On/Off]		Status of RAS warning lamp judged from RAS warning lamp signal received from RAS control unit with CAN communication line.
DDS W/L [On/Off]		This item is displayed, but cannot be monitored.
LANE W/L [On/Off]		Status of lane departure warning lamp judged from lane departure warning lamp signal received from lane camera unit with CAN communication line.
LDP IND [On/Off]		Status of LDP ON indicator lamp judged from LDP ON indicator lamp signal received from lane camera unit with CAN communication line.

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description	A
E-SUS IND [On/Off]		Status of sports mode indicator lamp judged from sports mode indicator lamp signal received from E-SUS control unit with CAN communication line.	A
DCA IND [On/Off]		Status of DCA switch indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	B
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY,OUTKY, LK WN]		Displays status of Intelligent Key system warning judged from meter display signal received from BCM with CAN communication line.	C
ACC TARGET [On/Off]		Status of vehicle ahead detection indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	D
ACC DISTANCE [Off, SHOR, MID, LONG]		Status of set distance indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	E
ACC OWN VHL [On/Off]		Status of own vehicle indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	F
ACC SET SPEED		Status of set vehicle speed indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	F
ACC UNIT [On/Off]		Status of display unit judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	G
SHIFT IND [P, R, N, D, L, M1, M2, M3, M4, M5, M6, M7]		Status of shift position indicator judged from shift position signal and manual mode indicator signal received from TCM with CAN communication line.	G
O/D OFF SW [On/Off]		This item is displayed, but cannot be monitored.	H
AT S MODE SW [On/Off]		Status of snow mode switch.	I
AT P MODE SW [On/Off]		This item is displayed, but cannot be monitored.	J
M RANGE SW [On/Off]		Status of manual mode switch.	J
NM RANGE SW [On/Off]		Status of not manual mode switch.	K
AT SFT UP SW [On/Off]		Status of A/T shift up switch.	L
AT SFT DWN SW [On/Off]		Status of A/T shift down switch.	L
ST SFT UP SW [On/Off]		Status of paddle shifter up switch.	M
ST SFT DWN SW [On/Off]		Status of paddle shifter down switch.	M
COMP F/B SIG [On/Off]		A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.	MWI
4WD LOCK SW [On/Off]		This item is displayed, but cannot be monitored.	O
PKB SW [On/Off]		Status of parking brake switch.	P
BUCKLE SW [On/Off]		Status of seat belt buckle switch.	P
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.	
DISTANCE [km/h]		Value of possible driving distance calculated by unified meter and A/C amp.	

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
OUTSIDE TEMP [°C] or [°F]		Ambient air temperature value converted from ambient sensor signal received from ambient sensor. <b>NOTE:</b> This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit with CAN communication line.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is judged with the buzzer output signal received from each unit with CAN communication line and the warning output condition of the combination meter.

**NOTE:**

Some items are not available according to vehicle specification.

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000003887088

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-21, "How to Use CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:000000003887089

#### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

#### Diagnosis Procedure

INFOID:000000003887090

#### 1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-22, "Trouble Diagnosis Flow Chart"](#).  
NO >> Refer to [GI-35, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000003887091

Initial diagnosis of unified meter and A/C amp.

### DTC Logic

INFOID:000000003887092

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	If any malfunction is detected during initial diagnosis of unified meter and A/C amp. CAN controller	Unified meter and A/C amp.

### Diagnosis Procedure

INFOID:000000003887093

#### 1. REPLACE UNIFIED METER AND A/C AMP.

When DTC "U1010" is detected, replace unified meter and A/C amp.

>> INSPECTION END

# B2201 COMMUNICATION ERROR 1

< DTC/CIRCUIT DIAGNOSIS >

## B2201 COMMUNICATION ERROR 1

### Description

INFOID:000000003887094

The communication line (LCD <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

### DTC Logic

INFOID:000000003887095

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2201	COMM ERROR 1	If a communication error is present in the communication line (LCD <-> AMP.) for 2 seconds or more	Communication line (LCD <-> AMP.) circuit

### Diagnosis Procedure

INFOID:000000003887096

#### 1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

#### 2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector and unified meter and A/C amp. harness connector.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
M53	24	M66	14	Existed
	25		34	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	24		Not existed
	25		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector and ground.

## B2201 COMMUNICATION ERROR 1

< DTC/CIRCUIT DIAGNOSIS >

---

Terminals		Voltage (Approx.)
(+)	(-)	
Unified meter A/C amp.		12 V
Connector	Terminal	
M66	14	
		Ground

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace unified meter and A/C amp.

### 4. CHECK COMBINATION METER OUTPUT VOLTAGE

---

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Combination meter		5 V
Connector	Terminal	
M53	25	
		Ground

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace combination meter.

# B2202 COMMUNICATION ERROR 2

< DTC/CIRCUIT DIAGNOSIS >

## B2202 COMMUNICATION ERROR 2

### Description

INFOID:000000003887097

The communication line (METER <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

### DTC Logic

INFOID:000000003887098

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2202	COMM ERROR 2	If a communication error is present in the communication line (METER <-> AMP.) for 2 seconds or more	Communication line (METER <-> AMP.) circuit

### Diagnosis Procedure

INFOID:000000003887099

#### 1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

#### 2. CHECK CONTINUITY COMMUNICATION CIRCUIT

- Turn ignition switch OFF.
- Disconnect combination meter connector and unified meter and A/C amp. connector.
- Check continuity between combination meter harness connector and unified meter and A/C amp. harness connector.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
M53	2	M66	27	Existed
	3		7	Existed

- Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	2		Not existed
	3		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

- Turn ignition switch OFF.
- Disconnect combination meter connector.
- Connect unified meter and A/C amp. connector.
- Turn ignition switch ON.
- Check voltage between unified meter and A/C amp. harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

## B2202 COMMUNICATION ERROR 2

< DTC/CIRCUIT DIAGNOSIS >

---

Terminals		Voltage (Approx.)
(+)	(-)	
Unified meter A/C amp.		5 V
Connector	Terminal	
M66	27	

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace unified meter and A/C amp.

### 4. CHECK COMBINATION METER OUTPUT VOLTAGE

---

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Combination meter		5 V
Connector	Terminal	
M53	3	

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace combination meter.

# B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2205 VEHICLE SPEED

### Description

INFOID:000000003887100

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication to unified meter and A/C amp.

### DTC Logic

INFOID:000000003887101

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2205	VEHICLE SPEED	If the abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more	<ul style="list-style-type: none"><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### Diagnosis Procedure

INFOID:000000003887102

#### 1. PERFORM SELF-DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnostic Result" of ABS actuator and electric unit (control unit), and repair or replace malfunctioning parts.

>> Refer to [BRC-44, "CONSULT-III Function"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2267 ENGINE SPEED

### Description

INFOID:000000003887103

The engine speed signal is transmitted from ECM to the unified meter and A/C amp. with CAN communication.

### DTC Logic

INFOID:000000003887104

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2267	ENGINE SPEED	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more	<ul style="list-style-type: none"><li>• Crankshaft position sensor (POS)</li><li>• ECM</li></ul>

### Diagnosis Procedure

INFOID:000000003887105

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnostic Result" of ECM, and repair or replace malfunctioning parts.

- >> • [EC-124, "CONSULT-III Function"](#) (VQ35HR models)  
• [EC-719, "CONSULT-III Function"](#) (VK50VE models)

# B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

## B2268 WATER TEMP

### Description

INFOID:000000003887106

The engine coolant temperature signal is transmitted from ECM to the unified meter and A/C amp. via CAN communication.

### DTC Logic

INFOID:000000003887107

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2268	WATER TEMP	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	<ul style="list-style-type: none"><li>• Engine coolant temperature sensor</li><li>• ECM</li></ul>

### Diagnosis Procedure

INFOID:000000003887108

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

- >> • [EC-124. "CONSULT-III Function"](#) (VQ35HR models)
- [EC-719. "CONSULT-III Function"](#) (VK50VE models)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

### COMBINATION METER : Diagnosis Procedure

INFOID:000000003887109

#### 1. CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

Terminals			Ignition switch position	Value (Approx.)
(+)		(-)		
Combination meter	Terminal	Signal name		
M53	1	Battery power supply	OFF	Battery voltage
	21	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

#### 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	5		Existed
	15		Existed
	22		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## UNIFIED METER AND A/C AMP.

### UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000003887110

#### 1. CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	6
Ignition switch ACC or ON	19
Ignition switch ON or START	3

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

### 2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector and ground.

Terminals			Ignition switch position	Value (Approx.)
(+)		(-)		
Unified meter A/C amp.	Terminal		Signal name	
M67	54	Battery power supply	OFF	Battery voltage
	41	ACC power supply	ACC	Battery voltage
	53	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter A/C amp.		Ground	Continuity
Connector	Terminal		
M67	55		Existed
	71		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## BCM (BODY CONTROL MODULE)

### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000003940366

### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground
Connector	Terminal	
M118	1	
M119	11	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000003940367

### 1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

Signal name	Fuses and fusible link No.
Battery power supply	D
	50
	51

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		Ground
Connector	Terminal	
E4	1	
		Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	12		Existed
E6	41		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### Description

INFOID:000000003887113

The fuel level sensor unit and fuel pump (main) and the fuel level sensor unit (sub) detect the fuel level in the fuel tank and transmit the fuel gauge signal to the unified meter and A/C amp.

### Component Function Check

INFOID:000000003887114

#### 1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter.

Fuel gauge pointer	Reference value of data monitor [L]
Full	Approx. 85.3
Three quarters	Approx. 67.3
Half	Approx. 45.4
A quarter	Approx. 22.0
Empty	Approx. 8.7

Does monitor value match fuel gauge reading?

- YES >> INSPECTION END  
 NO >> Replace combination meter.

### Diagnosis Procedure

INFOID:000000003887115

#### 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

- Turn ignition switch ON.
- Check voltage between unified meter and A/C amp. harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Unified meter and A/C amp.		<p style="text-align: right;">SKIB8867E</p>
Connector	Terminal	
M67	42	
		Ground

Does it match fuel gauge reading?

- YES >> GO TO 2.  
 NO >> Replace the unified meter and A/C amp.

#### 2. CHECK FUEL LEVEL SENSOR (SUB) CIRCUIT

- Turn ignition switch OFF.
- Disconnect unified meter and A/C amp. connector and fuel level sensor unit (sub) connector.
- Check continuity between unified meter and A/C amp. harness connector and fuel level sensor unit (sub) harness connector.

Unified meter A/C amp.		Fuel level sensor unit (sub)		Continuity
Connector	Terminal	Connector	terminal	
M67	42	B21	1	Existed

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter A/C amp.		Ground	Continuity
Connector	Terminal		
M67	42		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.CHECK FUEL LEVEL SENSOR (MAIN-SUB) CIRCUIT

1. Disconnect fuel level sensor unit and fuel pump (main) connector.
2. Check continuity between fuel level sensor unit (sub) harness connector and fuel level sensor unit and fuel pump (main) harness connector.

Fuel level sensor unit (sub)		Fuel level sensor unit and fuel pump (main)		Continuity
Connector	Terminal	Connector	terminal	
B21	2	B22	2	Existed

3. Check continuity between fuel level sensor unit (sub) harness connector and ground.

Fuel level sensor unit (sub)		Ground	Continuity
Connector	Terminal		
B21	2		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

### 4.CHECK FUEL LEVEL SENSOR (MAIN) CIRCUIT

Check continuity between fuel level sensor unit and fuel pump (main) harness connector and unified meter and A/C amp. harness connector.

Fuel level sensor unit and fuel pump (main)		Unified meter A/C amp.		Continuity
Connector	Terminal	Connector	terminal	
B22	5	M67	58	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

### 5.CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Install the fuel level sensor unit properly.

## Component Inspection

INFOID:000000003887116

### 1.REMOVE FUEL LEVEL SENSOR UNIT

Remove the fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

>> GO TO 2.

### 2.CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

Check the resistance between fuel level sensor unit and fuel pump (main).

Fuel level sensor unit and fuel pump (main)		Condition	Resistance (Approx.)
Terminal			
2	5	Full (A)	3 Ω
		Empty (B)	80 Ω



Standard float position

Standard float position [mm (in)]*	
Full (A)	Approx. 223.8 (8.81)
Empty (B)	Approx. 29.4 (1.16)

\*: When float rod is contact with stopper.

Is the inspection result normal?


YES >> GO TO 3.

NO >> Replace fuel level sensor unit and fuel pump (main).

### 3. CHECK FUEL LEVEL SENSOR UNIT (SUB)

Inspect the resistance of fuel level sensor unit (sub).

Fuel level sensor unit (sub)		Condition	Resistance (Approx.)
Terminal			
1	2	Full (A)	3 Ω
		Empty (B)	40 Ω



Standard float position

Standard float position [mm (in)]*	
Full (A)	Approx. 4.7 (0.19)
Empty (B)	Approx. 202.4 (7.97)

\*: When float rod is contact with stopper.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub).

# METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## METER CONTROL SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000003887117

Transmits the following signals to the combination meter.

-  (illumination control) switch signal (+)
-  (illumination control) switch signal (-)
-  (select) switch signal
-  (enter) switch signal

### Diagnosis Procedure

INFOID:000000003887118

#### 1. CHECK METER CONTROL SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Check voltage between the following terminals of the combination meter.

Combination meter		Condition	Voltage	
Connector	Terminal			
	(+)	(-)		
M53	36	16	When  (select) switch is pressed	0 V
			Other than the above	5 V
	37	16	When  (enter) switch is pressed	0 V
			Other than the above	5 V
	39	16	When  (illumination control) switch is pressed	0 V
			Other than the above	5 V
	40	16	When  (illumination control) switch is pressed	0 V
			Other than the above	5 V

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> GO TO 2.

#### 2. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector and meter control switch harness connector.

Combination meter		Meter control switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	16	M54	2	Existed
	36		6	Existed
	37		7	Existed
	39		3	Existed
	40		1	Existed

4. Check continuity between combination meter harness connector and ground.

# METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Ground	Continuity
Connector	Terminal		
M53	16	Ground	Not existed
	36		Not existed
	37		Not existed
	39		Not existed
	40		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## Component Inspection

INFOID:000000003887119

### 1. CHECK METER CONTROL SWITCH UNIT

1. Turn the ignition switch OFF.
2. Disconnect the meter control switch connector.
3. Check continuity between the following terminals of the meter control switch.

Combination meter			Operation and status	Continuity
Connector	Terminal			
M54	6	2	Press ● (select) switch	Existed
			Other than the above	Not existed
	7	2	Press □ (enter) switch	Existed
			Other than the above	Not existed
	3	2	Press ⚡- (illumination control) switch	Existed
			Other than the above	Not existed
	1	2	Press ⚡+ (illumination control) switch	Existed
			Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the meter control switch.

# TRIP A/B RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## TRIP A/B RESET SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000003887120

Transmits the trip A/B reset switch signals to the combination meter.

### Diagnosis Procedure

INFOID:000000003887121

#### 1. CHECK TRIP A/B RESET SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Check voltage between the combination meter harness connector terminals.

Combination meter			Condition	Voltage
Connector	Terminal			
	(+)	(-)		
M53	38	16	When trip A/B reset switch is pressed	0 V
			Other than the above	5 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

#### 2. CHECK TRIP A/B RESET SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector and trip A/B reset switch harness connector.

Combination meter		Trip A/B reset switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	38	M56	1	Existed
	16		2	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	38		Not existed
	16	Not existed	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

### Component Inspection

INFOID:000000003887122

#### 1. CHECK TRIP A/B RESET SWITCH UNIT

1. Turn the ignition switch OFF.
2. Disconnect the trip A/B reset switch connector.
3. Check continuity between the trip A/B reset switch connector terminals.

Combination meter			Operation and status	Continuity
Connector	Terminal			
M56	1	2	Press trip A/B reset switch	Existed
			Other than the above	Not existed

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

## TRIP A/B RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

---

Is inspection result normal?

YES >> INSPECTION END

NO >> Replace the trip A/B reset switch.

# OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## OIL PRESSURE SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000003887123

Detects the engine oil pressure and transmits the oil pressure switch signal to IPDM E/R.

### Component Function Check

INFOID:000000003887124

#### 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

"OIL W/L"	
Ignition switch ON	: On
Engine running	: Off

>> INSPECTION END

### Diagnosis Procedure

INFOID:000000003887125

#### 1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector and oil pressure switch harness connector.

IPDM E/R		Oil pressure switch		Continuity
Connector	Terminal	Connector	Terminal	
E7	75	F37	1	Existed

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E7	75		Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Repair harness or connector.


### Component Inspection

INFOID:000000003887126

#### 1. CHECK OIL PRESSURE SWITCH UNIT

Check continuity between oil pressure switch and ground.

Condition	Continuity
Engine stopped	Existed
Engine running	Not existed



Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace the oil pressure switch.

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PARKING BRAKE SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000003887127

Transmits the parking brake switch signal to the combination meter.

### Diagnosis Procedure

INFOID:000000003887128

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the voltage and waveform between combination meter harness connector and ground.

Terminals		Condition	Voltage and waveform
(+)	(-)		
Combination meter			
Connector	Terminal	Parking brake applied	Approx. 0 V
M53	27		

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector and parking brake switch harness connector.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	27	E107	1	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	27		Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Repair harness or connector.

### Component Inspection

INFOID:000000003887129

#### 1. CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-103, "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END.

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

---

NO >> Replace parking brake switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## WASHER LEVEL SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000003887130

Transmits the washer level switch signal to the combination meter.

### Diagnosis Procedure

INFOID:000000003887131

#### 1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and washer level switch connector.
3. Check continuity between combination meter harness connector and washer level switch harness connector.

Combination meter		Washer level switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	31	E32	1	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	31		Not existed

5. Check continuity between washer level switch harness connector and ground.

Washer level switch		Ground	Continuity
Connector	Terminal		
E32	2		Existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

### Component Inspection

INFOID:000000003887132

#### 1. CHECK WASHER LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect washer level switch connector.
3. Check washer level switch.

Terminal	Condition	Continuity
1 - 2	Washer fluid level is low (washer level switch ON)	Existed
	Washer fluid level is normal (washer level switch OFF)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace washer level switch. Refer to [WW-110, "Removal and Installation"](#).


# COMPASS

< DTC/CIRCUIT DIAGNOSIS >

## COMPASS

### Wiring Diagram - COMPASS -

INFOID:000000003887133



COMPASS

2008/03/04

JCNWM1006GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# COMPASS

## < DTC/CIRCUIT DIAGNOSIS >

### COMPASS

Connector No.	M1	Connector No.	M2	Connector No.	M106	Connector No.	M110
Connector Name	FUSE BLOCK (J/B)	Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	NSD6FW-M2	Connector Type	NSD6FW-CS	Connector Type	TK10MPW-NS8	Connector Type	TK18MPW-NH

Terminal No.	2A	Terminal No.	6B	Terminal No.	8	Terminal No.	5	Terminal No.	6
Color of Wire	G	Color of Wire	Y	Color of Wire	Y	Color of Wire	B	Color of Wire	BR
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-

Terminal No.	3A	Terminal No.	4B	Terminal No.	5	Terminal No.	6	Terminal No.	7	Terminal No.	8	Terminal No.	9	Terminal No.	10	Terminal No.	11	Terminal No.	12	Terminal No.	13	Terminal No.	14	Terminal No.	15	Terminal No.	16		
Color of Wire	H.S.																												

Connector No.	R1	Connector No.	R3	Connector No.	R7
Connector Name	WIRE TO WIRE	Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR	Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8	Connector Type	TH10FB-NH	Connector Type	TK18FW-NH

Terminal No.	8	Terminal No.	6	Terminal No.	5	Terminal No.	4	Terminal No.	3	Terminal No.	2	Terminal No.	1
Color of Wire	B	Color of Wire	BR	Color of Wire	BR	Color of Wire	BR	Color of Wire	BR	Color of Wire	BR	Color of Wire	BR
Signal Name [Specification]	-	Signal Name [Specification]	IGN	Signal Name [Specification]	GND	Signal Name [Specification]	BAT	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-

Terminal No.	10	Terminal No.	9	Terminal No.	8	Terminal No.	7	Terminal No.	6	Terminal No.	5	Terminal No.	4	Terminal No.	3	Terminal No.	2	Terminal No.	1		
Color of Wire	GR																				

Terminal No.	8	Terminal No.	7	Terminal No.	6	Terminal No.	5	Terminal No.	4	Terminal No.	3	Terminal No.	2	Terminal No.	1
Color of Wire	B	Color of Wire	BR												

Terminal No.	2A	Terminal No.	3A	Terminal No.	4A	Terminal No.	5A	Terminal No.	6A	Terminal No.	7A	Terminal No.	8A	Terminal No.	9A	Terminal No.	10A	Terminal No.	11A	Terminal No.	12A	Terminal No.	13A	Terminal No.	14A	Terminal No.	15A	Terminal No.	16A
Color of Wire	G	Color of Wire	H.S.																										

JCNWM1007GB


# CLOCK

< DTC/CIRCUIT DIAGNOSIS >

## CLOCK

### Wiring Diagram - CLOCK -

INFOID:000000003887134



CLOCK

2008/03/04

JCNWM1008GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# CLOCK

## < DTC/CIRCUIT DIAGNOSIS >

### CLOCK

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	HS10FY-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6B	Y	-

Connector No.	M74
Connector Name	CLOCK
Connector Type	TH0FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	GND
4	Y	BAT

JCNWM1009GB

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### COMBINATION METER


Reference Value

INFOID:000000003887135

VALUES ON THE DIAGNOSIS TOOL

Refer to [MWI-93. "Reference Value"](#).

TERMINAL LAYOUT



PHYSICAL VALUES





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (LG)	Ground	Communication signal (METER→ AMP.)	Output	Ignition switch ON	—	
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—	
5 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6 (W)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	Battery voltage
7 (LG)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V
10 (G)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON	0 V
					Security warning lamp OFF	12 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI


# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
16 (B)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
21 (R)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
23 (V)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
24 (BR)	Ground	Communication signal (LCD→ AMP.)	Output	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0028GB</p>
25 (Y)	Ground	Communication signal (AMP.→ LCD)	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0027GB</p>
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p><b>NOTE:</b> The maximum voltage varies de- pending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0012GB</p>
27 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
					Parking brake OFF	 <p style="text-align: right; font-size: small;">JSNIA0007GB</p>
28 (W)	Ground	Brake fluid level switch sig- nal	Input	Ignition switch ON	Brake fluid level is normal.	5 V
					The brake fluid level is low- er than the low level	0 V

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
29 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
30 (G)	Ground	Passenger seat belt warning signal	Input	Ignition switch ON	<ul style="list-style-type: none"> <li>When getting in the passenger seat</li> <li>When passenger seat belt is fastened</li> </ul>	12 V
					<ul style="list-style-type: none"> <li>When getting in the passenger seat</li> <li>When passenger seat belt is unfastened</li> </ul>	0 V
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
34 (O)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.	<p><b>NOTE:</b> When brightness level is midway</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p>
36 (LG)	16 (B)	Select switch signal	Input	Ignition switch ON	When ● is pressed	0 V
					Other than the above	5 V
37 (SB)	16 (B)	Enter switch signal	Input	Ignition switch ON	When □ is pressed	0 V
					Other than the above	5 V
38 (L)	16 (B)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
39 (P)	16 (B)	Illumination control switch signal (-)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V
40 (O)	16 (B)	Illumination control switch signal (+)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# COMBINATION METER


< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - METER -

INFOID:00000003887136

- ☆ 1 114
- 105
- ☆ 2 113
- 101
- With VQ engine
- With VK engine
- With climate controlled seat
- Without climate controlled seat

\*: This connector is not shown in "Harness Layout".



2008/03/04

JCNWM0994GB





# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No. Connector Name Connector Type	B1 WIRE TO WIRE TH8DFW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]
		80	L	-
		81	P	-
		82	L	-
		83	P	-
		84	SB	-
		86	Y	-
		87	B	-
Connector No. Connector Name Connector Type	B21 FUEL LEVEL SENSOR UNIT (SUB) E32FCGY-RS	Terminal No.	Color of Wire	Signal Name [Specification]
		1	Y	-
		2	W	-
Connector No. Connector Name Connector Type	B22 FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN) E32FCGY-RS	Terminal No.	Color of Wire	Signal Name [Specification]
		2	W	-
		5	B	-
Connector No. Connector Name Connector Type	B31 SEAT BELT BUCKLE SWITCH (DRIVER SIDE) (WITHOUT CLIMATE CONTROLLED SEAT) A43FW	Terminal No.	Color of Wire	Signal Name [Specification]
		1	SB	-
		2	B	-
Connector No. Connector Name Connector Type	B33 E-SUS CONTROL UNIT AAB32FL	Terminal No.	Color of Wire	Signal Name [Specification]
		17	L	-
		18	L	-
		19	L	-
		20	L	-
		21	L	-
		22	L	-
		23	L	-
		24	L	-
		25	L	-
		26	L	-
		27	L	-
		28	L	-
		29	L	-
		30	L	-
		31	L	-
		32	L	-
Connector No. Connector Name Connector Type	B37 RAS CONTROL UNIT A38FW-M4	Terminal No.	Color of Wire	Signal Name [Specification]
		1	L	-
		8	P	-
Connector No. Connector Name Connector Type	B58 WIRE TO WIRE NS10FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]
		60	B	-
		61	SB	-
Connector No. Connector Name Connector Type	E201 WIRE TO WIRE TH8DFW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]
		47	L	- [With ICC]
		48	P	- [With ICC]







JCNWM0997GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No. B250	Connector Name BRAKE BOOSTER CONTROL UNIT	Connector Type TK24FW		Terminal No. 5	Color of Wire P	Signal Name [Specification] ITS COMM-L
Connector No. 14	Connector Name ITS COMM-H	Connector Type ITS COMM-H		Terminal No. 14	Color of Wire L	Signal Name [Specification] ITS COMM-H
Connector No. E3	Connector Name WIRE TO WIRE	Connector Type SAA38MB-RS10-SZZ		Terminal No. 35	Color of Wire Y	Signal Name [Specification]
Connector No. E10	Connector Name SEAT BELT BUCKLE SWITCH (DRIVER SIDE) (WITH CLIMATE CONTROLLED SEAT)	Connector Type A03FW		Terminal No. 60	Color of Wire R/Y	Signal Name [Specification]
Connector No. 61	Connector Name A03FW	Connector Type A03FW		Terminal No. 61	Color of Wire B/Y	Signal Name [Specification]
Connector No. E7	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type TH20FW-CS12-M4		Terminal No. 60	Color of Wire R/Y	Signal Name [Specification]
Connector No. 61	Connector Name TH20FW-CS12-M4	Connector Type TH20FW-CS12-M4		Terminal No. 61	Color of Wire B/Y	Signal Name [Specification]
Connector No. E7	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type TH20FW-CS12-M4		Terminal No. 75	Color of Wire Y	Signal Name [Specification]
Connector No. E7	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type TH20FW-CS12-M4		Terminal No. 75	Color of Wire Y	Signal Name [Specification]
Connector No. E8	Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type TH08FW-NH		Terminal No. 38	Color of Wire P	Signal Name [Specification]
Connector No. 40	Connector Name ITS COMM-L	Connector Type ITS COMM-L		Terminal No. 40	Color of Wire L	Signal Name [Specification]
Connector No. E32	Connector Name WASHER LEVEL SWITCH	Connector Type Z02FBR		Terminal No. 1	Color of Wire LG	Signal Name [Specification]
Connector No. 2	Connector Name Z02FBR	Connector Type Z02FBR		Terminal No. 2	Color of Wire B/W	Signal Name [Specification]

JCNWM0998GB




# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No. F10	Connector Name WIRE TO WIRE	Connector Type SA33FE-RSS-S1Z8	Terminal No. 24	Color of Wire Y	Signal Name [Specification] -
Connector No. F37	Connector Name OIL PRESSURE SWITCH	Connector Type E01FGY-RS-AR	Terminal No. 1	Color of Wire Y	Signal Name [Specification] -
Connector No. F36	Connector Name ALTERNATOR	Connector Type HS0FPB	Terminal No. 2	Color of Wire G	Signal Name [Specification] L
Connector No. F151	Connector Name TCM (TRANSMISSION CONTROL MODULE)	Connector Type SP10FG	Terminal No. 3 8	Color of Wire R BR	Signal Name [Specification] CAN-H CAN-L
Connector No. F103	Connector Name WIRE TO WIRE	Connector Type TK36FW-NS10	Terminal No. 2 43 44	Color of Wire G P L	Signal Name [Specification] -
Connector No. F51	Connector Name A/T ASSEMBLY	Connector Type RK10FG-DGY	Terminal No. 3 8	Color of Wire L P	Signal Name [Specification] -
Connector No. M1	Connector Name FUSE BLOCK (J/B)	Connector Type NS06FW-MZ	Terminal No. 1A 2A 5A	Color of Wire O G V	Signal Name [Specification] -
Connector No. M2	Connector Name FUSE BLOCK (J/B)	Connector Type NS10FW-CS	Terminal No. 8B	Color of Wire Y	Signal Name [Specification] -



JCNWM1000GB



# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH407V-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	P	AIR BAG
10	G	SECURITY
13	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH407V-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
5	L	SHIFT UP
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE
11	G	NOT MANUAL MODE
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN
26	G	PADDLE DOWN
27	LG	COMM (METER->AMP)

23	V	ACC
24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	BRAKE FLUID LEVEL SW
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SW
34	O	ILL COON OUT
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12MW-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	B	-
3	P	-
6	LG	-
7	SB	-

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72

Terminal No.	Color of Wire	Signal Name [Specification]
41	V	ACC
42	Y	FUEL LEVEL SENS
45	P	AMB SENS
53	G	IGN
54	Y	BAT
55	B	GND
56	L	CAN-H
57	W	BRAKE FLUID LEVEL SW
58	B	FUEL LEVEL SENS GND
61	BR	AMB SENS GND
71	B	GND

Connector No.	M56
Connector Name	TRIP A/B RESET SWITCH
Connector Type	TH04MM-NH



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-

72	P	CAN-L
----	---	-------

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No.	M83	Connector No.	M85	Connector No.	M87	Connector No.	M88
Connector Name	AV CONTROL UNIT (WITHOUT NAVI)	Connector Name	AV CONTROL UNIT (WITHOUT NAVI)	Connector Name	AV CONTROL UNIT (WITH NAVI)	Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Type	TH24FW-NH	Connector Type	TH32FW-NH	Connector Type	TH46FW-NH	Connector Type	TH12FW-NH

Terminal No.	44	Terminal No.	52	Terminal No.	70
Color of Wire	BR	Color of Wire	L	Color of Wire	BR
Signal Name [Specification]	COMM (DISP->CONT)	Color of Wire	P	Color of Wire	Y
	COMM (CONT->DISP)	Signal Name [Specification]	CAN-H	Signal Name [Specification]	COMM (DISP->CONT)
	COMM (CONT->DISP)		CAN-L		COMM (DISP->CONT)

Terminal No.	8	Terminal No.	113	Terminal No.	2
Color of Wire	L	Color of Wire	P	Color of Wire	W
Signal Name [Specification]	CAN-H	Color of Wire	L	Color of Wire	P
	CAN-L	Signal Name [Specification]	VEH-CAN-L1	Signal Name [Specification]	-
	CAN-L		VEH-CAN-H1		-

Terminal No.	16	Terminal No.	114	Terminal No.	44
Color of Wire	P	Color of Wire	L	Color of Wire	L
Signal Name [Specification]	CAN-H	Color of Wire	L	Color of Wire	L
	CAN-L	Signal Name [Specification]	VEH-CAN-L1	Signal Name [Specification]	-
	CAN-L		VEH-CAN-H1		-






Terminal No.	47	Terminal No.	86	Terminal No.	90
Color of Wire	BR	Color of Wire	L	Color of Wire	W
Signal Name [Specification]	COMM (DISP->CONT)	Color of Wire	P	Color of Wire	W
	COMM (CONT->DISP)	Signal Name [Specification]	CAN-H	Color of Wire	W
	COMM (CONT->DISP)		CAN-L	Signal Name [Specification]	-

Terminal No.	105	Terminal No.	107	Terminal No.	110
Color of Wire	BR	Color of Wire	EGM (WITH V6 ENGINE)	Color of Wire	WIRE TO WIRE
Signal Name [Specification]	COMM (DISP->CONT)	Color of Wire	RH24FGY-RZ6-R-LH-Z	Color of Wire	WIRE TO WIRE
	COMM (CONT->DISP)	Signal Name [Specification]	VEH-CAN-L1	Color of Wire	WIRE TO WIRE
	COMM (CONT->DISP)		VEH-CAN-H1	Color of Wire	WIRE TO WIRE

Terminal No.	105	Terminal No.	107	Terminal No.	110
Color of Wire	BR	Color of Wire	EGM (WITH V6 ENGINE)	Color of Wire	WIRE TO WIRE
Signal Name [Specification]	COMM (DISP->CONT)	Color of Wire	RH24FGY-RZ6-R-LH-Z	Color of Wire	WIRE TO WIRE
	COMM (CONT->DISP)	Signal Name [Specification]	VEH-CAN-L1	Color of Wire	WIRE TO WIRE
	COMM (CONT->DISP)		VEH-CAN-H1	Color of Wire	WIRE TO WIRE







JCNWM1003GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER


Connector No. M117	WIRE TO WIRE	TH80WV-CS1(F-TM4)		Terminal No. 47	Color of Wire L	Signal Name [Specification] - [With ICC]
Connector Name				48	P	- [With ICC]
Connector Type						
Connector No. M122	BCM (BODY CONTROL MODULE)	TH40FB-NH		Terminal No. 90	P	CAN-L
Connector Name				91	L	CAN-H
Connector Type						
Connector No. M123	BCM (BODY CONTROL MODULE)	TH40FG-NH		Terminal No. 141	G	SECURITY INDICATOR OUTPUT
Connector Name						
Connector Type						
Connector No. M125	CAN GATEWAY	TH12FW-NH		Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name				1	L	CAN-H
Connector Type				4	L	CAN-H
				6	L	CAN-H
				7	P	CAN-L
				10	P	CAN-L
				12	P	CAN-L
Connector No. M137	A/T SHIFT SELECTOR	TH12FW-NH		Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name				1	W	-
Connector Type				2	V	-
				3	L	-
				4	B	-
				5	G	-
Connector No. M147	AIR BAG DIAGNOSIS SENSOR UNIT	TK2BFY-EX-SC		Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name				15	P	AIR BAG W/L
Connector Type				24	G	SEAT BELT
Connector No. M160	ECM (WITH YK ENGINE)	RH24FY-R28-R-LH-Z		Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name				101	P	VEHCAN-L
Connector Type				106	L	VEHCAN-H
Connector No. R7	WIRE TO WIRE	TH16FW-NH		Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name				1	L	-
Connector Type				2	P	-

JCNWM1004GB

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



JCNWM1005GB

## Fail-Safe

### FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

INFOID:000000003887137

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Function		Specifications
Speedometer		Reset to zero by suspending communication.
Tachometer		
Fuel gauge		
Engine coolant temperature gauge		
Illumination control		When suspending communication, change to nighttime mode.
Information display		The display turns off by suspending communication.
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	VDC OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	RAS warning lamp	
	CRUISE warning lamp	
	IBA OFF indicator lamp	
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Tail lamp indicator lamp	
	Oil pressure warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	Key warning lamp	
	AFS OFF indicator lamp	
	Lane departure warning lamp	
	LDP ON indicator lamp	
Sports mode indicator lamp		
Master warning lamp		

### DTC Index

INFOID:000000003887138

Refer to [MWI-112, "DTC Index"](#).

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

## UNIFIED METER AND A/C AMP.

### Reference Value

INFOID:000000003887139

### VALUES ON THE DIAGNOSIS TOOL

#### CONSULT-III MONITOR ITEM

Monitor Item	Condition		Value/Status
SPEED METER [km/h] or [mph]	Ignition switch ON	While driving	Equivalent to speedometer reading <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h] or [mph]	Ignition switch ON	While driving	Equivalent to speedometer reading <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading <b>NOTE:</b> 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C] or [°F]	Ignition switch ON	—	Values according to engine coolant temperature <b>NOTE:</b> 215 is displayed when the malfunction signal is input
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	SLIP indicator lamp ON	On
		SLIP indicator lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning displayed	On
		Door warning not displayed	Off
HI-BEAM IND	Ignition switch ON	Hi-beam indicator lamp ON	On
		Hi-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn indicator lamp ON	On
		Turn indicator lamp OFF	Off
FR FOG IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
RR FOG IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
LIGHT IND	Ignition switch ON	Tail lamp indicator lamp ON	On
		Tail lamp indicator lamp OFF	Off
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
MIL	Ignition switch ON	Malfunction warning lamp ON	On
		Malfunction warning lamp OFF	Off
GLOW IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
C-ENG2 W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
CRUISE IND	Ignition switch ON	CRUISE indicator displayed	On
		CRUISE indicator not displayed	Off
SET IND	Ignition switch ON	SET indicator displayed ON	On
		SET indicator not displayed OFF	Off
CRUISE W/L	Ignition switch ON	CRUISE warning lamp ON	On
		CRUISE warning lamp OFF	Off
BA W/L	Ignition switch ON	IBA OFF indicator lamp ON	On
		IBA OFF indicator lamp OFF	Off
ATC/T-AMT W/L	Ignition switch ON	A/T check warning lamp ON	On
		A/T check warning lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
4WD LOCK IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
FUEL W/L	Ignition switch ON	Low-fuel warning displayed	On
		Low-fuel warning not displayed	Off
WASHER W/L	Ignition switch ON	Washer warning displayed	On
		Washer warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On
		Low tire pressure lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	Key warning lamp ON	On
		Key warning lamp OFF	Off
AFS OFF IND	Ignition switch ON	AFS OFF indicator lamp ON	On
		AFS OFF indicator lamp OFF	Off
4WAS/RAS W/L	Ignition switch ON	RAS warning lamp ON	On
		RAS warning lamp OFF	Off
DDS W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
LANE W/L	Ignition switch ON	Lane departure warning lamp ON	On
		Lane departure warning lamp OFF	Off
LDP IND	Ignition switch ON	LDP ON indicator lamp ON	On
		LDP ON indicator lamp OFF	Off
E-SUS IND	Ignition switch ON	Sports mode indicator lamp ON	On
		Sports mode indicator lamp OFF	Off
DCA IND	Ignition switch ON	DCA switch indicator displayed	On
		DCA switch indicator not displayed	Off

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status	
LCD	Ignition switch ON	Engine start information display	B&P I	A
	Ignition switch ACC	Engine start information display	B&P N	B
	Ignition switch LOCK	Key ID warning display	ID NG	C
	Ignition switch LOCK	Steering lock information display	ROTAT	D
	Ignition switch LOCK	P position warning display	SFT P	E
	Ignition switch LOCK	Intelligent Key insert information display	INSRT	F
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT	G
	Ignition switch ON	Take away warning display	NO KY	H
	Ignition switch LOCK	Key warning display	OUTKY	I
	Ignition switch ON	ACC warning display	LK WN	J
ACC TARGET	Ignition switch ON	Vehicle ahead detection indicator displayed	On	K
		Vehicle ahead detection indicator not displayed	Off	L
ACC DISTANCE	Ignition switch ON	When following distance set to "LONG"	Long	M
		When following distance set to "MIDDLE"	Middle	N
		When following distance set to "SHORT"	Short	O
		Set distance indicator not displayed	Off	P
ACC OWN VHL	Ignition switch ON	Own vehicle indicator displayed	On	Q
		Own vehicle indicator not displayed	Off	R
ACC SET SPEED	Ignition switch ON	Set vehicle speed indicator not displayed	Off	S
		Set vehicle speed indicator displayed	Indicates the set vehicle speed	T
ACC UNIT	Ignition switch ON	Set vehicle speed indicator unit display ON	On	U
		Set vehicle speed indicator unit display OFF	Off	V
SHIFT IND	Ignition switch ON	Shift position indicator P display	P	W
		Shift position indicator R display	R	X
		Shift position indicator N display	N	Y
		Shift position indicator D display	D	Z
		Shift position indicator DS display	L	AA
		Shift position indicator M1 display	M1	AB
		Shift position indicator M2 display	M2	AC
		Shift position indicator M3 display	M3	AD
		Shift position indicator M4 display	M4	AE
		Shift position indicator M5 display	M5	AF
		Shift position indicator M6 display	M6	AG
Shift position indicator M7 display	M7	AH		
O/D OFF SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	AI

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
AT S MODE SW	Ignition switch ON	Snow mode switch pressed	On
		Snow mode switch not pressed	Off
AT P MODE SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
M RANGE SW	Ignition switch ON	Selector lever manual mode position	On
		Other than the above	Off
NM RANGE SW	Ignition switch ON	Selector lever manual mode position	Off
		Other than the above	On
AT SFT UP SW	Ignition switch ON	Selector lever + position	On
		Other than the above	Off
AT SFT DWN SW	Ignition switch ON	Selector lever – position	On
		Other than the above	Off
ST SFT UP SW	Ignition switch ON	Paddle shifter switch up operation	On
		Other than the above	Off
ST SFT DWN SW	Ignition switch ON	Paddle shifter switch down operation	On
		Other than the above	Off
COMP F/B SIG	Ignition switch ON	A/C compressor activation condition	On
		A/C compressor deactivation condition	Off
4WD LOCK SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt not fastened	On
		Seat belt fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km/h]	Ignition switch ON	—	Possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature <b>NOTE:</b> This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low-fuel warning signal output	On
		Low-fuel warning signal not output	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off


**NOTE:**

Some items are not available according to vehicle specification.

### TERMINAL LAYOUT

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >








## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
5 (L)	Ground	Manual mode shift up signal	Input	Ignition switch ON	Selector lever UP operation	0 V
					Other than the above	12 V
6 (O)	Ground	Paddle shifter up signal	Input	Ignition switch ON	Paddle shifter up operation	0 V
					Other than the above	12 V
7 (GR)	Ground	Communication signal (AMP. → METER)	Output	Ignition switch ON	—	<p style="text-align: right; font-size: small;">JSNIA0027GB</p>
8 (L)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	<p><b>NOTE:</b> The maximum voltage varies depending on the specification (destination unit).</p> <p style="text-align: right; font-size: small;">JSNIA0015GB</p>
9 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When seat belt is fastened	12 V
					When seat belt is not fastened	0 V
10 (W)	Ground	Manual mode signal	Input	Ignition switch ON	Selector lever DS position	0 V
					Other than the above	12 V
11 (G)	Ground	Not manual mode signal	Input	Ignition switch ON	Selector lever DS position	12 V
					Other than the above	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
14 (BR)	Ground	Communication signal (LCD → AMP.)	Input	Ignition switch ON	—	 <small>JSNIA0028GB</small>
25 (V)	Ground	Manual mode shift down signal	Input	Ignition switch ON	Selector lever down opera- tion	0 V
					Other than the above	12 V
26 (G)	Ground	Paddle shifter down signal	Input	Ignition switch ON	Paddle shifter down opera- tion	0 V
					Other than the above	12 V
27 (LG)	Ground	Communication signal (METER → AMP.)	Input	Ignition switch ON	—	 <small>JSNIA0027GB</small>
28 (R)	Ground	Vehicle speed signal output (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p><b>NOTE:</b> The maximum voltage varies de- pending on the specification (destination unit).</p>  <small>JSNIA0012GB</small>
30 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
					Parking brake OFF	 <small>JSNIA0007GB</small>
34 (Y)	Ground	Communication signal (AMP. → LCD)	Output	Ignition switch ON	—	 <small>JSNIA0027GB</small>
41 (V)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
42 (Y)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	<p style="text-align: center;">SKIB8867E</p>
45 (P)	Ground	Ambient sensor signal	Input	—	—	<p style="text-align: center;">JSNIA0014GB</p>
53 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
54 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
55 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
56 (L)	Ground	CAN-H	—	—	—	—
57 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	5 V
					The brake fluid level is lower than the low level	0 V
58 (BR)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
61 (BR)	Ground	Ambient sensor signal ground	—	Ignition switch ON	—	0 V
71 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
72 (P)	Ground	CAN-L	—	—	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >


## Wiring Diagram - METER -

INFOID:00000003887140

- \*1 114
- 105
- \*2 113
- 101

- With VQ engine
- With VK engine
- With climate controlled seat
- Without climate controlled seat

\*: This connector is not shown in "Harness Layout".




2008/03/04

JCNWM0994GB

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

## METER







Connector No. Connector Name Connector Type	B1 WIRE TO WIRE TH8DFW-CS16-TM4	Terminal No. Color of Wire Signal Name [Specification]	80 L 81 P 82 L 83 P 84 SB 86 Y 87 B	Terminal No. Color of Wire Signal Name [Specification]	1 SB 2 B	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B13 SEAT BELT BUCKLE SWITCH (DRIVER SIDE) (WITHOUT CLIMATE CONTROLLED SEAT) A03FW	Terminal No. Color of Wire Signal Name [Specification]	1 SB 2 B	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B21 FUEL LEVEL SENSOR UNIT (SUB) E02FGY-RS	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B22 FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN) E02FGY-RS	Terminal No. Color of Wire Signal Name [Specification]	1 SB 2 B	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B37 RAS CONTROL UNIT A38FW-M4	Terminal No. Color of Wire Signal Name [Specification]	1 L 2 L 3 L 4 L 5 L 6 L 7 L 8 L 9 L 10 L 11 L 12 L 13 L 14 L 15 L 16 L 17 L 18 L 19 L 20 L 21 L 22 L 23 L 24 L 25 L 26 L 27 L 28 L 29 L 30 L 31 L 32 L 33 L 34 L 35 L 36 L 37 L 38 L 39 L 40 L	Terminal No. Color of Wire Signal Name [Specification]	1 SB 2 B	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B38 E-SUS CONTROL UNIT AAB32FL	Terminal No. Color of Wire Signal Name [Specification]	1 SB 2 B	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	B58 WIRE TO WIRE NS10FW-CS	Terminal No. Color of Wire Signal Name [Specification]	55 61 56 60 59 21 15 16	Terminal No. Color of Wire Signal Name [Specification]	60 B 61 SB	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B
Connector No. Connector Name Connector Type	E201 WIRE TO WIRE TH8DFW-CS16-TM4	Terminal No. Color of Wire Signal Name [Specification]	1 L 2 L 3 L 4 L 5 L 6 L 7 L 8 L 9 L 10 L 11 L 12 L 13 L 14 L 15 L 16 L 17 L 18 L 19 L 20 L 21 L 22 L 23 L 24 L 25 L 26 L 27 L 28 L 29 L 30 L 31 L 32 L 33 L 34 L 35 L 36 L 37 L 38 L 39 L 40 L	Terminal No. Color of Wire Signal Name [Specification]	47 L 48 P	Terminal No. Color of Wire Signal Name [Specification]	1 Y 2 W	Terminal No. Color of Wire Signal Name [Specification]	2 W 5 B

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No.	B250	Connector No.	B501	Connector No.	B503	Connector No.	E3	Connector No.	E10	Connector No.	E7	Connector No.	E8	Connector No.	E32
Connector Name	BRAKE BOOSTER CONTROL UNIT	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE) (WITH CLIMATE CONTROLLED SEAT)	Connector Name	WIRE TO WIRE	Connector Name	WASHER LEVEL SWITCH	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	WASHER LEVEL SWITCH
Connector Type	TK24FW	Connector Type	NS10MIF-CS	Connector Type	NS10MIF-CS	Connector Type	A03FW	Connector Type	SAA38MB-RS10-SZZ	Connector Type	Z02FBR	Connector Type	TH02FW-M4	Connector Type	Z02FBR
															
Terminal No.	5	Terminal No.	60	Terminal No.	60	Terminal No.	60	Terminal No.	60	Terminal No.	60	Terminal No.	60	Terminal No.	35
Color of Wire	P	Color of Wire	R/Y	Color of Wire	R/Y	Color of Wire	R/Y	Color of Wire	R/Y	Color of Wire	R/Y	Color of Wire	R/Y	Color of Wire	Y
Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-L	Signal Name [Specification]	ITS COMM-H
	L		L		L		L		L		L		L		
Terminal No.	14	Terminal No.	61	Terminal No.	61	Terminal No.	61	Terminal No.	61	Terminal No.	61	Terminal No.	61	Terminal No.	35
Color of Wire	L	Color of Wire	B/Y	Color of Wire	B/Y	Color of Wire	B/Y	Color of Wire	B/Y	Color of Wire	B/Y	Color of Wire	B/Y	Color of Wire	Y
Signal Name [Specification]	ITS COMM-H	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—
	L		—		—		—		—		—		—		—
Terminal No.	40	Terminal No.	75	Terminal No.	75	Terminal No.	24	Terminal No.	24	Terminal No.	24	Terminal No.	24	Terminal No.	1
Color of Wire	P	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	LG
Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—
	L		—		—		—		—		—		—		—
Terminal No.	38	Terminal No.	75	Terminal No.	75	Terminal No.	24	Terminal No.	24	Terminal No.	24	Terminal No.	24	Terminal No.	2
Color of Wire	P	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	Y	Color of Wire	B/W
Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—
	L		—		—		—		—		—		—		—

JCNWM0998GB







# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

### METER

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH407V-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	P	AIR BAG
10	G	SECURITY
13	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH407V-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
5	L	SHIFT UP
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE
11	G	NOT MANUAL MODE
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN
26	G	PADDLE DOWN
27	LG	COMM (METER->AMP)

23	V	ACC
24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	BRAKE FLUID LEVEL SW
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SW
34	O	ILL COON OUT
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12MW-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	B	-
3	P	-
6	LG	-
7	SB	-

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72

Terminal No.	Color of Wire	Signal Name [Specification]
41	V	ACC
42	Y	FUEL LEVEL SENS
45	P	AMB SENS
53	G	IGN
54	Y	BAT
55	B	GND
56	L	CAN-H
57	W	BRAKE FLUID LEVEL SW
58	B	FUEL LEVEL SENS GND
61	BR	AMB SENS GND
71	B	GND

Connector No.	M56
Connector Name	TRIP A/B RESET SWITCH
Connector Type	TH04MM-NH



1	2	3	4
---	---	---	---





Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-




72	P	CAN-L
----	---	-------

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No.	M83	Connector No.	M85	Connector No.	M87	Connector No.	M88
Connector Name	AV CONTROL UNIT (WITHOUT NAVI)	Connector Name	AV CONTROL UNIT (WITHOUT NAVI)	Connector Name	AV CONTROL UNIT (WITH NAVI)	Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Type	TH24FW-NH	Connector Type	TH32FW-NH	Connector Type	TH46FW-NH	Connector Type	TH12FW-NH
							
Terminal No.	44	Terminal No.	86	Terminal No.	52	Terminal No.	70
Color of Wire	BR	Color of Wire	L	Color of Wire	L	Color of Wire	BR
Signal Name [Specification]	COMM (DISP->CONT)	Signal Name [Specification]	CAN-H	Signal Name [Specification]	CAN-H	Signal Name [Specification]	Signal Name [Specification]
	COMM (CONT->DISP)		CAN-L		CAN-L		COMM (DISP->CONT)
	COMM (CONT->DISP)		CAN-L		CAN-L		COMM (DISP->CONT)

Connector No.	M105	Connector No.	M107	Connector No.	M110	Connector No.	M116
Connector Name	AVD CONTROL UNIT	Connector Name	ECM (WITH V6 ENGINE)	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH	Connector Type	RH24FGY-RZ6-R-LH-Z	Connector Type	TH16MW-NH	Connector Type	TK3BMW-NS10
							
Terminal No.	8	Terminal No.	113	Terminal No.	1	Terminal No.	2
Color of Wire	L	Color of Wire	P	Color of Wire	L	Color of Wire	W
Signal Name [Specification]	CAN-H	Signal Name [Specification]	VEH-CAN-L1	Signal Name [Specification]	-	Signal Name [Specification]	Signal Name [Specification]
	CAN-L		VEH-CAN-H1		-		-
	CAN-L		VEH-CAN-H1		-		-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P



# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



MWI

JCNWM1005GB

## Fail-Safe

### FAIL-SAFE

The unified meter and A/C amp. activates the fail-safe control if CAN communication with each unit is malfunctioning.

INFOID:000000003887141

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Function	Specifications	
Speedometer	Reset to zero by suspending communication.	
Tachometer		
Fuel gauge		
Engine coolant temperature gauge		
Illumination control	When suspending communication, change to nighttime mode.	
Information display	The display turns off by suspending communication.	
Buzzer	The buzzer turns off by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	VDC OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	IBA OFF indicator lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	RAS warning lamp	
	Master warning lamp	
	AFS OFF indicator lamp	The lamp blinking caused by communication malfunction
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Tail lamp indicator lamp	
	Oil pressure warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
	Key warning lamp	
	Lane departure warning lamp	
LDP ON indicator lamp		
Sports mode indicator lamp		

### DTC Index

INFOID:000000003887142

Display contents of CONSULT-III	Time	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	CRNT, 1 - 39	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	<a href="#">MWI-49</a>
CONTROL UNIT (CAN) [U1010]	CRNT, 1 - 39	When detecting error during the initial diagnosis of CAN controller of unified meter and A/C amp.	<a href="#">MWI-50</a>
COMM ERROR 1 [B2201]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	<a href="#">MWI-51</a>
COMM ERROR 2 [B2202]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	<a href="#">MWI-53</a>
VEHICLE SPEED [B2205]	CRNT, 1 - 39	The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more.	<a href="#">MWI-55</a>

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT-III	Time	Diagnostic item is detected when ...	Refer to
ENGINE SPEED [B2267]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	<a href="#">MWI-56</a>
WATER TEMP [B2268]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	<a href="#">MWI-57</a>

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:000000004113577

### VALUES ON THE DIAGNOSIS TOOL

#### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
DOOR SW-DR	Driver door closed	Off	A
	Driver door opened	On	
DOOR SW-AS	Passenger door closed	Off	B
	Passenger door opened	On	
DOOR SW-RR	Rear RH door closed	Off	C
	Rear RH door opened	On	
DOOR SW-RL	Rear LH door closed	Off	D
	Rear LH door opened	On	
DOOR SW-BK	Back door closed	Off	E
	Back door opened	On	
CDL LOCK SW	Other than power door lock switch LOCK	Off	E
	Power door lock switch LOCK	On	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off	F
	Power door lock switch UNLOCK	On	
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off	G
	Driver door key cylinder LOCK position	On	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off	H
	Driver door key cylinder UNLOCK position	On	
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	I
HAZARD SW	Hazard switch is OFF	Off	I
	Hazard switch is ON	On	
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	J
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	K
TR/BD OPEN SW	Back door opener switch OFF	Off	K
	While the back door opener switch is turned ON	On	
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	L
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off	M
	LOCK button of the Intelligent Key is pressed	On	
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off	M
	UNLOCK button of the Intelligent Key is pressed	On	
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off	MWI
RKE-PANIC	PANIC button of the Intelligent Key is not pressed	Off	O
	PANIC button of the Intelligent Key is pressed	On	
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off	P
	UNLOCK button of the Intelligent Key is pressed and held	On	
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off	P
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On	
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V	
	Dark outside of the vehicle	Close to 0 V	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
ENGINE STATE	Engine stopped	Stop	A
	While the engine stalls	Stall	
	At engine cranking	Crank	B
	Engine running	Run	
S/L LOCK-IPDM	Steering is unlocked	Off	
	Steering is locked	On	C
S/L UNLK-IPDM	Steering is locked	Off	
	Steering is unlocked	On	D
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off	
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK	On	E
VEH SPEED 1	While driving	Equivalent to speedometer reading	F
VEH SPEED 2	While driving	Equivalent to speedometer reading	
DOOR STAT-DR	Driver door is locked	LOCK	G
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Driver door is unlocked	UNLOCK	
DOOR STAT-AS	Passenger door is locked	LOCK	H
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Passenger door is unlocked	UNLOCK	
ID OK FLAG	Steering is locked	Reset	I
	Steering is unlocked	Set	
PRMT ENG STRT	The engine start is prohibited	Reset	J
	The engine start is permitted	Set	
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset	K
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off	
	The Intelligent Key is inserted into key slot	On	L
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key	
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—	M
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet	
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done	MWI
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet	O
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done	
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet	P
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done	
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet	
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done	

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT




## PHYSICAL VALUES

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		12 V
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		12 V
4 (P)	Ground	Interior room lamp power supply (Battery saver signal)	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		12 V
5 (V)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	12 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ACC or ON	0 V
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
18 (O)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	0 V
				Turn signal switch OFF	6.5 V
					<p>PKID0926E</p>
19 (SB)	Ground	Room lamp timer	Output	Other than under condition	5.0 V
				<ul style="list-style-type: none"> <li>Interior room lamp timer is activated. (Door is unlocked. etc...)</li> <li>Welcome light function is activated.</li> </ul>	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	0 V
				Turn signal switch OFF	6.5 V
					<p>PKID0926E</p>
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	0 V
				Turn signal switch OFF	6.5 V
					<p>PKID0926E</p>
26 (G)	Ground	Rear wiper	Output	Rear wiper	0 V
				OFF (Stopped)	12 V
34 (SB)	Ground	Luggage room anten- na (-)	Output	Ignition switch OFF	0 V
				When Intelligent Key is in the passenger compart- ment	12 V
					<p>JMKIA0062GB</p>
					<p>JMKIA0063GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
35 (V)	Ground	Luggage room antenna (+)	Output		
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
38 (B)	Ground	Back door antenna (-)	Output	When the back door opener request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC
				ON	12 V
					0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
48 (W)	Ground	Back door opener switch operation	Output	Back door opener switch	Not pressed 12 V
				Pressed 0 V	
52 (LG)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position 12 V
					When selector lever is not in P or N position 0 V
61 (W)	Ground	Back door opener re- quest switch	Input	Back door re- quest switch	ON (Pressed) 0 V
					OFF (Not pressed)  1.0 V
64 (L)	Ground	Intelligent Key warn- ing buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding 0 V
					Not sounding 12 V
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position  1.0 V
					Not in stop position 0 V
66 (LG)	Ground	Back door switch	Input	Back door switch	OFF (Door close) 12 V
					ON (Door open) 0 V
67 (P)	Ground	Back door opener switch	Input	Back door opener switch	Pressed 0 V
					Not pressed  8.5 - 9.0 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)  8.5 - 9.0 V
					ON (Door open) 0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	 <p style="text-align: right; font-size: small;">JPMIA0594GB</p> <p style="text-align: center;">8.5 - 9.0 V</p>
				OFF (Door close)	ON (Door open)
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	<p>When Intelligent Key is in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Ignition switch OFF	<p>When Intelligent Key is not in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	<p>When Intelligent Key is in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Ignition switch OFF	<p>When Intelligent Key is not in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 <small>JMKIA0063GB</small>
75 (BR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area	 <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 <small>JMKIA0063GB</small>
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 <small>JMKIA0062GB</small>
				When the driver door request switch is operated with ignition switch OFF	 <small>JMKIA0063GB</small>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
77 (LG)	Ground	Driver door antenna (+)	Output		
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (P)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
83 (GR)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting		
				When operating either button on the Intelligent Key		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p>1.4 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	 <p>1.3 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p>1.3 V</p>
					Rear washer switch ON (Wiper intermittent dial 4)	 <p>1.3 V</p>
					Any of the conditions below with all switches OFF	 <p>1.3 V</p> <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>
89 (SB)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (Push switch)	Pressed Not pressed	0 V 12 V
90 (P)	Ground	CAN-L	Input/ Output	—	—	
91 (L)	Ground	CAN-H	Input/ Output	—	—	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
92 (LG)	Ground	Key slot illumination	Output		
				Blinking	 <p style="text-align: right; font-size: small;">JPMA0015GB</p>
				ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)
				OFF or ACC	Battery voltage
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF
				OFF or ON	12 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—	12 V
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status
				LOCK status	0 V
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	UNLOCK status
				UNLOCK status	12 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position
				P position	0 V
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	Any position other than P
				Any position other than P	12 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)
				ON (Pressed)	0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF (Not pressed)
				OFF (Not pressed)	 <p style="text-align: right; font-size: small;">JPMA0016GB</p>
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch	ON (Pressed)
				ON (Pressed)	0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC
				OFF or ACC	1.0 V
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch	ON (Pressed)
				ON (Pressed)	0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC
				OFF or ACC	1.0 V
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch	ON (Pressed)
				ON (Pressed)	0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC
				OFF or ACC	1.0 V
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch	ON (Pressed)
				ON (Pressed)	0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	12 V
				ON	0 V	
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 1.4 V
					Turn signal switch LH	 1.3 V
					Turn signal switch RH	 1.3 V
					Front wiper switch LO	 1.3 V
					Front washer switch ON	 1.3 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch INT (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 1.4 V
					Lighting switch PASS	 1.3 V
					Lighting switch 2ND	 1.3 V
					Front wiper switch INT	 1.3 V
					Front wiper switch HI	 1.3 V
					ON	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	OFF	 1.1 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
111 (GR)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V
					LOCK or UNLOCK	 <p style="text-align: right; font-size: small;">JMKIA0066GB</p>
					For 15 seconds after UN- LOCK	12 V
				15 seconds or later after UNLOCK	0 V	
112 (GR)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">JPMIA0156GB</p>	
					8.7 V	
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
116 (BR)	Ground	Stop lamp switch 1	Input	—	Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not de- pressed) and ICC brake hold relay OFF	0 V	
				Stop lamp switch ON (Brake pedal is de- pressed) or ICC brake hold relay ON	Battery voltage	
119 (SB)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 <p style="text-align: right; font-size: small;">JPMIA0594GB</p>
					UNLOCK status (Unlock switch sensor ON)	0 V
121 (BR)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot	12 V	
				When the Intelligent Key is not inserted into key slot	0 V	
122 (V)	Ground	ACC feedback	Input	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 8.5 - 9.0 V
					ON (Door opene)	0 V
132 (O)	Ground	Power window switch communication	Input/ Output	Ignition switch ON	 10.2 V	
				Ignition switch OFF or ACC	12 V	
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (B)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
140 (R)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	12 V
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 11.3 V
					OFF	12 V
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	 10.7 V
					Lighting switch HI	
					Lighting switch 2ND	
				Turn signal switch RH		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI


# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>						
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front wiper switch INT	
					Front wiper switch LO	
					Lighting switch AUTO	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
Turn signal switch LH						

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	 8.5 - 9.0 V
				ON (Door open)	0 V	
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V
				Not activated	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M


MWI

O  
P



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWM1991GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- <VO> : With VC engine
- <VK> : With VK engine
- <NV> : With NAVI
- <ON> : Without NAVI
- <OP> : Without automatic drive positioner
- <AN> : With rear anti-pinch system
- <NA> : Without rear anti-pinch system




\*: This connector is not shown in "Harness Layout".

JCMWM1992GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

◁ FX ▷ : With automatic drive positioner




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWM1994GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

19	SB	ROOM LAMP TIMER
----	----	-----------------

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY(BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT.(FUSE)
13	B	GND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)


67	P	BACK DOOR OPENER SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT.(F/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(RAP)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH




Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (PDM E./R) CONT
48	W	BK DOOR OPENER SW OPERATION
52	LG	STARTER RELAY CONT
61	W	BACK DOOR OPENER REQUEST SW
64	L	L-KEY WARN BUZZER (ENG ROOM)
65	O	REAR WIPER STOP POSITION
66	LG	BACK DOOR SW

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
4	L	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
25	G	TURN SIGNAL LH (REAR)
26	G	REAR WIPER OUTPUT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

JCMWM1995GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

137	B	RECEIVER/SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT N/P
141	G	SECURITY INDICATOR OUTPUT
142	O	COMBI SW OUTPUT 3
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPTICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
122	V	ACC F/B
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	O	POWER WINDOW SW COMM
134	GR	LOCK IND

83	GR	KEYLESS ENTRY RECEIVER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	SB	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	GR	S/L UNIT COMM

## BCM (BODY CONTROL MODULE)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	W	IMMOBI ANTENNA SIGNAL
82	P	IGN RELAY (F/B) CONT

JCMWM1996GB

## Fail-safe

INFOID:000000005176912

## FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (battery voltage)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position <ul style="list-style-type: none"> <li>- Power position: IGN</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- Interlock/PNP switch signal (CAN): OFF</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (battery voltage)</li> <li>- PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>• BCM steering lock control status</li> <li>• Steering lock condition No. 1 signal status</li> <li>• Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering lock unit status signal (CAN) is received normally</li> <li>• The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering condition No. 1 signal: LOCK (0 V)</li> <li>• Steering condition No. 2 signal: LOCK (Battery voltage)</li> </ul>

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### **NOTE:**

The blinking speed is normal while activating the hazard warning lamp.

### FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

#### **NOTE:**

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT position, BCM operates a fail-safe control.

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

A

## DTC Inspection Priority Chart

INFOID:000000004113580

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

B

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
3	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI SCANNING</li> </ul>
4	<ul style="list-style-type: none"> <li>• B2013: ID DISCORD BCM-S/L</li> <li>• B2014: CHAIN OF S/L-BCM</li> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP SW</li> <li>• B2605: PNP SW</li> <li>• B2606: S/L RELAY</li> <li>• B2607: S/L RELAY</li> <li>• B2608: STARTER RELAY</li> <li>• B2609: S/L STATUS</li> <li>• B260A: IGNITION RELAY</li> <li>• B260B: STEERING LOCK UNIT</li> <li>• B260C: STEERING LOCK UNIT</li> <li>• B260D: STEERING LOCK UNIT</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2612: S/L STATUS</li> <li>• B2614: ACC RELAY CIRC</li> <li>• B2615: BLOWER RELAY CIRC</li> <li>• B2616: IGN RELAY CIRC</li> <li>• B2617: STARTER RELAY CIRC</li> <li>• B2618: BCM</li> <li>• B2619: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B26E9: S/L STATUS</li> <li>• B26EA: KEY REGISTRATION</li> <li>• U0415: VEHICLE SPEED SIG</li> </ul>
5	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2622: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>
6	B26E7: TPMS CAN COMM

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

## DTC Index

INFOID:000000004113581

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-16. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference page
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	<a href="#">BCS-34</a>
U1010: CONTROL UNIT (CAN)	—	—	—	<a href="#">BCS-35</a>
U0415: VEHICLE SPEED SIG	—	—	—	<a href="#">BCS-36</a>
B2013: ID DISCORD BCM-S/L	×	×	—	<a href="#">SEC-50</a>
B2014: CHAIN OF S/L-BCM	×	×	—	<a href="#">SEC-51</a>
B2190: NATS ANTENNA AMP	×	—	—	<a href="#">SEC-42</a>
B2191: DIFFERENCE OF KEY	×	—	—	<a href="#">SEC-45</a>
B2192: ID DISCORD BCM-ECM	×	—	—	<a href="#">SEC-46</a>
B2193: CHAIN OF BCM-ECM	×	—	—	<a href="#">SEC-48</a>
B2195: ANTI SCANNING	×	—	—	<a href="#">SEC-49</a>
B2553: IGNITION RELAY	—	×	—	<a href="#">PCS-50</a>
B2555: STOP LAMP	—	×	—	<a href="#">SEC-54</a>
B2556: PUSH-BTN IGN SW	—	×	×	<a href="#">SEC-56</a>
B2557: VEHICLE SPEED	×	×	×	<a href="#">SEC-58</a>
B2560: STARTER CONT RELAY	×	×	×	<a href="#">SEC-59</a>
B2562: LOW VOLTAGE	—	×	—	<a href="#">BCS-37</a>
B2601: SHIFT POSITION	×	×	×	<a href="#">SEC-60</a>
B2602: SHIFT POSITION	×	×	×	<a href="#">SEC-63</a>
B2603: SHIFT POSI STATUS	×	×	×	<a href="#">SEC-65</a>
B2604: PNP SW	×	×	×	<a href="#">SEC-68</a>
B2605: PNP SW	×	×	×	<a href="#">SEC-70</a>
B2606: S/L RELAY	×	×	×	<a href="#">SEC-72</a>
B2607: S/L RELAY	×	×	×	<a href="#">SEC-73</a>
B2608: STARTER RELAY	×	×	×	<a href="#">SEC-75</a>
B2609: S/L STATUS	×	×	×	<a href="#">SEC-77</a>
B260A: IGNITION RELAY	×	×	×	<a href="#">PCS-52</a>
B260B: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-81</a>
B260C: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-82</a>
B260D: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-83</a>
B260F: ENG STATE SIG LOST	×	×	×	<a href="#">SEC-84</a>
B2612: S/L STATUS	×	×	×	<a href="#">SEC-88</a>
B2614: ACC RELAY CIRC	—	×	×	<a href="#">PCS-54</a>
B2615: BLOWER RELAY CIRC	—	×	×	<a href="#">PCS-56</a>
B2616: IGN RELAY CIRC	—	×	×	<a href="#">PCS-58</a>
B2617: STARTER RELAY CIRC	×	×	×	<a href="#">SEC-92</a>
B2618: BCM	×	×	×	<a href="#">PCS-60</a>
B2619: BCM	×	×	×	<a href="#">SEC-94</a>
B261A: PUSH-BTN IGN SW	—	×	×	<a href="#">SEC-95</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-98</a>

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference page	A
B2621: INSIDE ANTENNA	—	×	—	<a href="#">DLK-61</a>	B
B2622: INSIDE ANTENNA	—	×	—	<a href="#">DLK-63</a>	C
B2623: INSIDE ANTENNA	—	×	—	<a href="#">DLK-65</a>	D
B26E7: TPMS CAN COMM	—	—	—	<a href="#">BCS-38</a>	E
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-86</a>	F
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	<a href="#">SEC-87</a>	G

E

F

G

H

I

J

K

L

M

MWI

O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000004113582

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	Off
		<ul style="list-style-type: none"> <li>• Front fog lamp switch ON</li> <li>• Daytime running light activated (Only for Canada)</li> </ul>	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >


Monitor Item	Condition	Value/Status	
ST/INHI RLY	Ignition switch ON	Off	A
	At engine cranking	INHI → ST	
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN	B
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> <li>Press the selector button with selector lever in P position</li> <li>Selector lever in any position other than P</li> </ul>	C
	Release the selector button with selector lever in P position	On	D
S/L RLY -REQ	None of the conditions below are present	Off	
	<ul style="list-style-type: none"> <li>Open the driver door after the ignition switch is turned OFF (for a few seconds)</li> <li>Press the push-button ignition switch when the steering lock is activated</li> </ul>	On	E
S/L STATE	Steering lock is activated	LOCK	F
	Steering lock is deactivated	UNLOCK	
	[DTC: B210A] is detected	UNKWN	G
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
OIL P SW	Ignition switch OFF, ACC or engine running	Open	H
	Ignition switch ON	Close	
HOOD SW	Close the hood	Off	I
	Open the hood	On	
HL WASHER REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
THFT HRN REQ	Not operation	Off	J
	<ul style="list-style-type: none"> <li>Panic alarm is activated</li> <li>Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On	K
HORN CHIRP	Not operating	Off	L
	Door locking with Intelligent Key (horn chirp mode)	On	
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	M

MWI

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
4 (V)	Ground	Front wiper LO	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch HI	Battery voltage
7 (R)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch OFF	Lighting switch OFF	0 V
				Ignition switch ON	Lighting switch 1ST	Battery voltage
10 <sup>*1</sup> (SB)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)</li> </ul>		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
11 (BR)	Ground	Steering lock unit power supply	Output	Ignition switch OFF	A few seconds after opening the driver door	Battery voltage	A
				Ignition switch LOCK	Press the push-button ignition switch	Battery voltage	B
				Ignition switch ACC or ON		0 V	C
12 (B)	Ground	Ground	—	Ignition switch ON		0 V	D
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V	E
				<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		Battery voltage	F
16 (LG)	Ground	Front wiper stop position	Input	Ignition switch ON	Front wiper stop position	0 V	G
					Any position other than front wiper stop position	Battery voltage	H
19 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V	I
				Ignition switch ON		Battery voltage	J
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V	K
				Ignition switch ON		Battery voltage	L
26*2 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V	M
				Ignition switch ON		Battery voltage	
27 (Y)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC		Battery voltage	
				Ignition switch ON		0 V	
28 (O)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch		0 V	
				Release the push-button ignition switch		Battery voltage	
30 (GR)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any position other than P or N	0 V	
					Selector lever P or N	Battery voltage	
32 (SB)	Ground	Steering lock unit condition-1	Input	Steering lock is activated		0 V	
				Steering lock is deactivated		Battery voltage	
33 (P)	Ground	Steering lock unit condition-2	Input	Steering lock is activated		Battery voltage	
				Steering lock is deactivated		0 V	
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage	MWI
39 (P)	—	CAN-L	Input/ Output	—		—	
40 (L)	—	CAN-H	Input/ Output	—		—	O
41 (B)	Ground	Ground	—	Ignition switch ON		0 V	P
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC		0 V	
				Ignition switch ON		0.7 V	




# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
43 (SB)	Ground	Control device (Detention switch)	Input	Ignition switch ON	<ul style="list-style-type: none"> <li>Press the selector but- ton (Selector lever P)</li> <li>Selector lever in any po- sition other than P</li> </ul>	Battery voltage
					Release the selector but- ton (selector lever P)	0 V
44 (W)	Ground	Horn relay control	Input	The horn is deactivated		Battery voltage
				The horn is activated		0 V
45 (G)	Ground	Anti theft horn relay control	Input	The horn is deactivated		Battery voltage
				The horn is activated		0 V
46 (BR)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any posi- tion other than P or N	0 V
					Selector lever P or N	Battery voltage
48 (L)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is oper- ating)	Battery voltage
49 (W)*1 (SB)*3	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)</li> </ul>		Battery voltage
51 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
52*1 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)</li> </ul>		Battery voltage
54 (R)	Ground	Throttle control motor re- lay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)</li> </ul>		Battery voltage
55 (BR)	Ground	ECM power supply	Output	Ignition switch OFF		Battery voltage
56 (O)*1 (V)*3	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
57 (LG)*1 (R)*3	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
58 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
69 (W)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)</li> </ul>	0 – 1.5 V
70 (O)	Ground	Throttle control motor re- lay control	Output	Ignition switch ON → OFF	0 – 1.0 V ↓ Battery voltage ↓ 0 V
				Ignition switch ON	0 – 1.0 V
74 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
75 (Y)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped 0 V
				Engine running Battery voltage	
76 (P) <sup>*1</sup> (V) <sup>*3</sup>	Ground	Power generation com- mand signal	Output	Ignition switch ON	 <p>6.3 V</p>
				40% is set on "ACTIVE TEST", "AL- TERNATOR DUTY" of "ENGINE"	 <p>3.8 V</p>
				80% is set on "ACTIVE TEST", "AL- TERNATOR DUTY" of "ENGINE"	 <p>1.4 V</p>
77 (B) <sup>*1</sup> (L) <sup>*3</sup>	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>	0 – 1.0 V
				Approximately 1 second or more after turning the ignition switch ON	Battery voltage
80 (W)	Ground	Starter motor	Output	At engine cranking	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
83 (R)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
84 (P)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
86 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Canada)</li> </ul>	Battery voltage
						Front fog lamp switch OFF
87 (GR)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Canada)</li> </ul>	Battery voltage
						Front fog lamp switch OFF
88 (G)	Ground	Washer pump power supply	Output	Ignition switch ON		Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
						Lighting switch OFF
90 (Y)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
						Lighting switch OFF
91 (P)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
						Lighting switch OFF
92 (O)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
						Lighting switch OFF
97 (V)	Ground	Cooling fan control	Output	Engine idling		0 – 5 V
104 (LG)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V

\*1: VK engine models

\*2: Only for the models with ICC system


\*3: VQ engine models

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R -

INFOID:000000004113583



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

2008/03/04

JCMWM2014GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >




JCMWM2015GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

---

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P






MWI

JCMWM2016GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)		
Connector No.	Connector Name	Connector Type
E4	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	10PFB-MC
1	W	
2	L	
 		
Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	L	
 		
E5	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH20FW-CS12-M4-1V
4	V	
5	L	
7	R	
10	SB	
11	BR	
12	B	
13	Y	
16	LG	
19	W	
25	G	
26	R	
 		
E6	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH08FW-NH
39	P	
40	L	
41	B	
43	SB	
44	W	
45	G	
46	BR	
 		
E7	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH20FW-CS12-M4
48	L	
49	W	
49	SB	
51	G	
52	W	
53	W	
54	R	
55	BR	
56	V	
56	O	
57	R	
 		
E8	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	NS08FW-CS
83	R	
84	P	
86	W	
87	GR	
88	G	
89	BR	
90	Y	
 		
E9	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH18FW-NH
91	P	
92	O	
97	V	
104	LG	
 		

JCMWM2017GB

INFOID:000000004113584

## Fail-safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

### If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>License plate lamps</li> <li>Side marker lamps</li> <li>Illuminations</li> <li>Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF
Steering lock unit	Steering lock relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>Detects DTC "B2098: IGN RELAY ON"</li> <li>Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal. When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### DTC Index

INFOID:000000004113585

### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-16</a>
B2098: IGN RELAY ON	×	<a href="#">PCS-17</a>
B2099: IGN RELAY OFF	—	<a href="#">PCS-18</a>
B2108: STRG LCK RELAY ON	—	<a href="#">SEC-99</a>
B2109: STRG LCK RELAY OFF	—	<a href="#">SEC-100</a>
B210A: STRG LCK STATE SW	—	<a href="#">SEC-101</a>
B210B: START CONT RLY ON	—	<a href="#">SEC-105</a>
B210C: START CONT RLY OFF	—	<a href="#">SEC-106</a>
B210D: STARTER RELAY ON	—	<a href="#">SEC-107</a>
B210E: STARTER RELAY OFF	—	<a href="#">SEC-108</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-110</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-112</a>

# THE FUEL GAUGE POINTER DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### THE FUEL GAUGE POINTER DOES NOT MOVE

#### Description

INFOID:000000003887152

Fuel gauge needle will not move from a certain position.

#### Diagnosis Procedure

INFOID:000000003887153

#### 1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

1. Connect CONSULT-III.
2. Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter. Refer to [MWI-62, "Component Function Check"](#).

Does monitor value match fuel gauge reading?

- YES >> GO TO 2.  
NO >> Replace combination meter.

#### 2. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair harness or connector.

#### 3. CHECK FUEL LEVEL SENSOR UNIT

Perform a unit check for the fuel level sensor unit. Refer to [MWI-63, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

#### 4. CHECK FLOAT INTERFERENCE

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

- YES >> Replace unified meter and A/C amp.  
NO >> Repair or replace malfunctioning parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE METER CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

---

## THE METER CONTROL SWITCH IS INOPERATIVE

### Description

INFOID:000000003887154

If any of the following malfunctions is found for the meter control switch operation.

- All switches are inoperative
- The specified switch cannot be operated

### Diagnosis Procedure

INFOID:000000003887155

#### 1. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

---

Check the meter control switch signal circuit. Refer to [MWI-65, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK METER CONTROL SWITCH UNIT

---

Perform a unit check for the meter control switch. Refer to [MWI-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace meter control switch.

# THE TRIP A/B RESET SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

## THE TRIP A/B RESET SWITCH IS INOPERATIVE

### Description

INFOID:000000003887156

The trip A/B reset switch is inoperative.

### Diagnosis Procedure

INFOID:000000003887157

#### 1.CHECK TRIP A/B RESET SWITCH SIGNAL CIRCUIT

Check the trip A/B reset switch signal circuit. Refer to [MWI-67, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2.CHECK TRIP A/B RESET SWITCH UNIT

Perform a unit check for the trip A/B reset switch. Refer to [MWI-67, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace trip A/B reset switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

---

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

### Description

INFOID:000000003887158

The oil pressure warning lamp stays off when the ignition switch is turned ON

### Diagnosis Procedure

INFOID:000000003887159

#### 1. CHECK OIL PRESSURE WARNING LAMP

---

Perform auto active test. Refer to [PCS-11, "Diagnosis Description"](#).

Does oil pressure warning lamp blink?

YES >> GO TO 2.

NO >> Replace combination meter.

#### 2. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

---

Check the oil pressure switch signal circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK OIL PRESSURE SWITCH UNIT

---

Perform a unit check for the oil pressure switch. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Replace oil pressure switch.

# THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

### Description

INFOID:000000003887160

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure)

### Diagnosis Procedure

INFOID:000000003887161

#### 1. CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-11, "Diagnosis Description"](#).

Does oil pressure warning lamp blink?

YES >> GO TO 2.

NO >> Replace combination meter.

#### 2. CHECK IPDM E/R OUTPUT VOLTAGE

1. Disconnect the oil pressure switch connector.
2. Turn ignition switch ON.
3. Check voltage between the oil pressure switch harness connector and ground.

Terminals		Voltage
(+)	(-)	
Oil pressure switch		Approx. 12 V
Connector	Terminal	
F37	1	

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3. CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Replace oil pressure switch.

#### 4. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000003887162

- The parking brake warning is displayed during vehicle travel even though the parking brake is released
- The parking brake warning is not displayed even though driving the vehicle with the parking brake applied

### Diagnosis Procedure

INFOID:000000003887163

#### 1. CHECK PARKING BRAKE WARNING LAMP OPERATION

1. Start engine.
2. Check the operation of the parking brake warning lamp when operating the parking brake.

Condition	Warning lamp status
Parking brake applied	ON
Parking brake released	OFF

Is the inspection result normal?

- YES >> Replace combination meter.  
NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Check the parking brake switch signal circuit. Refer to [MWI-70, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NG >> Repair harness or connector.

#### 3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit check for the parking brake switch. Refer to [BRC-103, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.  
NO >> Replace parking brake switch.

# THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000003887164

- The warning is still displayed even after washer fluid is added
- The warning is not displayed even though the washer tank is empty

### Diagnosis Procedure

INFOID:000000003887165

#### 1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

Check the washer level switch signal circuit. Refer to [MWI-72. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK WASHER LEVEL SWITCH UNIT

Perform a unit check for the washer level switch. Refer to [MWI-72. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace washer level switch. Refer to [WW-110. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000003887166

- The door ajar warning is displayed even though all of the doors are closed.
- The door ajar warning is not displayed even though a door is ajar.

### Diagnosis Procedure

INFOID:000000003887167

#### 1. CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT-III and check the BCM input signals. Refer to [DLK-69, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "DOOR W/L" monitor value.

"DOOR W/L"

Door open : On

Door closed : Off

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace BCM. Refer to [BCS-82, "Removal and Installation"](#).

#### 3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Check the door switch signal circuit. Refer to [DLK-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

#### 4. CHECK DOOR SWITCH UNIT

Perform a unit check for the door switch. Refer to [DLK-71, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace applicable door switch. Refer to [DLK-269, "Removal and Installation"](#).

# THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

## THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

### Description

INFOID:000000003887168

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

### Diagnosis Procedure

INFOID:000000003887169

#### NOTE:

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-172, "INFORMATION DISPLAY : Description"](#).

#### 1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Check the ambient sensor signal circuit. Refer to [HAC-89, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2.CHECK AMBIENT SENSOR UNIT

Perform a unit check for the ambient sensor. Refer to [HAC-90, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace unified meter and A/C amp.

NO >> Replace ambient sensor. Refer to [HAC-180, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

## NORMAL OPERATING CONDITION COMPASS

### COMPASS : Description

INFOID:000000003887170

#### COMPASS

- The electronic compass is highly protected from changes in most magnetic fields. However, some large changes in magnetic fields can affect it. Some examples are (but not limited to): high tension power lines, large steel buildings, subways, steel bridges, automatic car washes, large piles of scrap metal, etc. While this does not happen very often, it is possible.
- During normal operation, the compass mirror will continuously update the compass calibration to adjust for gradual changes in the vehicle's magnetic "remnant" field. If the vehicle is subjected to high magnetic influences, the compass may appear to indicate false headings, become locked, or appear that it is unable to be calibrated. If this occurs, perform the calibration procedure.
- If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, verify the correct zone variance.

#### Symptom Chart

Symptom	Cause	Solution / Reference
The compass display reads "C".	<ul style="list-style-type: none"><li>• Compass is not calibrated.</li><li>• Incorrect zone variance setting.</li><li>• Large change in magnetic field (Steel bridges, subways, concentrations of metal, carwashes, etc.)</li><li>• Compass was calibrated incorrectly or in the presence of a strong magnetic field.</li></ul>	Perform calibration. Refer to <a href="#">MWI-39, "Description"</a> .
Compass shows the wrong direction.		
Compass does not change direction appears "Locked".		
Compass does not show all the directions, one or more is missing.		
The compass was calibrated but it "loses" calibration.		
On long trips the compass shows the wrong direction.	Perform zone variation setting if correct reading is desired in that location. Refer to <a href="#">MWI-39, "Description"</a> .	

## INFORMATION DISPLAY

### INFORMATION DISPLAY : Description

INFOID:000000003887171

#### AMBIENT AIR TEMPERATURE

The displayed ambient air temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the unified meter and A/C amp. Refer to [MWI-33, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

#### POSSIBLE DRIVING DISTANCE

The calculated possible driving distance may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3-3/10 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003887172

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# COMBINATION METER

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### COMBINATION METER


#### Exploded View

INFOID:000000003931393

#### REMOVAL

Refer to [IP-11. "Exploded View"](#).

#### DISASSEMBLY



1. Front cover


2. Unified meter control unit

#### Removal and Installation

INFOID:000000003931394

#### REMOVAL

1. Remove the cluster lid A. Refer to [IP-12. "Removal and Installation"](#).
2. Remove the combination switch. Refer to [BCS-83. "Removal and Installation"](#).
3. Remove screw (A) and connector, and then remove combination meter (1).



#### INSTALLATION

Install in the reverse order of removal.

#### Disassembly and Assembly

INFOID:000000003931395

#### DISASSEMBLY

Disengage the tabs to separate front cover.

#### ASSEMBLY

Assemble in the reverse order of disassembly.

# UNIFIED METER AND A/C AMP.

< REMOVAL AND INSTALLATION >

## UNIFIED METER AND A/C AMP.


### Exploded View

INFOID:000000003931396

#### REMOVAL

Refer to [JP-11, "Exploded View"](#).

#### DISASSEMBLY



1. Unified meter and A/C amp.
2. Bracket (LH)
3. AV control unit
4. Bracket (RH)

### Removal and Installation

INFOID:000000003931397

#### REMOVAL

1. Remove the display unit. Refer to [AV-252, "Removal and Installation"](#).
2. Remove the unified meter and A/C amp. and AV control unit as an assembly.
3. Remove the bracket screws and remove the unified meter and A/C amp.

#### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

- Unified meter and A/C amp. screws are different from other screws. Never confuse them when installing.
- Since AV control unit connector and unified meter and A/C amp. connector have the same form, be careful not insert them wrongly.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER CONTROL SWITCH

< REMOVAL AND INSTALLATION >

## METER CONTROL SWITCH


### Exploded View

INFOID:000000003931398

#### REMOVAL

Refer to [IP-11. "Exploded View"](#).

#### DISASSEMBLY



1. Meter control switch

### Removal and Installation

INFOID:000000003931399

#### REMOVAL

1. Remove cluster lid A. Refer to [IP-12. "Removal and Installation"](#).
2. Remove screws and remove meter control switch.
3. Remove meter control switch from instrument panel assembly.

#### INSTALLATION

Install in the reverse order of removal.


# TRIP A/B RESET SWITCH

< REMOVAL AND INSTALLATION >

## TRIP A/B RESET SWITCH

Exploded View

INFOID:000000003931400



1. Trip A/B reset switch

## Removal and Installation

INFOID:000000003931401

### REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-12. "Removal and Installation"](#).
2. Press pawls and remove trip A/B reset switch.

### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# COMPASS

< REMOVAL AND INSTALLATION >

---

## COMPASS

### Exploded View

INFOID:000000003887182

Refer to [MIR-67. "Exploded View"](#).

### Removal and Installation

INFOID:000000003887183

Refer to [MIR-68. "Removal and Installation"](#).

# CLOCK

< REMOVAL AND INSTALLATION >

## CLOCK


### Exploded View

INFOID:000000003931402

#### REMOVAL

Refer to [IP-11, "Exploded View"](#).

#### DISASSEMBLY



1. Clock

2. Cluster lid C


3. Multifunction switch

### Removal and Installation

INFOID:000000003931403

#### REMOVAL

1. Remove cluster lid C assembly. Refer to [IP-12, "Removal and Installation"](#).
2. Remove screws (A), (B), (C) and remove clock (2) in conjunction with multifunction switch (1) from cluster lid C.
3. Disengage the tabs to separate clock (2).



#### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Never confuse screws when installing.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI